

Hunter CC5C26C16

Hunter 52-Inch Matte Black Ceiling Fan (Model CC5C26C16) Instruction Manual

For Indoor and Covered Outdoor Use

INTRODUCTION

This manual provides comprehensive instructions for the safe installation, operation, and maintenance of your Hunter 52-inch Matte Black Ceiling Fan, Model CC5C26C16. This fan is designed to enhance comfort in both indoor and covered outdoor spaces, featuring a modern aesthetic with soft, curved blades. It is equipped with Surespeed technology for optimal airflow and a reversible motor for year-round functionality.

Key features of your fan include:

- **52-inch Diameter:** Ideal for large rooms up to 400 sq. ft.
- **Matte Black Finish:** A contemporary design suitable for various decor styles.
- **3 Blades:** Aerodynamically designed for efficient air movement.
- **Damp Rated:** Suitable for areas with high moisture, such as covered patios, garages, and breezeways, but protected from direct rain.
- **Reversible Motor:** Allows for downdraft mode in summer to cool and updraft mode in winter to circulate warm air.
- **Droop-Free Blades:** Constructed from durable materials to maintain blade integrity over time.
- **13-Degree Blade Pitch:** Optimized for ideal air movement and peak performance.
- **3-Speed Whisperwind Motor:** Provides powerful yet quiet operation.

SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Failure to follow these instructions could result in electric shock, fire, or personal injury.

- Always disconnect power at the main circuit breaker before working on the fan.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The fan must be mounted to a structurally sound ceiling joist or outlet box capable of supporting the fan's weight

(approximately 14.33 lbs).

- Ensure the fan blades are at least 7 feet (2.1 meters) from the floor and 18 inches (0.45 meters) from any wall or obstruction.
- Do not operate the fan with damaged blades or housing.
- Avoid placing objects in the path of the fan blades.
- This fan is damp rated, meaning it can be used in covered outdoor areas. It is not suitable for direct exposure to water or rain.

PACKAGE CONTENTS

Carefully unpack your fan and inspect the contents to ensure all parts are present and undamaged. Refer to the following list:

- Fan Motor Assembly
- 3 Fan Blades
- 2-inch Downrod
- Mounting Bracket
- Hardware Pack (screws, washers, wire nuts)
- Instruction Manual

SETUP AND INSTALLATION

Follow these steps for proper installation of your ceiling fan. If you are unsure about any part of the installation, consult a qualified electrician.

1. Prepare for Installation

1. **Turn off Power:** Before starting, ensure power is turned off at the circuit breaker to prevent electrical shock.
2. **Mounting Location:** Select a location where the fan can be securely mounted to a ceiling joist or an approved outlet box. Ensure there is sufficient clearance for the blades.

2. Install Mounting Bracket

Attach the mounting bracket to the ceiling outlet box using the screws provided. Ensure the bracket is firmly secured.

3. Assemble Fan

1. **Attach Downrod:** Insert the 2-inch downrod into the fan motor assembly and secure it with the provided pin and screw.
2. **Hang Fan:** Carefully lift the fan assembly and hang it from the mounting bracket using the hook provided on the downrod. This will allow you to make wiring connections hands-free.

4. Wiring Connections

Connect the electrical wires according to the wiring diagram in your separate wiring guide. Typically, this involves connecting the fan's wires to the household supply wires (live, neutral, and ground) using wire nuts.

5. Attach Blades

Once wiring is complete and the fan is securely mounted, attach the three fan blades to the motor housing using the screws provided. Ensure each blade is firmly fastened.

52"

Large Room
(up to 400 sq. ft.)



Matte Black



Damp Rated



Flexible Mounting



Reversible Motor



Hunter

OUTDOOR RATED

This image displays the Hunter 52-inch Matte Black Ceiling Fan, highlighting its key features including damp rating for versatile use, flexible mounting options, and a reversible motor for year-year comfort.



Hunter

OUTDOOR RATED


A detailed view of the Hunter ceiling fan, pointing out the 3-Speed Whisperwind Motor for quiet operation, the 13-degree blade pitch optimized for air movement, and the durable, droop-free blades.

Hunter

52
INCHES

LARGE ROOM

Fan Design May Vary



Low Profile:

2in downrod included

A: 9.63
B: 10.15

Standard:

4in downrod included

A: 11.63
B: 12.15

Angled:

36in downrod not included

A: 43.63
B: 44.15

Fan Dimensions

This diagram illustrates the various dimensions for installing the 52-inch Hunter ceiling fan, including measurements for low profile, standard, and angled mounting configurations. It shows 'A' as the distance from the ceiling to the bottom of the fan and 'B' as the distance from the ceiling to the bottom of the blades.

OPERATING INSTRUCTIONS

Your Hunter ceiling fan is designed for ease of use with a pull chain control for speed and a reversible motor switch for seasonal comfort.

Fan Speed Control

The fan features a 3-speed motor controlled by a pull chain. Pull the chain repeatedly to cycle through the speed settings:

1. **First Pull:** High Speed
2. **Second Pull:** Medium Speed
3. **Third Pull:** Low Speed
4. **Fourth Pull:** Off

Reversible Motor Function

The reversible motor allows you to optimize airflow for different seasons:

- **Summer Mode (Downdraft):** Push the reverse switch to the 'down' position. The blades will rotate counter-clockwise, creating a downdraft that produces a cooling breeze.

- **Winter Mode (Updraft):** Push the reverse switch to the 'up' position. The blades will rotate clockwise, creating an updraft that circulates warm air trapped near the ceiling, helping to warm the room.

Note: To change the direction of the fan, ensure the fan is turned off and the blades have come to a complete stop before engaging the reverse switch.

MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your Hunter ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.
- **Blade Cleaning:** Dust the blades regularly to prevent buildup, which can affect balance and performance.
- **Tighten Fasteners:** Periodically check all screws and fasteners on the fan and mounting hardware to ensure they are secure.
- **No Lubrication Needed:** The motor is permanently lubricated and does not require oiling.

Warning: Always turn off the power at the circuit breaker before performing any cleaning or maintenance.

TROUBLESHOOTING

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan will not start	No power to the fan.	Check circuit breaker and wall switch. Ensure all wire connections are secure.
Fan wobbles	Loose blade screws or mounting hardware.	Ensure all blade screws are tightened. Check that the mounting bracket and downrod are securely fastened.
Noisy operation	Loose screws, motor housing rubbing, or unbalanced blades.	Tighten all screws. Ensure no wires are rubbing against the motor housing. Check for any bent or damaged blades.
Air movement is insufficient	Fan speed too low or incorrect direction.	Increase fan speed using the pull chain. Ensure the fan is operating in downdraft mode for cooling (summer).

SPECIFICATIONS

Refer to the following technical specifications for your Hunter 52-inch Matte Black Ceiling Fan:

Specification	Detail
Brand	Hunter
Model Name	Hunter
Item Model Number	CC5C26C16
Color	Matte Black
Product Dimensions	52"D x 52"W x 12.15"H

Specification	Detail
Item Weight	14.33 Pounds
Number of Blades	3
Blade Pitch	13 Degrees
Air Flow Capacity	3535 Cubic Feet Per Minute
Wattage	45 Watts
Voltage	120 Volts
Speed	3 RPM (Speed settings)
Motor Type	Brushless AC Motor
Indoor/Outdoor Usage	Indoor / Covered Outdoor (Damp Rated)
Switch Type	Pull Chain
Downrod Length Included	2 Inches
Special Features	Reversible Motor, Variable Speed
Certification	ETL

ENERGYGUIDE

Estimated 
Yearly Energy Cost
\$13



Cost Range of Similar Models (19" – 84")

- Based on 12 cents per kWh and 6.4 hours use per day
- Your cost depends on rates and use**
- Energy Use: 45 Watts

Airflow
3,535
Cubic Feet Per Minute

- The higher the airflow, the more air the fan will move
- Airflow Efficiency: 79 Cubic Feet Per Minute Per Watt

All estimates based on typical use, excluding lights

ftc.gov/energy

The EnergyGuide label for the fan, indicating an estimated yearly energy cost of \$13 and an airflow capacity of 3,535 Cubic Feet Per

Minute, based on typical use.

WARRANTY AND SUPPORT

Hunter Fan Company products are manufactured to the highest quality standards. For specific warranty information, please refer to the warranty card included with your product or visit the official Hunter Fan Company website. For technical support, replacement parts, or any questions regarding your fan, please contact Hunter Fan Company customer service directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question