truke Clarity 6

truke Buds Clarity 6 User Manual

Model: Clarity 6

Introduction

Welcome to the truke Buds Clarity 6 user manual. This guide provides comprehensive instructions for setting up, operating, and maintaining your new earbuds. The truke Buds Clarity 6 are designed to deliver a superior audio experience with features like advanced ENC, dual device pairing, and ultra-low latency for gaming.



Image: truke Buds Clarity 6 earbuds and their charging case.

What's in the Box

- Wireless Charging Case
- Ear Cushions (various sizes)
- USB Type-C Cable
- User Manual (this document)
- Warranty Card

Product Overview

The truke Buds Clarity 6 feature a sleek design with touch-sensitive controls for easy operation.



Image: Close-up of truke Buds Clarity 6 highlighting the touch-glass design on the earbuds and the charging case.

Key Components:

- **Earbuds:** Left and Right, each with touch control area.
- **Charging Case:** Houses and charges the earbuds, with LED indicators for battery status.
- **USB Type-C Port:** For charging the case.
- **Microphones:** Six microphones for Environmental Noise Cancellation (ENC).

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the truke Buds Clarity 6 and their charging case. Connect the provided USB Type-C cable to the charging port on the case and a power source. The LED indicators on the case will show charging progress.



Image: The truke Buds Clarity 6 charging case connected via a USB Type-C cable, illustrating the fast charging capability.

A single charge provides up to 10 hours of playtime, with the charging case extending total playtime up to 80 hours.

2. Initial Pairing

1. Ensure the charging case has sufficient battery.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for "truke Buds Clarity 6" in the list of available Bluetooth devices.
5. Select "truke Buds Clarity 6" to connect. A voice prompt will confirm successful pairing.

The earbuds utilize Bluetooth 5.3 technology for stable and uninterrupted audio experiences.

3. Dual Device Pairing

The truke Buds Clarity 6 support seamless dual-connectivity, allowing you to switch between two devices effortlessly.



Image: A user simultaneously connected to a laptop and a smartphone, demonstrating the dual-connectivity feature of the truke Buds Clarity 6.

To enable dual pairing:

1. Pair the earbuds with your first device as described in "Initial Pairing".
2. Disconnect the earbuds from the first device's Bluetooth settings.
3. Pair the earbuds with your second device.
4. Reconnect the earbuds to the first device. The earbuds should now be connected to both devices simultaneously.

Note: The dual-pairing feature will automatically close if not connected with the second device within 3 minutes. To resume dual-pairing, tap the earbuds four times, or place both earbuds back into the charging case and reopen.

Operating Instructions

Touch Controls:

The truke Buds Clarity 6 feature intuitive touch controls on the glass part of each earbud.

Action	Left Earbud	Right Earbud
Play/Pause Music	Single Tap	Single Tap
Next Track	Double Tap	Double Tap
Previous Track	Triple Tap	Triple Tap
Answer/End Call	Single Tap	Single Tap
Reject Call	Long Press (2s)	Long Press (2s)
Activate Voice Assistant	Long Press (2s)	Long Press (2s)
Switch EQ Mode	N/A	Long Press (3s)

EQ Modes:

The earbuds offer 3 preset EQ modes to personalize your music experience:

- **Dynamic Mode:** Balanced audio for general listening.
- **Movie Mode:** Enhanced dialogue and sound effects for cinematic experience.
- **Bass Boost Mode:** Amplified bass for powerful audio.

To switch between EQ modes, simply press and hold the right earbud for 3 seconds.




Image: Visual representation of the three EQ modes (Dynamic, Movie, Bass Boost) available on the truke Buds Clarity 6.

Gaming Mode (Ultra-Low Latency):

For an optimized gaming experience, the earbuds feature 35ms ultra-low latency. This ensures lightning-quick audio synchronization, providing a competitive edge in games.



Image: truke Buds Clarity 6 earbuds positioned in front of a smartphone displaying a racing game, illustrating the low-latency gaming feature.

Activation of gaming mode is typically automatic when a low-latency connection is detected, or can be toggled via specific touch controls (refer to the table above if applicable, or product packaging for specific gesture).

Maintenance

Cleaning:

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Do not use abrasive cleaners or immerse the earbuds or case in water.

Storage:

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid storing in extreme temperatures or high humidity.

The earbuds are IPX5 water-resistant, meaning they can withstand splashes and sweat, but are not designed for submersion.

Troubleshooting

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close, then reopen. Turn off and on Bluetooth on your device. Forget the device in Bluetooth settings and re-pair.
Only one earbud working	Ensure both earbuds are charged. Place both back in the case, close, then reopen. Perform a factory reset (refer to product packaging or manufacturer's website for specific steps).
Poor call quality	Ensure microphones are not obstructed. Move to a quieter environment. The 6-Mic ENC technology reduces background noise, but extreme noise can still affect clarity.
Battery drains quickly	Ensure earbuds are fully charged before use. Reduce volume. Close unused apps on your connected device.
Dual pairing not working	Ensure both devices are within range. Tap the earbuds four times or place them back in the case to reset dual-pairing.

Specifications

Feature	Detail
Model Name	Clarity 6
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Driver Type	13mm Titanium Dynamic Driver
Battery Life (Earbuds)	Up to 10 hours (single charge)
Total Playtime (with Case)	Up to 80 hours
Charging Port	USB Type-C
Microphones	6-Mic Advanced ENC (Environmental Noise Cancellation)
Latency	35ms Ultra-Low Latency (Gaming Mode)
EQ Modes	3 Preset Modes (Dynamic, Movie, Bass Boost)
Water Resistance	IPX5 (Water Resistant)
Control Method	Touch
Item Weight	48 Grams
Product Dimensions	5.8 x 5.8 x 2.9 cm

Warranty and Support

The truke Buds Clarity 6 come with a**12-month warranty**, ensuring quality and customer satisfaction. truke has a vast service network with over 350+ service points for convenient and accessible support.



Image: Information regarding truke's 12-month warranty and customer support details.

Contact Information:

Contact Number: +91 9354170767

Email ID: support@eccentricindia.com

Brand Store: Visit the truke Store on Amazon

For any queries or assistance, please reach out to our customer support team.

© 2024 truke. All rights reserved.