

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [mabe](#) /
- › [Mabe RME360PVMRM0 Refrigerator User Manual](#)

mabe RME360PVMRM0

Mabe RME360PVMRM0 Refrigerator User Manual

Model: RME360PVMRM0 | Brand: Mabe

1. PRODUCT OVERVIEW

The Mabe RME360PVMRM0 refrigerator is a 360-liter (14 cubic feet) appliance designed for efficient food storage. It features a modern matte inox finish and an optimized internal organization system. This manual provides essential information for the safe and effective use of your refrigerator.



Image: Front view of the Mabe RME360PVMRM0 refrigerator, showcasing its matte inox finish and two-door design.

Key Features:

- Generous capacity for food storage.
- Elegant and modern design.
- Adapts perfectly to any kitchen style.

2. SETUP AND INSTALLATION

Proper installation is crucial for the optimal performance and longevity of your refrigerator. Follow these guidelines carefully.

2.1 Unpacking and Placement

- Remove all packaging materials, including tape and protective films.

- Place the refrigerator on a flat, stable surface.
- Ensure adequate ventilation around the unit. Maintain at least 5 cm (2 inches) of space from walls on the sides and back, and 10 cm (4 inches) at the top.
- Avoid direct sunlight or heat sources.

2.2 Electrical Connection

- The refrigerator operates on 127 Volts. Ensure your electrical outlet matches this requirement.
- Use a dedicated, grounded electrical outlet. Do not use extension cords or adapters.
- Allow the refrigerator to stand upright for at least 2-4 hours before plugging it in to allow compressor fluids to settle.

2.3 Dimensions and Door Orientation

The refrigerator has an independent installation type with a right-hand door orientation. Its dimensions are:

- **Depth:** 63 cm
- **Width:** 68 cm
- **Height:** 173.5 cm



**Instala, repara y
da mantenimiento
a tus productos con
Servicio mabe**

Al hacer tu compra, llámanos para
programar el servicio que requieras.

Teléfono: 461 471 7000.

WhatsApp: 55 41635939

servicio mabe

Te queda Bien

Image: Dimensional diagram of the Mabe RME360PVMRM0 refrigerator, indicating its height, width, and depth for installation planning.

3. OPERATING INSTRUCTIONS

This section details how to operate your Mabe refrigerator effectively.

3.1 Initial Operation

- After plugging in, allow the refrigerator to run empty for at least 4-6 hours to reach optimal cooling temperatures before loading food.
- The cooling method is via a compressor.

3.2 Temperature Control

This model does not feature adjustable temperature control. The refrigerator maintains an optimal temperature automatically for food preservation.

3.3 Storage Capacity and Organization

The refrigerator offers ample space with a total capacity of 360 liters (14 cubic feet). It includes:

- **Fresh Food Capacity:** 200 liters
- **Freezer Capacity:** 160 liters
- **Number of Shelves:** 6 (across both compartments)



Image: Interior of the Mabe RME360PVMRM0 refrigerator, showing organized food items on shelves and in door bins.



Image: Empty interior of the Mabe RME360PVMRM0 refrigerator, highlighting the shelf configuration and storage compartments.

4. MAINTENANCE

Regular maintenance ensures your refrigerator operates efficiently and extends its lifespan.

4.1 Cleaning

- **Exterior:** Clean the exterior surfaces with a soft cloth and mild detergent. Avoid abrasive cleaners.
- **Interior:** Periodically clean the interior with a solution of baking soda and warm water. Remove shelves and drawers for thorough cleaning.
- **Door Gaskets:** Clean door gaskets regularly to ensure a tight seal.

- **Condenser Coils:** For optimal efficiency, clean the condenser coils at the back or bottom of the refrigerator at least once a year. Unplug the unit before cleaning.

4.2 Manual Defrost System

This refrigerator features a manual defrost system for the freezer compartment. Defrost when frost accumulation reaches approximately 0.5 cm (1/4 inch) thickness.

1. Unplug the refrigerator from the power outlet.
2. Remove all food items from the freezer and store them in a cooler.
3. Leave the freezer door open to allow frost to melt naturally. Place towels at the bottom to absorb water.
4. Once all frost has melted, clean and dry the interior thoroughly.
5. Plug the refrigerator back in and allow it to cool down before returning food.
6. *Do not use sharp objects or heating devices to speed up defrosting, as this can damage the unit.*

5. TROUBLESHOOTING

Before contacting service, review these common issues and solutions.

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; power outage; circuit breaker tripped.	Ensure plug is secure; check household fuse/breaker; verify power supply.
Refrigerator is not cooling sufficiently.	Door left open; excessive food load; poor ventilation; dirty condenser coils.	Check door seal; reduce food load; ensure proper clearance; clean condenser coils.
Unusual noise from the refrigerator.	Unit not level; items vibrating inside; normal compressor operation.	Adjust leveling feet; rearrange items; some operational noise is normal. If noise is excessive or persistent, contact service.
Water on the floor.	Drain tube clogged; defrost water overflowing.	Clear drain tube; ensure proper defrosting procedure is followed.

If the problem persists after attempting these solutions, please contact Mabe customer service.

6. SPECIFICATIONS

Detailed technical specifications for the Mabe RME360PVMRM0 refrigerator.

Feature	Specification
Brand	Mabe
Model Number	RME360PVMRM0
UPC	757638371056
Product Dimensions (D x W x H)	63 cm x 68 cm x 173.5 cm
Item Weight	63 Kilograms
Capacity (Total)	14 Cubic Feet (360 Liters)

Feature	Specification
Fresh Food Capacity	200 Liters
Freezer Capacity	160 Liters
Color	Matte Inox
Installation Type	Freestanding
Number of Doors	2
Defrost System	Manual
Voltage	127 Volts
Finish Type	Matte
Cooling Method	Compressor
Number of Shelves	6
Adjustable Temperature Control	No
Door Orientation	Right
Annual Energy Consumption	175 Kilowatt Hours Per Year
Is Electric?	Yes
Pattern	Solid
BEE Rating	5 Star

7. WARRANTY AND SUPPORT

For warranty information, service, repairs, or maintenance, please contact Mabe customer support.



Image: Mabe Service contact details, including phone number and WhatsApp, for installation, repair, and maintenance services.

- **Telephone:** 461 471 7000
- **WhatsApp:** 55 41635939
- Please have your model number (RME360PVMRM0) and purchase date ready when contacting support.