Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Schleich 42659-23

Schleich Farm World - Working in The Forest Playset Instruction Manual

Model: 42659-23 | Brand: Schleich

Introduction

Welcome to the Schleich Farm World - Working in The Forest Playset. This manual provides essential information for the assembly, operation, and maintenance of your new playset. Designed for imaginative play, this set includes a tractor toy, action figure, dog figurine, and various accessories to simulate forest work activities.
Safety Information: This product contains small parts and is not suitable for children under 3 years of age due to choking hazards. Please ensure adult supervision during play, especially during initial assembly.

Setup and Assembly

The Schleich Farm World - Working in The Forest Playset requires some assembly. Follow these steps carefully to ensure proper setup.

Unboxing and Component Check

Carefully remove all components from the packaging. Verify that all parts listed below are present. If any parts are missing or damaged, please contact customer support.

- 1x Utility Vehicle
- 1x Forester Action Figure
- 1x Dog Figurine
- 1x Chainsaw (two pieces)
- 1x Helmet
- 1x Gas Can
- 3x Log Sections (interlocking)
- 1x Tree Stump
- 1x Hedgehog Figurine
- 1x Backpack
- 1x Hook on a rope



Figure 1: Overview of the Schleich Farm World - Working in The Forest Playset, showing the packaging and all included components: the utility vehicle, forester figure, dog, chainsaw, logs, and other accessories.

Assembling the Utility Vehicle

The utility vehicle requires assembly. Refer to the detailed instructions provided in the original packaging for step-by-step guidance. Key assembly points include attaching the wheels, seats, and cargo bed. Ensure all connections are secure.



Figure 2: The utility vehicle with its cargo bed open, demonstrating its functionality. The forester figure and dog are positioned nearby.



Figure 3: The utility vehicle with its front hood open, revealing engine details. The forester figure is shown with a wrench, suggesting maintenance or assembly.

Assembling Accessories

- **Chainsaw:** The chainsaw consists of two pieces that lock together. Align the parts and press firmly until they click into place.

- **Logs:** The log sections are designed to interlock, simulating cutting a large branch into smaller pieces. They can also be "split" in half.
- **Backpack:** Attach the backpack to the forester figure.
- **Hook on a rope:** This accessory can be used with the vehicle's front winch.

Operating the Playset

This playset encourages imaginative role-play centered around forest work. Here are some ways to interact with the components:

Using the Utility Vehicle

The utility vehicle features rolling wheels for movement. The forester figure can be placed in the driver's seat. The cargo bed can be opened to load and unload logs or other accessories. The front winch with the hook can be used for towing or pulling objects.



Figure 4: A child's hand demonstrates pushing the utility vehicle, with the forester figure in the driver's seat and the dog figure beside it, indicating active play.



Figure 5: The forester figure stands next to the utility vehicle, holding a gas can, ready for refueling operations.

Forestry Activities

The forester figure can hold the chainsaw to simulate cutting logs. The interlocking log pieces allow for realistic play scenarios where logs are cut and split. The tree stump provides a base for these activities. The dog and hedgehog figurines add to the forest environment.



Figure 6: The forester figure, wearing a helmet, is depicted using the chainsaw on logs placed on a tree stump, with the dog figure observing nearby.

Care and Maintenance

To ensure the longevity of your Schleich playset, follow these simple care instructions:

- **Cleaning:** Wipe figures and vehicle with a damp cloth. Do not use harsh chemicals or abrasive cleaners, as this may damage the paint or plastic.
- **Storage:** Store the playset in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Handling:** While durable, avoid excessive force or bending of smaller parts to prevent breakage.

Troubleshooting

If you encounter any issues with your playset, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Parts do not fit together during assembly.	Incorrect alignment or debris in connection points.	Ensure parts are correctly oriented. Check for any small obstructions and clear them. Apply gentle, even pressure.
Chainsaw pieces separate easily.	Not fully engaged or worn connection.	Press the two chainsaw pieces firmly together until a secure click is felt. If the issue persists, contact customer support.
Forester figure's arms are stiff or do not move.	Initial stiffness from packaging.	Gently manipulate the joints to loosen them. Avoid excessive force.
Vehicle wheels do not roll smoothly.	Debris in axle or improper assembly.	Check for hair or small particles around the axles and remove them. Ensure wheels were correctly attached during assembly.

Product Specifications

Product Name: Schleich Farm World - Working in The Forest Playset

Model Number: 42659-23

Brand: Schleich

Product Dimensions: 10.91 x 4.21 x 8.78 inches (27.7 x 10.7 x 22.3 cm)

Item Weight: 0.017 ounces (0.48 grams)

Recommended Age: 36 months - 8 years

Release Date: March 1, 2024

Materials: High-quality, durable plastic

Contents: Toy playset including utility vehicle, forester figure, dog figure, chainsaw, logs, tree stump, gas can, helmet, backpack, hedgehog.

Warranty and Customer Support

Schleich products are known for their high quality and durability. For specific warranty information, please refer to the documentation included with your purchase or visit the official Schleich website.
If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Schleich customer support:

- **Online Support:** Visit the Schleich Store on Amazon or the official Schleich website.
- **Contact Information:** Refer to the contact details provided in your product packaging.

Please retain your proof of purchase for any warranty claims.

© 2024 Schleich. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CH1HRQ67

More documents and user manuals: **https://manuals.plus/**