Bowers & Wilkins Px7 S2e

Bowers & Wilkins Px7 S2e Over-Ear Headphones User Manual

Model: Px7 S2e

Brand: Bowers & Wilkins

1. Introduction & Overview

The Bowers & Wilkins Px7 S2e Over-Ear Headphones are designed to provide a premium audio experience with advanced features. These wireless headphones combine 24-bit high-res DSP processing and custom 40 mm drive units for exceptional sound quality. They offer enhanced noise cancellation, a transparency mode, and crystal-clear call quality through an integrated microphone. The design prioritizes comfort with plush foam earpads and a sophisticated finish, making them suitable for extended listening sessions during travel, work, or study.

Key Features:

- **Premium Sound:** 24-bit high-res DSP processing and custom 40mm drivers with Qualcomm aptX Adaptive for superior audio.
- **Comfortable Design:** Plush foam earpads and metal accents ensure comfort for long listening periods.
- **Advanced Noise Cancellation:** Six microphones with advanced noise cancellation block unwanted sounds without compromising audio quality.
- **Customizable Listening:** Bowers & Wilkins Music app allows direct streaming, voice assistant support, and personalized noise cancellation adjustments.
- **Extended Battery Life:** Up to 30 hours of playback time with quick-charge support.

2. What's in the Box

Your Bowers & Wilkins Px7 S2e headphones come with the following components:

- Bowers & Wilkins Px7 S2e Over-Ear Headphones
- 1.2m USB-C to 3.5mm stereo jack audio cable

- 1.2m USB-C to USB-C cable
- Protective Case
- Literature pack (User Manual, Safety Information)




Image: Bowers & Wilkins Px7 S2e headphones shown with their protective case and charging/audio cables.

3. Setup

3.1. Initial Charging

Before first use, fully charge your Px7 S2e headphones. Connect the supplied USB-C to USB-C cable to the headphone's USB-C port and a compatible USB power source. A full charge takes approximately 2 hours and provides up to 30 hours of playback.




Image: The USB-C port on the headphone is shown connected to a charging cable.

3.2. Bluetooth Pairing

1. Ensure your headphones are charged and powered on.
2. Press and hold the Bluetooth pairing button (usually located on the right earcup) for 2 seconds until the LED indicator flashes blue.
3. On your device (smartphone, tablet, computer), go to Bluetooth settings and select "Bowers & Wilkins Px7 S2e" from the list of available devices.
4. Once connected, the LED indicator will turn solid blue.

3.3. Bowers & Wilkins Music App

Download the Bowers & Wilkins Music App from your device's app store (iOS or Android). The app allows you to:

- Customize noise cancellation and transparency modes.
- Adjust EQ settings for personalized sound.
- Manage connected devices.
- Update headphone firmware.

Your browser does not support the video tag.

Video: A user demonstrates the fit and handling of the Bowers & Wilkins Px7 S2e headphones, highlighting their form-fitting design.

4. Operating Instructions

4.1. Physical Controls

The Px7 S2e headphones feature intuitive physical buttons for easy control:

- **Power/Bluetooth Button:** Located on the right earcup. Press and hold to power on/off, short press for battery status, long press for Bluetooth pairing.
- **Volume Up/Down:** Located on the right earcup. Press to adjust volume.
- **Multi-function Button:** Located on the right earcup. Single press for Play/Pause, double press for Skip Forward, triple press for Skip Backward.
- **Quick Action Button:** Located on the left earcup. Customizable via the B&W Music App for functions like Noise Cancellation mode cycling or voice assistant activation.




Image: A detailed view of the control buttons on the right earcup of the headphones.

4.2. Noise Cancellation & Transparency Mode

- **Active Noise Cancellation (ANC):** Reduces external ambient noise for an immersive listening experience. Activate via the Quick Action button or the B&W Music App.
- **Transparency Mode:** Allows ambient sounds to pass through, keeping you aware of your surroundings without removing the headphones. Activate via the Quick Action button or the B&W Music App.

4.3. Wear Sensors

The headphones feature wear sensors that automatically pause your audio when you remove them and resume playback when you put them back on. This feature can be enabled or disabled via the B&W Music App.

Your browser does not support the video tag.

Video: A user demonstrates the comfortable fit and handling of the Bowers & Wilkins Px7 S2e headphones.

5. Maintenance

5.1. Charging the Battery

The Px7 S2e headphones offer up to 30 hours of battery life on a single charge. Use the provided USB-C to USB-C cable to charge the headphones. A 15-minute quick charge provides up to 7 hours of playback.

5.2. Cleaning and Care

- Clean the headphones with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Store the headphones in their protective case when not in use to prevent damage.

6. Troubleshooting

- **No Sound:** Ensure headphones are powered on, charged, and correctly paired. Check volume levels on both headphones and the connected device.
- **Pairing Issues:** Turn off Bluetooth on other nearby devices. Try resetting the headphones to factory settings (refer to the B&W Music App or full manual for instructions).
- **Charging Problems:** Ensure the USB-C cable is securely connected to both the headphones and the power source. Try a different USB-C cable or power adapter.
- **Poor Audio Quality:** Move closer to your connected device to reduce interference. Try disabling ANC or Transparency mode to see if it improves.

7. Specifications

Feature	Detail
Noise Control	Active Noise Cancellation

Connectivity Technology	Wired, Wireless (Bluetooth 5.0)
Audio Driver Type	Dynamic Driver
Audio Driver Size	40 Millimeters
Battery Life	30 Hours
Charging Time	30 Hours (Note: This likely refers to total playback time, not charging time. Typical charging time is ~2 hours for full charge.)
Headphones Jack	3.5 mm Jack (via USB-C to 3.5mm cable)
Item Weight	307 Grams (10.8 ounces)
Material	Leather, Metal, Plastic
Model Name	FP44547

8. Warranty and Support

Bowers & Wilkins products are engineered to deliver class-leading performance and are built to the highest standards. For detailed warranty information, product registration, and technical support, please visit the official Bowers & Wilkins website or contact their customer service. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question