

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Snakebyte](#) /

› [Snakebyte Gamepad Base X SB922466 Wired Controller User Manual](#)

Snakebyte SB922466

Snakebyte Gamepad Base X SB922466 Wired Controller User Manual

Model: SB922466 | Brand: Snakebyte

INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your Snakebyte Gamepad Base X SB922466 wired controller. Please read these instructions carefully before using the product to ensure optimal performance and longevity. This controller is designed for use with PC, Xbox 360, Xbox One, and Xbox Series X systems.

PRODUCT OVERVIEW

The Snakebyte Gamepad Base X is a wired controller featuring Hall Effect technology for enhanced precision and durability. It includes a 3.5 mm headset jack for audio connectivity and a 3-meter USB-C cable for a reliable connection.




Rear view of the Snakebyte Gamepad Base X, showing the USB-C port for connection.



HALL EFFECT SENSOR



Internal view highlighting the Hall Effect Sensor technology for precise joystick control and anti-drift functionality.



3,5 MM HEADSET JACK

Front view of the controller's bottom edge, showing the 3.5 mm headset jack for audio connectivity.

HALL EFFECT TRIGGERS



Top-rear view of the controller, highlighting the Hall Effect Triggers (green) for accurate and responsive input.

3 METER USB-C CABLE



Close-up of the controller's top, showing the 3-meter USB-C cable connected, emphasizing its length and wired connection.

SETUP INSTRUCTIONS

- Connect to Console/PC:** Insert the USB-C end of the included 3-meter cable into the port on the top of the controller.
- Plug into System:** Insert the standard USB-A end of the cable into an available USB port on your Xbox console (Xbox 360, Xbox One, Xbox Series X) or PC.
- System Recognition:** Your system should automatically detect and install the necessary drivers for the controller. This may take a few moments.
- Verify Connection:** Once recognized, the controller's indicator light will illuminate, signifying a successful connection and readiness for use.

OPERATING INSTRUCTIONS

- Basic Control:** Use the analog sticks for movement and camera control, the D-pad for directional input, and the face buttons

(A, B, X, Y) for in-game actions.

- Shoulder Buttons and Triggers:** The shoulder buttons (LB, RB) and Hall Effect triggers (LT, RT) provide additional input options, with the triggers offering precise pressure sensitivity.
- Headset Connection:** Plug any compatible 3.5 mm headset into the jack located at the bottom of the controller for in-game audio and voice chat.
- System Buttons:** Utilize the central Xbox/Home button to access system menus and the Start/Menu and View/Select buttons for in-game functions or menu navigation.

MAINTENANCE

- Cleaning:** Use a soft, dry cloth to wipe the surface of the controller. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.
- Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. Avoid wrapping the cable too tightly to prevent damage.
- Cable Care:** Do not pull on the cable to disconnect the controller. Always grasp the USB plug firmly.

TROUBLESHOOTING

- Controller Not Responding:**
 - Ensure the USB cable is securely connected to both the controller and the console/PC.
 - Try connecting the controller to a different USB port on your system.
 - Restart your console or PC.
- Input Lag or Disconnections:**
 - Verify the cable is not damaged.
 - Ensure no other devices are causing interference with the USB connection (less common for wired controllers but possible).
- Headset Audio Issues:**
 - Check if the headset is fully plugged into the 3.5 mm jack.
 - Test the headset with another device to confirm it is functional.
 - Adjust audio settings on your console or PC.

SPECIFICATIONS

Model Number	SB922466
Brand	Snakebyte
Connectivity Technology	Wired (USB-C)
Cable Length	3 meters
Compatible Platforms	PC, Xbox 360, Xbox One, Xbox Series X
Special Features	3.5 mm Audio Jack, Hall Effect Sensors (Joysticks & Triggers)
Number of Buttons	10
Product Dimensions	10 x 5 x 1.3 cm

Product Weight	180 g
-----------------------	-------

WARRANTY INFORMATION

This product is covered by a manufacturer's warranty. Please refer to the warranty card included in the product packaging or visit the official Snakebyte website for detailed terms and conditions regarding warranty coverage and claims.

SUPPORT

For technical assistance, troubleshooting beyond this manual, or general inquiries, please visit the official Snakebyte support website or contact their customer service department. Contact information can typically be found on the product packaging or the official brand website.

© 2023 Snakebyte. All rights reserved.