

## Manuals+


[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HEALTHY CHOICE](#) /

› [Healthy Choice 2.2L Water Tank Ice Cube Maker User Manual](#)

## HEALTHY CHOICE ICM22



# Healthy Choice 2.2L Water Tank Ice Cube Maker User Manual

Model: ICM22

## INTRODUCTION

Thank you for choosing the Healthy Choice 2.2L Water Tank Ice Cube Maker. This appliance is designed for efficient and convenient ice production, providing an impressive 12 kilograms of ice within 24 hours. With its user-friendly features, including LED indicators, touch control, and a self-clean function, this ice maker ensures a continuous supply of fresh ice for all your needs. Please read this manual thoroughly before operation to ensure safe and optimal performance.

## SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the appliance is placed on a stable, level surface away from direct sunlight and heat sources.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the ice maker from the power outlet before cleaning or when not in use.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep children and pets away from the appliance during operation.
- Use only potable water in the water tank.
- Do not block ventilation openings.

## PRODUCT OVERVIEW

Familiarize yourself with the components of your Healthy Choice Ice Cube Maker.



Figure 1: Front-side view of the Healthy Choice Ice Cube Maker.



Figure 2: Top view with the transparent lid open, revealing the ice basket and control panel.

## Components:

- **Transparent Grey Lid:** Allows viewing of the ice-making process.
- **Control Panel:** Features LED indicators and touch controls.
- **Ice Basket:** Removable basket for collecting ice cubes (0.7kg capacity).
- **Water Tank:** Internal reservoir for water (2.2L capacity).
- **Air Vent:** Located on the side for heat dissipation.
- **Ice Scoop:** Included for convenient ice retrieval.

## SETUP

1. **Unpacking:** Carefully remove the ice maker from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the unit on a flat, stable, and heat-resistant surface. Ensure there is adequate ventilation around the appliance, at least 15cm clearance from walls or other objects.
3. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Refer to the "Maintenance" section for detailed cleaning instructions.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

## OPERATING INSTRUCTIONS

### Adding Water:

1. Open the transparent lid.

2. Remove the ice basket.
3. Fill the water tank with potable water up to the MAX fill line. Do not overfill.
4. Replace the ice basket and close the lid.

## Starting Ice Production:

1. Press the "ON/OFF" button on the touch control panel. The indicator light will illuminate.
2. Select your desired ice cube size (small or large) using the "SELECT" button. The corresponding LED indicator will light up.
3. The ice maker will begin its cycle. The first batch of 9 bullet-shaped ice cubes will be ready in approximately 10 minutes.
4. The appliance can produce up to 12kg of ice in 24 hours under optimal conditions.



Figure 3: The ice maker producing ice, with ice cubes ready for use.

## Stopping Ice Production:

Press the "ON/OFF" button again to stop the ice-making process.

## **Ice Full Alarm:**

When the ice basket is full, the "ICE FULL" indicator light will illuminate, and the ice maker will automatically pause production. Remove ice from the basket to resume operation.



Figure 4: Close-up of the ice basket filled with bullet-shaped ice cubes and the included scoop.

## MAINTENANCE

### Regular Cleaning:

- Unplug the appliance before cleaning.
- Remove the ice basket and clean it with warm, soapy water. Rinse thoroughly.
- Wipe the interior of the water tank and ice collection area with a soft cloth dampened with a mild detergent solution. Rinse with clean water.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure all parts are completely dry before reassembling and storing or operating.

### Self-Clean Function:

The ice maker is equipped with a self-clean function for convenient internal cleaning. Refer to your appliance's specific instructions for activating this mode, typically involving filling the water tank and pressing a dedicated self-clean button or sequence.

### Storage:

If the ice maker will not be used for an extended period, drain all water from the tank, clean the unit thoroughly, and store it in a dry, well-ventilated area.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
<b>No Water Alarm</b> (Indicator light on)	Water tank is empty or water level is too low.	Fill the water tank with potable water up to the MAX line.
<b>Ice Full Alarm</b> (Indicator light on)	Ice basket is full.	Remove ice from the basket. The ice maker will resume operation automatically.
<b>Caution Alarm</b> (Indicator light on)	Indicates a potential malfunction or error.	Unplug the unit, wait a few minutes, then plug it back in and restart. If the issue persists, contact customer support.
Ice maker not producing ice	No water, power issue, or ambient temperature too high.	Check water level. Ensure unit is plugged in. Operate in a cool, well-ventilated area.
Ice cubes are too small or clumpy	Water temperature too high, or air vent blocked.	Use colder water. Ensure air vents are clear and not obstructed.

## SPECIFICATIONS




Figure 5: Dimensions of the Healthy Choice Ice Cube Maker.

Feature	Detail
---------	--------

Feature	Detail
Model Number	ICM22
Ice Production Capacity	12 kg / 24 hours
First Batch Time	Approx. 10 minutes (9 cubes)
Water Tank Capacity	2.2 Litres
Ice Basket Capacity	0.7 kg (700 grams)
Ice Cube Sizes	2 (adjustable)
Power	160 Watts
Dimensions (L x W x H)	23.3cm x 32cm x 32.4cm
Weight	6.9 kg
Manufacturer	lenoxx
Country of Origin	China

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Healthy Choice website.

If you encounter any issues not covered in the troubleshooting section, please contact Healthy Choice customer service for assistance.

© 2024 Healthy Choice. All rights reserved.

## Related Documents - ICM22

 <p>Model: POB400/POR400   Batch: PRS07A Household Use Only Caution: Read all instructions before use and save for future reference.</p>	<p><a href="#">Healthy Choice Electric 12" Pizza Oven User Manual and Recipes</a></p> <p>Comprehensive user manual for the Healthy Choice Electric 12" Pizza Oven (Model POB400/POR400), including safety guidelines, product overview, cooking instructions, cleaning tips, recipes, and troubleshooting.</p>
 <p>Model: AF720 Guaranteed to your health top and splash back. Do not place air fryer directly on top of splash back. Use air fryer on heat proof material and on a dry, flat and even surface. Never leave air fryer unattended while in use. Do not use air fryer on heat sensitive materials. Please read and retain instructions for future reference.</p>	<p><a href="#">Healthy Choice AF720 Digital Air Fryer: User Manual &amp; Cooking Guide</a></p> <p>Discover the Healthy Choice AF720 Digital Air Fryer. This guide covers its 7.1L capacity, turbo air technology, digital controls, pre-set programs, operation, cooking settings, troubleshooting, and cleaning for healthy home cooking.</p>

	<p><b><a href="#">Healthy Choice WC250 Cold Water Dispenser User Manual</a></b></p> <p>User manual for the Healthy Choice WC250 Cold Water Dispenser, providing instructions for operation, safety, maintenance, and troubleshooting. Learn how to use and care for your water dispenser.</p>												
 <p>DOUBLE INDUCTION COOKER</p> <p>Model: IC1600   Batch: PH4751</p> <p>HOUSEHOLD USE ONLY</p> <p>Caution: Read all instructions before use and save for future reference.</p>	<p><b><a href="#">Healthy Choice Double Induction Cooker IC1600 User Manual and Safety Guide</a></b></p> <p>Comprehensive user manual and safety guide for the Healthy Choice IC1600 Double Induction Cooker, detailing operation, features, cleaning, maintenance, and troubleshooting. Includes technical specifications and important safety precautions.</p>												
 <p>PRESSURE &amp; SLOW COOKER</p> <p>Model: PC600</p> <p>Batch: PH5439</p> <p>POWER: 2000W/1600W/1200W, 100-120V</p> <p>For more information, refer to the instruction book enclosed with this unit.</p> <table border="1"> <tr> <td>Introduction</td> <td>1</td> </tr> <tr> <td>Product Information</td> <td>2</td> </tr> <tr> <td>Parts</td> <td>3</td> </tr> <tr> <td>Setting Instructions</td> <td>4</td> </tr> <tr> <td>Temperature</td> <td>5</td> </tr> <tr> <td>Features</td> <td>6</td> </tr> </table>	Introduction	1	Product Information	2	Parts	3	Setting Instructions	4	Temperature	5	Features	6	<p><b><a href="#">Healthy Choice PC600 Pressure &amp; Slow Cooker User Manual</a></b></p> <p>Comprehensive user manual for the Healthy Choice PC600 6-litre Pressure and Slow Cooker. Includes instructions for use, safety precautions, cleaning, troubleshooting, and features.</p>
Introduction	1												
Product Information	2												
Parts	3												
Setting Instructions	4												
Temperature	5												
Features	6												
 <p>6.5L DIGITAL AIR FRYER</p> <p>CAUTION: TO AVOID DAMAGE TO YOUR BENCH TOP AND SPLASH BACK, DO NOT PLACE AIR FRYER DIRECTLY ON BENCH TOP.</p> <p>Model: AFG605   Batch: PH527</p> <p>Caution: Read all instructions before use and save for future reference.</p>	<p><b><a href="#">Healthy Choice 6.5L Digital Air Fryer User Manual and Recipes</a></b></p> <p>Comprehensive guide for the Healthy Choice 6.5L Digital Air Fryer (Model AFG605), including important safety precautions, operating instructions, cleaning and maintenance tips, troubleshooting, and a variety of recipes.</p>												