

[Manuals.plus](#) /

› [qirita](#) /

› Selfie Stick, 41" Extendable Phone Tripod Stand with Phone Holder & Detachable Remote, 360° Rotation Selfie Stick Tripod for Cell Phone
Compatible with iPhone, Android, Samsung Black

qirita QRTA-EXT-1041-BK

qirita Selfie Stick Tripod User Manual

Model: QRTA-EXT-1041-BK

INTRODUCTION

Thank you for choosing the qirita Selfie Stick Tripod. This versatile device combines a selfie stick, a phone tripod, and a tabletop phone stand into one compact unit, designed to enhance your mobile photography and videography experience. With its extendable design, rotatable phone holder, and detachable remote control, capturing perfect moments has never been easier. Please read this manual carefully to ensure proper use and maintenance of your device.

PRODUCT OVERVIEW

The qirita Selfie Stick Tripod is engineered for portability and functionality, offering multiple modes for various shooting needs.




Figure 1: Overview of the qirita Selfie Stick Tripod and its components.

Key Components:

- **Extendable Pole:** Multi-section telescopic pole for adjustable length.

- **Phone Holder:** Adjustable clip to securely hold smartphones, with 360° rotation and 225° tilt capabilities.
- **Tripod Base:** Foldable legs for stable freestanding use.
- **Detachable Bluetooth Remote:** Wireless remote for hands-free photo and video capture.
- **Action Camera Mount:** Integrated mount for compatibility with action cameras.

Wide Compatibility



Compatible With Action Cameras



Figure 2: Compatibility details for smartphones and action cameras.

The phone holder is compatible with most smartphones ranging from 2.5 to 3.7 inches (65-95mm) in width and features soft silicone padding to protect your device from scratches.

SETUP

1. Extending the Selfie Stick:

1. Hold the handle firmly.
2. Gently pull the top section of the pole upwards to extend it. The pole can extend from 7.7 inches (19.6 cm) to 41.7 inches (106 cm).
3. Ensure all sections are fully extended and locked into place for maximum stability.

Longest Extension



Ours



Others



106cm



Figure 3: Extending the selfie stick to its full length.

2. Setting up as a Tripod:

1. Locate the tripod legs at the base of the handle.
2. Fold out the three legs until they are fully splayed and form a stable base.
3. Place the tripod on a flat, stable surface. For optimal stability, extend the pole only as much as necessary.

3. Attaching Your Phone:

1. Open the phone holder clip by pulling the top jaw upwards.
2. Carefully insert your smartphone into the holder, ensuring it is centered and securely gripped by the silicone pads.
3. The phone holder can be rotated 360° for horizontal or vertical orientation and tilted 225° for various shooting angles.




Figure 4: Adjusting the phone holder for optimal angles.

4. Detaching the Phone Holder for Tabletop Use:

1. Gently slide the phone holder upwards from its mounting point on the selfie stick.
2. Once detached, the phone holder can be used as a compact tabletop stand for watching videos or video calls.

Detachable Cell Phone Holder



Figure 5: Detaching the phone holder for use as a tabletop stand.

1. Pairing the Bluetooth Remote Control:

1. The remote control is located in a slot on the handle of the selfie stick. Slide it out to remove.
2. Turn on the remote control by pressing and holding the button until the indicator light flashes.
3. On your smartphone, go to Bluetooth settings and search for new devices.
4. Select "Selfie" or "AB Shutter3" (or similar name) from the list of available devices to pair. The indicator light will stop flashing once paired.
5. Open your phone's camera app. Press the button on the remote to take photos or start/stop video recording.
6. When not in use, slide the remote back into its slot on the handle to prevent loss.

Handsfree Selfie



Figure 6: Using the detachable Bluetooth remote for hands-free operation.

The remote control has an operating range of up to 30 feet (10 meters) and is compatible with both iOS (5.1+) and Android (4.4+) devices.

2. Using with Action Cameras:

The selfie stick tripod includes a standard mount compatible with most action cameras. Simply attach your action camera to the designated mount at the top of the pole.



Figure 7: Versatile use with smartphones and action cameras.

- **Cleaning:** Wipe the selfie stick tripod with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, collapse the selfie stick to its most compact size (7.7 inches / 19.6 cm) and store it in a cool, dry place away from direct sunlight.
- **Battery:** The remote control uses a replaceable Lithium Metal battery. If the remote stops responding, replace the battery.
- **Avoid Over-extension:** While durable, avoid forcefully over-extending the pole or applying excessive weight, especially when used as a tripod in windy conditions.

Easy To Carry



Length: 7.7 in

Weight: 5.5 oz

Figure 8: Compact size for easy portability and storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control not pairing.	Remote not turned on; battery low; Bluetooth not enabled on phone; already paired to another device.	Ensure remote is on and charged. Enable Bluetooth on phone. Forget previous pairings. Restart phone and remote.
Remote control not taking photos.	Not paired; camera app not open; phone volume buttons not set to shutter.	Confirm pairing. Open camera app. Check phone camera settings to ensure volume buttons trigger shutter.
Tripod is unstable.	Legs not fully splayed; uneven surface; pole extended too far; windy conditions.	Ensure legs are fully open. Place on a flat, stable surface. Reduce pole extension. Use in calm conditions.
Phone not fitting in holder.	Phone too wide/narrow; protective case interfering.	Check phone width (2.5-3.7 inches). Remove bulky phone cases if necessary.

SPECIFICATIONS

Model Name: QRTA-EXT-1041-BK

Material: Aluminum, Silicone

Product Dimensions (Folded): 2.05 x 1.46 x 7.72 inches (19.6 cm)

Item Weight: 5.5 ounces (156 Grams)

Maximum Height: 41.7 inches (106 cm)

Minimum Height: 7.7 inches (19.6 cm)

Phone Holder Compatibility: 2.5 - 3.7 inches (65-95mm) width

Rotation Angle: 360° (phone holder), 225° (tilt)

Remote Control Range: Up to 30 feet (10 meters)

Remote Control Battery: 1 Lithium Metal battery (included)

Compatible Devices: Smartphones (iOS 5.1+, Android 4.4+), Action Cameras

Special Features: Lightweight, Remote Control, Rotatable, Telescopic, Portable

WARRANTY AND SUPPORT

Warranty information and specific support contacts are not provided within this manual. For warranty details, technical support, or customer service inquiries, please refer to the product packaging or visit the official qirita store on Amazon or their official website.

Qirita Store on Amazon: [Visit the qirita Store](#)

© 2025 qirita. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question