

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Homall](#) /

› [Homall Electric Height Adjustable Desk 160 x 80 cm User Manual](#)

Homall 0496

Homall Electric Height Adjustable Desk 160 x 80 cm User Manual

Model: 0496

INTRODUCTION

Thank you for choosing the Homall Electric Height Adjustable Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or faulty.
- Keep children and pets away from the desk during operation to prevent injury.
- Do not overload the desk. Refer to the specifications for maximum weight capacity.
- Ensure the power cord is not pinched or damaged. Connect to a grounded outlet.
- Avoid placing liquids directly on the control panel or near electrical components.
- The desk features an anti-collision system. However, always ensure the path of movement is clear when adjusting height.
- For indoor use only. Avoid exposure to moisture or extreme temperatures.

PACKAGE CONTENTS

Please verify that all the following components are included in your package:

- Desktop Panels (4 sections)
- Desk Legs (2)
- Foot Pads (2)
- Control Panel
- Motor and Power Adapter
- Cable Management Tray
- Headphone Hooks (2)

- Assembly Hardware (screws, bolts, Allen keys)
- Instruction Manual

SETUP AND ASSEMBLY

Assembly typically requires two people. Follow the detailed instructions provided in the included manual. The desktop consists of four panels that need to be joined.



The desktop is supplied in four separate panels that must be assembled together.

Key Assembly Steps:

1. **Assemble the Desktop:** Join the four desktop panels using the provided dowels and screws. Ensure they are tightly secured to form a single, stable surface.
2. **Attach Desk Legs:** Secure the desk legs to the assembled desktop using the designated hardware. Ensure the legs are oriented correctly.
3. **Install Foot Pads:** Attach the foot pads to the bottom of the desk legs for stability and floor protection.
4. **Mount Control Panel:** Secure the control panel to the underside of the desk in an easily accessible location.
5. **Connect Wiring:** Connect the motor, control panel, and power adapter according to the wiring diagram in the detailed manual. Ensure all connections are secure.
6. **Install Cable Management:** Attach the cable management tray and headphone hooks as desired to organize your workspace.



Utilize the integrated cable management system to keep your workspace tidy and organized.

OPERATING INSTRUCTIONS

Control Panel Functions:

80 KG MAXIMALLAST

Geprüftes Heben 50.000 Mal

50.000



The control panel allows for precise height adjustments, memory presets, and includes a USB charging port.

- **Up/Down Buttons (▲ / ▼):** Press and hold to manually adjust the desk height. Release to stop.
- **Memory Presets (1, 2, 3):** The desk features three programmable height settings.
- **Set Memory Position:** Adjust the desk to your desired height using the Up/Down buttons. Press the 'M' button, then press one of the number buttons (1, 2, or 3) within 3 seconds to save the current height.
- **Recall Memory Position:** Press the corresponding number button (1, 2, or 3) to automatically move the desk to the saved height.
- **Sit/Stand Reminder:** This function encourages alternating between sitting and standing positions for health benefits. Refer to the detailed manual for programming the reminder interval.
- **USB Charging Port:** A USB port is integrated into the control panel for convenient device charging.

Anti-Collision System:


The desk is equipped with an anti-collision system. If the desk encounters an obstacle during height adjustment, it will

automatically stop and reverse slightly to prevent damage. Always ensure the area around the desk is clear during operation.

SICHERHEIT ANTI-KOLLISIONSSYSTEM


MIT

Anti-Kollisions-Funktion



OHNE

Anti-Kollisions-Funktion



The anti-collision system automatically stops and reverses the desk if an obstacle is detected during movement.

MAINTENANCE

- **Cleaning:** Wipe the desk surface and legs with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Inspections:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Cable Management:** Regularly check the power cord and other cables for any signs of wear or damage.
- **Motor Care:** The electric motor is maintenance-free. Do not attempt to open or service the motor housing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk does not move.	Power cord disconnected; Motor cable loose; Overload.	Check power connection; Reconnect motor cable; Reduce weight on desk.

Problem	Possible Cause	Solution
Desk moves unevenly.	Uneven weight distribution; Loose connections.	Distribute weight evenly; Check and tighten all connections.
Memory function not working.	Incorrect programming.	Re-program memory positions following the operating instructions.
Anti-collision system triggers frequently.	Obstacles in the path; Sensor sensitivity.	Ensure clear path; Refer to detailed manual for sensor adjustment if available.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact customer support.


SPECIFICATIONS

- **Brand:** Homall
- **Model Number:** 0496
- **Color:** White
- **Product Dimensions (L x W x H):** 160 x 80 x 72 cm (minimum height)
- **Adjustable Height Range:** 72 cm to 131 cm
- **Material:** Wood, Metal
- **Weight Capacity:** Up to 80 kg
- **Features:** Height adjustable, Electric, Memory function, Anti-collision system, USB charging port
- **Item Weight:** 18 Kilograms
- **Country of Origin:** China



The desk offers a wide height adjustment range, promoting a healthier posture by allowing users to alternate between sitting and standing.

Desktop 25% Prozent breiter



The desk is designed for exceptional stability, supporting a maximum load of 80 kg and tested for 50,000 lift cycles.

WARRANTY INFORMATION

Homall products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to your purchase documentation or contact customer support for specific warranty terms and conditions.

CUSTOMER SUPPORT

For any questions, assistance with assembly, troubleshooting, or warranty claims, please contact Homall customer service. Detailed contact information can typically be found on the Homall website or your purchase receipt. We are committed to providing quality service to our users.

