Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl VL732

onerbl 31V AC/DC Adapter Instruction Manual

For VacLife VL732, Model 206, and Model 206A Cordless Stick Vacuum Cleaners

1. Introduction

Thank you for choosing the onerbl 31V AC/DC Adapter. This adapter is designed to provide reliable power for your VacLife VL732, Model 206, and Model 206A cordless stick vacuum cleaners. Please read this manual carefully before use to ensure proper operation and to prevent damage to the product or connected devices. Keep this manual for future reference.

This adapter is a high-quality replacement AC/DC power charger, tested and confirmed to be in great working condition, ensuring compatibility and performance with specified VacLife models.

2. Safety Information

To ensure safe operation and prevent injury or damage, please observe the following safety precautions:

- **Input Voltage:** Ensure the power outlet voltage matches the adapter's input specifications (AC 100-240V, 50/60Hz).
- **Compatibility:** Use this adapter only with compatible devices, specifically VacLife VL732, Model 206, and Model 206A cordless stick vacuum cleaners. Using it with incompatible devices may cause damage.
- **Protection Features:** The adapter includes built-in Over Voltage Protection, Over Heat Protection, Short-Circuit Protection, and Over-Current Protection to safeguard your devices.
- **Environmental Conditions:** Do not expose the adapter to water, moisture, or extreme temperatures. Use in a dry, well-ventilated area.
- **Physical Damage:** Do not use the adapter if the cord or plug is damaged. Do not attempt to open or repair the adapter yourself. Contact qualified service personnel for assistance.
- **Children and Pets:** Keep the adapter out of reach of children and pets.
- **Unplug When Not in Use:** Disconnect the adapter from the power outlet when not in use for extended periods.



Figure 2.1: The adapter features multiple protection mechanisms including short-circuit, over-voltage, and over-current protection to ensure electrical safety.

3. Product Overview

The onerbl 31V AC/DC Adapter is a compact and durable power supply designed for specific VacLife vacuum models. It features a robust construction with quality components.



Figure 3.1: Front and side view of the onerbl 31V AC/DC Adapter, showing the AC input prongs and DC output cable.




Figure 3.2: Physical dimensions of the adapter (approximately 2.6 inches long, 1.6 inches wide, 1.2 inches thick) and a cable length of 76 inches.



Figure 3.3: The adapter cable features a durable design with copper wire conductors and a protective PVC jacket for longevity and safety.

Package Contents:

- 1 x onerbl 31V AC/DC Adapter

4. Setup

Follow these steps to set up your onerbl 31V AC/DC Adapter:

1. **Verify Compatibility:** Confirm that your device is a VacLife VL732, Model 206, or Model 206A cordless stick vacuum cleaner.
2. **Inspect Adapter:** Before first use, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
3. **Connect to Device:** Plug the DC output connector of the adapter into the charging port of your VacLife vacuum cleaner. Ensure a secure connection.
4. **Connect to Power Outlet:** Insert the AC input prongs of the adapter into a standard wall power outlet (100-240V AC).



Figure 4.1: The adapter connected to a power source, ready for use with a compatible device.

5. Operating Instructions

Once the adapter is properly set up, it will begin to power or charge your compatible VacLife vacuum cleaner.

- **Charging Indication:** Refer to your VacLife vacuum cleaner's user manual for specific charging indicators (e.g., LED lights) to confirm that charging is in progress.
- **Charging Time:** Charging times will vary depending on the battery level and model of your vacuum cleaner. Consult your vacuum's manual for estimated charging durations.
- **Continuous Power:** The adapter can also provide continuous power to your device if it is designed to operate directly from an AC adapter.
- **Disconnecting:** To disconnect, first unplug the adapter from the wall outlet, then disconnect the DC connector from your device.

6. Maintenance

Proper maintenance ensures the longevity and safe operation of your adapter:

- **Cleaning:** Disconnect the adapter from all power sources and devices before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cable to prevent damage.
- **Cable Care:** Do not bend, twist, or pull the cable excessively. Avoid placing heavy objects on the cable.
- **Inspection:** Periodically inspect the adapter, cable, and connectors for any signs of wear or damage. If damage is found, discontinue use and replace the adapter.

7. Troubleshooting

If you encounter issues with your onerbl 31V AC/DC Adapter, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Device not charging/powering on.	Adapter not properly plugged into outlet. Adapter not properly connected to device. Power outlet is not active. Device issue (not adapter). Adapter is faulty.	Ensure adapter is fully inserted into a working wall outlet. Ensure DC connector is securely plugged into the device's charging port. Test the outlet with another device. Try charging the device with its original adapter (if available) to rule out a device issue. If all else fails, the adapter may be faulty and require replacement.
Adapter feels hot during use.	Normal operation (slight warmth is common). Overload or poor ventilation.	A slight warmth is normal. Ensure the adapter is in a well-ventilated area. Disconnect if it becomes excessively hot and allow it to cool. If overheating persists, discontinue use.
Visible damage to adapter or cable.	Physical damage.	Discontinue use immediately. Replace the adapter.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Detail
Brand	onerbl
Model Number	VL732 (Compatible with VacLife VL732, Model 206, 206A)
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	DC 31V, 0.5A (500mA)

Feature	Detail
Power Source	Corded Electric
Plug Type	Type C (US Standard)
Cable Length	Approximately 76 inches (1.93 meters)
Protection Features	Over Voltage Protection, Over Heat Protection, Short-Circuit Protection, Over-Current Protection
Manufacturer	Shenzhen Waweis Technology Co., Ltd

9. Warranty and Support

For warranty information or technical support, please refer to the retailer or manufacturer's official website where the product was purchased. Keep your purchase receipt as proof of purchase.

If you have any questions or require assistance, please contact onerbl customer service through the platform of purchase or their official support channels.

© 2026 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CH2Y8PW4

More documents and user manuals: **https://manuals.plus/**