XIAOMI L55M8-A2IN

XIAOMI 55-inch X Series 4K Smart Google LED TV (Model L55M8-A2IN) User Manual

Model: L55M8-A2IN

1. INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your XIAOMI 55-inch X Series 4K Smart Google LED TV, model L55M8-A2IN. Please read this manual thoroughly before using the product to ensure safe and optimal performance.

Image: Front view of the Xiaomi 55-inch X Series 4K Smart Google LED TV, showcasing its sleek design and display.

Key Features:

- **4K Ultra HD Dolby Vision Display:** Experience stunning visuals with vibrant colors and sharp details.
- **Premium Metal Bezel-less Design:** Modern aesthetic with maximized screen space.
- **Google TV Integration:** Access personalized content recommendations and a wide range of apps.
- **30W Cinematic Speakers:** Enhanced audio experience with Dolby Audio and DTS-X support.
- **PatchWall & PatchWall+:** Intuitive content interface with free live TV channels.

Image: A visual summary of the TV's main features, including its 4K Ultra HD display, bezel-less design, Google TV, and powerful speakers.

2. SAFETY INFORMATION

Always follow basic safety precautions when using this television to reduce the risk of fire, electric shock, and injury.

- Do not expose the TV to rain or moisture.
- Do not open the TV casing; refer all servicing to qualified personnel.
- Ensure proper ventilation around the TV.
- Keep the TV away from direct sunlight and heat sources.
- Use only the power cord provided with the TV.

3. WHAT'S IN THE BOX

Verify that all components are present upon unpacking:

- 1 x XIAOMI 55-inch LED TV
- 2 x Table Stand Base (along with screws)
- 1 x Remote Control
- 2 x AAA Batteries
- 1 x User Manual (this document)

4. SETUP

4.1 Unpacking

Carefully remove the TV and all accessories from the packaging. Retain the packaging for future transport or service needs.

4.2 Stand Installation (Table Mount)

If placing the TV on a table, attach the two provided stand bases to the bottom of the TV using the included screws. Ensure the stands are securely fastened.

Image: The Xiaomi TV displayed on a table stand, illustrating a typical home setup.

4.3 Wall Mount Installation

For wall mounting, it is recommended to use a professional installation service. Refer to the wall mount bracket's instructions for proper installation. Ensure the wall can support the weight of the TV.

4.4 Connecting Peripherals

The TV features various ports for connecting external devices. Refer to the diagram below for port locations and types.


Image: Detailed view of the TV's connectivity ports, including HDMI 2.1*3, USB 2.0*2, Ethernet, AV Input, Optical, and Headphone Jack.

- **HDMI:** Connect Blu-ray players, gaming consoles, or set-top boxes.
- **USB:** Connect USB drives for media playback.
- **Ethernet:** For wired internet connection.
- **AV Input:** For older devices using composite video and stereo audio.
- **Optical:** For digital audio output to soundbars or home theater systems.

- **3.5mm Headphone Jack:** For connecting headphones or external speakers.

4.5 Power Connection

After connecting all desired peripherals, plug the power cord into the TV and then into a wall outlet. The TV is now ready for initial setup.

5. OPERATING INSTRUCTIONS

5.1 First Time Setup

Upon first power-on, the TV will guide you through the initial setup process, including:

- Language selection
- Network connection (Wi-Fi or Ethernet)
- Google account sign-in for Google TV features
- Channel scanning

Image: An overview of Google TV and Google Assistant functionalities, emphasizing content-first interface, recommendations, and built-in Chromecast.

5.2 Remote Control Functions

The sleek remote control provides quick access to various features:

Image: The Xiaomi remote control, highlighting dedicated buttons for popular streaming services and features like Quick Wake, Quick Mute, and Quick Settings.

- **Quick Wake:** Turn on the TV in less than 5 seconds.
- **Quick Mute:** Double tap the volume down button to mute the audio.
- **Quick Settings:** Long press the PatchWall button to access the quick settings menu.
- Dedicated buttons for Netflix, Prime Video, Disney+ Hotstar, and YouTube.
- Integrated Google Assistant button for voice commands.

5.3 Navigating Google TV / PatchWall

Your TV offers two primary interfaces:

- **Google TV:** Provides a personalized content-first user interface with recommendations based on your viewing habits.
- **PatchWall:** An exclusive content experience offering access to over 30 OTT apps, 300+ Live channels, Universal Search, Kids Mode, and Smart Recommendations.

Image: The PatchWall interface, demonstrating its content aggregation from various streaming services and live channels.

Image: The PatchWall+ interface, showcasing its live TV channel guide and scheduling features.

5.4 Using Voice Assistant (Google Assistant)

Press the Google Assistant button on your remote and speak your commands to search for content, control smart home devices, or get information.

5.5 Display Settings

The TV supports advanced display technologies for an immersive viewing experience:

Image: Visual representation of the TV's support for Dolby Vision, HDR 10, and HLG, ensuring superior picture quality.

- **4K Dolby Vision:** Delivers ultra-vivid picture quality with incredible brightness, contrast, and color.
- **HDR 10 & HLG:** Provides enhanced contrast and a wider range of colors for a more realistic image.
- **Vivid Picture Engine:** Optimizes color, contrast, and clarity in real-time.
- **Reality Flow MEMC:** Reduces motion blur for smoother fast-moving scenes.

5.6 Audio Settings

The TV is equipped with 30W Cinematic Speakers and supports advanced audio technologies:

Image: A visual emphasizing the TV's 30W Cinematic Speakers and support for Dolby Audio, DTS-X, and DTS Virtual: X for an immersive sound experience.

- **Dolby Audio:** Delivers rich, clear, and powerful sound.
- **DTS-X & DTS Virtual: X:** Provides multi-dimensional audio for an immersive experience.

6. MAINTENANCE

6.1 Cleaning the TV

To clean the screen, gently wipe it with a soft, lint-free cloth. For the TV casing, use a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents.

6.2 Software Updates

The TV may receive periodic software updates to improve performance and add new features. Ensure your TV is connected to the internet to receive these updates automatically or check for them manually in the settings menu.

7. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common solutions:

Problem	Possible Solution
TV does not turn on	Check if the power cord is securely plugged into the TV and the wall outlet. Ensure the wall outlet is functioning.
No picture, but sound is present	Check the input source. Ensure external devices are properly connected and powered on.
No sound, but picture is present	Check the volume level and mute status. Verify audio cables for external sound systems.
Remote control not working	Replace the AAA batteries. Ensure there are no obstructions between the remote and the TV. Re-pair the remote if necessary.
Slow or laggy user interface	Restart the TV. Clear cache for apps. Ensure sufficient storage space. Perform a factory reset if the issue persists (note: this will erase all data).
Wi-Fi connectivity issues	Restart your router and modem. Ensure the TV is within range of the Wi-Fi signal. Check Wi-Fi settings on the TV.

8. SPECIFICATIONS

Detailed technical specifications for the XIAOMI 55-inch X Series 4K Smart Google LED TV (Model L55M8-A2IN):

Xiaomi Smart TV X Series (55)

122.5cm / 48.22inch
Length

71.2cm / 28inch
Height without Stand

140cm/55inch

77.8cm / 30.62inch
Height with Stand

103cm / 40.55inch
Distance between stands

32cm / 12.6inch

"*Mentioned dimensions are for reference only.

Image: Dimensional drawing of the Xiaomi 55-inch X Series TV, providing measurements for length, height (with/without stand), and stand spacing.

Feature	Detail
Brand	XIAOMI
Model	L55M8-A2IN
Screen Size	55 Inches (138 cm)
Resolution	4K Ultra HD (3840 x 2160)
Refresh Rate	60 Hertz
Viewing Angle	178 Degrees
Display Technology	LED

| Feature	Detail
HDR Support	4K Dolby Vision, HDR 10, HLG
Sound Output	30 Watts
Audio Technology	Dolby Audio, DTS-X, DTS Virtual: X
Operating System	Google TV
Processor	Quad Core A55
RAM	2 GB
Storage	8 GB
Connectivity	Dual Band Wi-Fi, Bluetooth 5.0, 3 x HDMI 2.1, 2 x USB 2.0, Optical Port, AV Port, Ethernet Port, 3.5 mm Jack
Power Consumption (On-mode)	160 Watts
Product Dimensions (LxWxH)	122.58 x 27.99 x 77.83 cm (with stand)
Item Weight	11.23 kg

Image: Side profile of the TV, illustrating its slim design and the location of side-facing ports.

Image: A graphic detailing the TV's internal components for seamless performance, including 2GB RAM, 8GB storage, and a Quad-core A55 processor.

9. WARRANTY & SUPPORT

Your XIAOMI TV comes with a comprehensive warranty:

- **1st Year:** Comprehensive Warranty
- **Additional 1 Year:** Free Warranty on the Display Panel

Please note that any physical damages to the unit are not covered under warranty. The brand warranty can be availed using your Amazon invoice.

Customer Support:

For any service requests or assistance, please contact XIAOMI customer support. You can access the user manual from the brand's official website for further details.

Say Goodbye to Waiting

99% of new TV installations are completed within **3 hours** of your appointment.

Need assistance? We're just a call away!

We're just a call away! Enjoy a call back from our team within **60 minutes** for any service request.

Swift solutions at your doorstep!

Our experts arrive at your home within **24 hours** of your service request, **99%** of the time.

Image: Details on Xiaomi's commitment to customer service, including efficient installation, prompt call-back support, and rapid doorstep service.