

wipro CIC203

Wipro Vesta CIC203 Radiant Induction Cooktop 2200W User Manual

Model: CIC203

1. INTRODUCTION

Thank you for choosing the Wipro Vesta CIC203 Radiant Induction Cooktop. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before use and retain it for future reference.

2. SAFETY INSTRUCTIONS

Important Safety Precautions:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- Ensure proper ventilation around the cooktop during operation.
- Use only induction-compatible cookware.

3. PRODUCT OVERVIEW

The Wipro Vesta CIC203 is a 2200W radiant induction cooktop designed for efficient and convenient cooking. It features a sleek black glass finish and intuitive feather touch controls.



Figure 3.1: Front view of the Wipro Vesta CIC203 Radiant Induction Cooktop, showcasing its sleek black design and control panel.



Figure 3.2: Side view of the Wipro Vesta CIC203 Radiant Induction Cooktop, highlighting its compact profile.

Key Features:

- **Feather Touch Controls:** For seamless and precise operation.
- **2200W High Power:** Ensures fast and efficient cooking.
- **Auto Switch-off:** Enhances safety by automatically turning off the cooktop.
- **Radiant Heating Element:** Provides even heat distribution for consistent cooking results.

- **7 Power Levels:** Offers versatile cooking options.
- **Smart Timer:** For precise cooking duration control.
- **8 Preset Menus:** Customizable options for various dishes.



Figure 3.3: Close-up of the cooktop's feather touch control panel, indicating various functions and power settings.

4. SETUP

1. **Unpacking:** Carefully remove the cooktop from its packaging. Retain all packaging materials for future transport or service.
2. **Placement:** Place the cooktop on a stable, flat, heat-resistant surface. Ensure there is adequate ventilation around the appliance (at least 10-15 cm clearance from walls or other objects).
3. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of the cooktop (220-240V, 50Hz).
4. **Cookware:** Use only induction-compatible cookware. These typically have a flat bottom and are made of magnetic materials like cast iron or magnetic stainless steel. A simple test is to see if a magnet sticks to the bottom of the pan.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

1. **Power On:** Place suitable cookware with food on the center of the cooking zone. Press the **ON/OFF** button to turn on the cooktop. The display will light up.
2. **Select Function:** The cooktop may start with a default power level or require you to select a cooking function. Use the **FUNC** button to cycle through available cooking modes or the **UP/DOWN** buttons to adjust power/temperature.
3. **Adjust Settings:** Use the **UP** and **DOWN** buttons to increase or decrease the power level or temperature as desired. The cooktop offers 7 power levels.
4. **Power Off:** After cooking, press the **ON/OFF** button to turn off the cooktop. The fan may continue to run for a short period to cool down internal components.



Figure 5.1: The Wipro Vesta CIC203 Induction Cooktop actively heating a pan, demonstrating its operational state.

5.2 Using Preset Menus

The cooktop includes 8 preset menus for common Indian dishes, simplifying your cooking process.

1. **Select Preset:** After turning on the cooktop, press the **PRESET** button to cycle through the available preset options (e.g., Chapati, Deep Fry, Idli, Milk, Boil, Curry, Saute, Cooker).
2. **Automatic Settings:** Each preset automatically adjusts the power and cooking time for optimal results.
3. **Adjust (if applicable):** Some presets may allow minor adjustments to power or time using the **UP/DOWN** buttons.



Figure 5.2: The cooktop display highlighting the various preset cooking options available for user convenience.

5.3 Using the Timer

The smart timer allows you to set a specific cooking duration.

1. **Activate Timer:** While cooking, press the **TIMER** button (if available, or use the **FUNC** button to navigate to timer setting).

2. **Set Time:** Use the **UP** and **DOWN** buttons to set the desired cooking time.
3. **Start Timer:** The timer will start automatically after a few seconds or by pressing the **START** button (if available). The cooktop will automatically switch off once the timer expires.

6. CLEANING AND MAINTENANCE

Regular cleaning and maintenance ensure the longevity and optimal performance of your cooktop.

- **Before Cleaning:** Always unplug the cooktop from the power outlet and allow it to cool completely before cleaning.
- **Surface Cleaning:** Wipe the glass surface with a soft, damp cloth and a mild detergent. For stubborn stains, use a non-abrasive cleaner specifically designed for glass cooktops.
- **Control Panel:** Gently wipe the feather touch control panel with a soft, dry cloth. Avoid excessive moisture.
- **Ventilation Openings:** Ensure the ventilation openings are free from dust and debris to prevent overheating. Do not block these openings during operation.
- **Do Not Immerse:** Never immerse the cooktop in water or any other liquid.

7. TROUBLESHOOTING

If you encounter issues with your cooktop, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Cooktop does not turn on.	No power supply; Power cord not plugged in; Fuse blown.	Check power outlet; Ensure cord is securely plugged in; Check household fuse/circuit breaker.
No heating.	Incorrect cookware; Cookware not centered; Cooktop in standby mode.	Use induction-compatible cookware; Center cookware on the cooking zone; Press ON/OFF to activate.
Display shows an error code.	Internal malfunction; Overheating.	Refer to the specific error code in the full manual (if available) or contact customer service. Unplug and allow to cool if overheating is suspected.
Fan continues to run after turning off.	Normal cooling process.	This is normal. The fan will stop automatically once the internal components have cooled down.

If the problem persists after attempting these solutions, please contact Wipro customer support.

8. SPECIFICATIONS

Model Number	CIC203
---------------------	--------

Brand	Wipro
Power Source	Electric
Power Consumption	2200 W
Heating Elements	1
Color	Black
Item Weight	2 kg 800 g
Item Dimensions (LxWxH)	41.3 x 11.5 x 35 Centimeters
Included Components	Induction Cooktop, Warranty Card and User Manual
Country of Origin	India
Manufacturer	Wipro Enterprises(P) Ltd

9. WARRANTY AND SUPPORT

Your Wipro Vesta CIC203 Radiant Induction Cooktop comes with a warranty. Please refer to the included Warranty Card for detailed terms and conditions.

For any product-related queries, assistance, or service requests, please contact Wipro Customer Care:

- **Customer Care Number:** 1800-425-1969
- **Email:** feedback.wcc@wipro.com

Please have your model number (CIC203) and purchase details ready when contacting support.