

## Nicebay HB-822

# Nicebay HB-822 One Step Hair Dryer Brush User Manual

Model: HB-822

## INTRODUCTION

Thank you for choosing the Nicebay HB-822 One Step Hair Dryer Brush. This innovative styling tool combines the power of a hair dryer with the versatility of a styling brush, allowing you to dry, straighten, curl, and volumize your hair with a single device. Designed for efficiency and hair health, it features ceramic coating, negative ion technology, and a user-friendly display screen for precise control. Please read this manual thoroughly before use to ensure safe and optimal performance.

## IMPORTANT SAFETY INFORMATION

**WARNING: To reduce the risk of death by electric shock, do not use this appliance near water.**

- Always unplug the appliance immediately after use.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.
- This appliance is equipped with an Appliance Leakage Circuit Interrupter (ALCI) safety plug. Press the RED button on the plug for initial use.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Do not use this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged.
- Always allow the appliance to cool down completely before storing.

## PRODUCT FEATURES

- **Versatile Styling Tool:** Combines straightening, curling, styling, and drying functions.
- **Visual Display:** Clear screen for easy control of airflow (Low, Medium, High) and temperature (130°F, 180°F, 240°F), offering 9 modes.
- **Unique Cold Air Function:** Delivers high-speed airflow at 100°F for quick cooling and setting styles.
- **Ceramic Coating and Negative Ion:** Oval-shaped ceramic barrel distributes heat evenly to minimize damage. Negative ions reduce static, promote smoothness, and decrease frizz and dryness.
- **Safe and Convenient:** Features an ALCI safety plug and a 360-degree swivel power cord to prevent tangles.
- **Oval Cool Tip:** Provides a safe area to hold the brush during styling.
- **Ergonomically Designed Handle:** Comfortable grip for ease of use.
- **Nylon Pin and Tufted Bristles:** Designed to gently detangle and grip hair for effective styling.

## Main Features



Ceramic Coating



360 Degree  
Negative Ion  
Air Vents



Button Control



Cool Tip



Soft Ball Pin  
And  
Tufted Bristles



Visual Settings

Image: Diagram illustrating the main features of the Nicebay Hair Dryer Brush, including dimensions, cool tip, ceramic coating, bristles, and controls.

## SETUP

1. **Unpack:** Carefully remove the Nicebay Hair Dryer Brush from its packaging.
2. **Inspect:** Check the appliance for any visible damage.
3. **Plug In:** Insert the ALCI safety plug into a standard electrical outlet. For initial use, press the RED button on the plug to activate the device.
4. **Power On:** Rotate the control dial at the base of the handle to turn the device on and select your desired airflow and temperature settings.



Image: Close-up of the Nicebay Hair Dryer Brush showing the ALCI safety plug, power specifications (125V/60Hz/1200W), and the 360-degree swivel power cord.

## OPERATING INSTRUCTIONS

1. **Prepare Hair:** For best results, towel-dry your hair to remove excess water. The brush works effectively on damp or slightly wet hair.
2. **Select Settings:** Rotate the control dial to choose your preferred airflow (Low, Medium, High) and temperature (130°F, 180°F, 240°F). The visual display will show the selected settings.
3. **Cold Air Function:** Press the dedicated cold air button (indicated by a snowflake icon on the display) to activate the 100°F cool shot for setting your style.

4. **Section Hair:** Divide your hair into manageable sections.

5. **Styling:**

- **For Volume:** Place the brush close to the roots and roll outwards, lifting the hair.
- **For Straightening:** Glide the brush slowly downwards through each section of hair.
- **For Curling Ends:** Wrap the ends of your hair around the oval barrel and hold for a few seconds before releasing.

6. **Finish:** Once your hair is dry and styled, turn the control dial to the 'OFF' position and unplug the appliance.

## All In One Blow Dryer Brush



Hair dryer



Hair brush



Straightener



Hair Curler



Image: Visual representation of the Nicebay Hair Dryer Brush's all-in-one capabilities, including hair drying, brushing, straightening, and curling.

## Visuable Settings

# 1200W

### General settings



Low



Medium



High

9 Free combinations

130°F 180°F 240°F

### Extra Cool Air Function



Image: Close-up of the Nicebay Hair Dryer Brush's visual display showing temperature and airflow settings, along with the extra cool air function.

Video: Official demonstration of the Nicebay hair dryer brush in use, showcasing its features and styling capabilities.

## MAINTENANCE

- **Cleaning Air Inlet:** Regularly clean the air inlet with a small brush to prevent dust and hair buildup, which can affect performance.
- **Bristle Care:** Remove any tangled hair from the bristles once the device has completely cooled down. Do not let the pins and tufted bristles bend.
- **Storage:** Ensure the device is completely cool before storing. Do not wrap the power cord around the device, as this can damage the cord.
- **Water Exposure:** Never place the device in water or any other liquid.

# Care Instructions




Clean air inlet regularly with small brushes.



Do not wrap the power cord around the device.



Do not let the pins and tufted bristles bent.



Remove hair when the device completely cool down.



Never place the device in water or other liquid.



Do not touch the device before it has cooled down completely.

Image: Visual guide to care instructions for the Nicebay Hair Dryer Brush, including cleaning the air inlet, removing hair, proper cord storage, avoiding water, and allowing to cool.

## TROUBLESHOOTING

### • Device Not Turning On:

- Ensure the power cord is securely plugged into a working outlet.
- Check the ALCI safety plug and press the RED reset button if it has tripped.
- Verify the control dial is turned to an 'ON' setting (Low, Medium, or High).

### • Insufficient Heat or Airflow:

- Check that the selected temperature and airflow settings are appropriate for your needs.
- Clean the air inlet to ensure it is not blocked by dust or hair.

### • Hair Getting Tangled:

- Ensure hair is thoroughly detangled before use.
- Work with smaller sections of hair.

- Brush gently and avoid wrapping hair too tightly around the barrel.

## SPECIFICATIONS

Feature	Detail
Model Number	HB-822
Product Dimensions	0.45 x 0.45 x 13 inches
Item Weight	1.43 Pounds (0.65 Kilograms)
Power	1200W
Voltage/Frequency	125V/60HZ
Number of Speeds	3 (Low, Medium, High)
Temperature Settings	130°F, 180°F, 240°F (plus 100°F Cold Air)
Material Type	Ceramic
Included Components	Safety Plug

## Unique Oval Design

For extra lift at roots  
Adding volume  
Curling ends




Image: Detailed view of the unique oval design of the brush barrel, showing its dimensions for optimal lift, volume, and curling.

### WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Nicebay HB-822 One Step Hair Dryer Brush, please contact Nicebay customer service. Refer to the product packaging or the official Nicebay website for contact information.