

[Manuals.plus](#) /

> [Kircuit](#) /

> Kircuit 24V AC/DC Adapter Instruction Manual

Kircuit 24V AC/DC Adapter for VEVOR Y428bt/Y468bt/Y428/Y468

Kircuit 24V AC/DC Adapter Instruction Manual

For VEVOR Y428bt, Y468bt, Y428, Y468 Bluetooth Wireless Thermal Shipping Label Printers

INTRODUCTION

This instruction manual provides essential information for the safe and effective use of your Kircuit 24V AC/DC Adapter. This adapter is specifically designed to provide reliable power to compatible VEVOR Y428bt, Y468bt, Y428, and Y468 Bluetooth Wireless Thermal Shipping Label Printers. Please read this manual thoroughly before use and retain it for future reference.

IMPORTANT SAFETY INFORMATION

To prevent injury or damage to the adapter or connected device, always observe the following safety precautions:

- Ensure the adapter's voltage and current ratings match the requirements of your device.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not disassemble or modify the adapter. Refer all servicing to qualified personnel.
- Unplug the adapter from the power outlet when not in use or during electrical storms.
- Keep out of reach of children.

SETUP

Follow these steps to set up your Kircuit AC/DC Adapter:

1. **Unpack the Adapter:** Carefully remove the adapter and its power cord from the packaging. Inspect for any visible damage.
2. **Connect the Power Cord:** Insert the 2-pin connector of the AC power cord firmly into the input port on the adapter unit.



Image: The Kircuit 24V AC/DC Adapter showing the main unit, the detachable AC power cord with a 2-pin plug, and the DC output cable with a barrel plug connector.

3. **Connect to Device:** Insert the barrel plug connector of the adapter's output cable into the power input port of your compatible VEVOR Y428bt, Y468bt, Y428, or Y468 Bluetooth Wireless Thermal Shipping Label Printer. Ensure a secure connection.



Image: The Kircuit 24V AC/DC Adapter plugged into a wall outlet, with the output cable connected to a device (printer, not fully visible) on a desk.

4. **Plug into Power Outlet:** Insert the AC power plug into a standard 100V-240V AC wall outlet.

OPERATING INSTRUCTIONS

Once properly connected, the Kircuit AC/DC Adapter will supply power to your VEVOR label printer. The adapter is designed for continuous operation within its specified voltage range.

- The adapter features built-in dynamic IC, charger IC, and power fuse for rapid charging and overcharge protection, ensuring safe and efficient power delivery.
- A small indicator light (if present, typically blue) on the adapter unit will illuminate when power is being supplied.



Image: The Kirccuit 24V AC/DC Adapter showing its dimensions (4.2 inch length, 1.8 inch width, 1.2 inch height) and highlighting the anti-interference magnetic ring on the output cable for system reliability.

MAINTENANCE AND CARE

Proper care will extend the life of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cables to prevent damage.
- **Cable Inspection:** Periodically inspect the power cord and output cable for any signs of fraying, cuts, or damage. If damage is observed, discontinue use immediately and replace the adapter.

TROUBLESHOOTING

If you encounter issues with your Kirccuit AC/DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Adapter not powering device.	No power from outlet. Loose connections. Incompatible device. Damaged adapter/cable.	Test outlet with another device. Ensure all connections (AC cord to adapter, adapter to device, adapter to wall) are secure. Verify your device is a compatible VEVOR Y428bt, Y468bt, Y428, or Y468 printer. Inspect adapter and cables for damage. If damaged, replace.
Adapter feels hot during use.	Normal operation (slight warmth). Overload or poor ventilation.	A slight warmth is normal. Ensure adapter is in a well-ventilated area. Do not cover. If excessively hot, disconnect immediately and contact support.
Device not charging/powering consistently.	Intermittent connection. Faulty adapter.	Check all cable connections for looseness. If problem persists, the adapter may be faulty and require replacement.

If the issue persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Kircuit
Model	24V AC/DC Adapter (Compatible with VEVOR Y428bt, Y468bt, Y428, Y468)
Input Voltage	100-240V AC
Output Voltage	24V DC
Connector Type	Barrel Plug (DC Output), 2-Pin (AC Input)
Special Features	Built-in Dynamic IC, Charger IC & Power fuse for rapid charging and overcharge protection. Anti-interference magnetic ring.
Color	Black
Manufacturer	Shenzhen Waweis Technology Co., Ltd
ASIN	B0CH3F7QTS

WARRANTY INFORMATION

This Kircuit AC/DC Adapter is covered by a standard manufacturer's warranty against defects in materials and workmanship. The warranty period typically begins from the date of purchase. Please retain your proof of purchase for warranty claims.

For specific warranty terms and conditions, or to initiate a warranty claim, please refer to the seller's return policy or contact the manufacturer directly. As per Amazon's policy, the buybox winner offers a 30-day return policy (refund/replacement).

CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report an issue with your Kircuit 24V AC/DC Adapter, please contact the seller or manufacturer through the platform where the product was purchased.

Seller: [LGM DYstore](#)

Manufacturer: Shenzhen Waweis Technology Co., Ltd

© 2023 Kircuit. All rights reserved.
Manual Version: 1.0

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CH3F7QTS>

More documents and user manuals: <https://manuals.plus/>