

Simfer SIM51GW

Simfer SIM51GW 500mm Single Cavity Gas Cooker User Manual

Model: SIM51GW | Brand: Simfer

INTRODUCTION

Welcome to your new Simfer SIM51GW Single Cavity Gas Cooker. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your appliance. Please read it thoroughly before use and keep it for future reference.

This gas cooker features a 51-liter capacity oven and a hob with four gas burners of varying sizes, offering versatility for all your cooking needs.

Image: Front view of the Simfer SIM51GW 500mm Single Cavity Gas Cooker. It is a white freestanding unit with a black oven door. The hob features four gas burners with black pan supports. The control panel is located above the oven door, featuring five rotary dials for burner and oven control.

IMPORTANT SAFETY INFORMATION

Always ensure proper ventilation when operating gas appliances.

Do not store flammable materials near the cooker.

Keep children and pets away from the appliance during operation.

Ensure the appliance is installed by a qualified professional.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use oven mitts or pot holders.
- Never use water to extinguish grease fires.
- Disconnect power before servicing.

SETUP AND INSTALLATION

Your Simfer SIM51GW gas cooker must be installed by a qualified and registered gas safe engineer in accordance with local regulations and standards.

Unpacking

- Carefully remove all packaging materials.
- Check the appliance for any signs of damage. Report any damage immediately to your retailer.
- Retain packaging for future transport if needed.

Positioning

- Ensure adequate clearance from adjacent walls and cabinets.
- The appliance dimensions are H:900mm x W:498mm x D:633mm.
- The cooker is designed for natural gas connection.

OPERATING INSTRUCTIONS

Gas Hob Operation

The hob features four gas burners: 1 large, 2 medium, and 1 small.

1. Place your cookware centrally on the burner grate.
2. Push in and turn the corresponding control dial counter-clockwise to the large flame symbol.
3. Use the simple button ignition to ignite the burner.
4. Adjust the flame size by turning the dial between the large and small flame symbols.
5. To turn off, turn the dial clockwise to the "off" position.

Oven Operation

The main oven cavity has a 51-liter capacity.

1. Ensure the oven is clear of any obstructions.
2. Turn the oven control dial to the desired temperature setting.
3. Allow the oven to preheat to the set temperature before placing food inside.
4. Monitor cooking progress through the double glass oven door.
5. To turn off, turn the dial to the "off" position.

MAINTENANCE AND CLEANING

Regular cleaning will help maintain the performance and appearance of your cooker.

Hob Cleaning

- Allow burners and pan supports to cool completely before cleaning.
- Remove pan supports and burner caps. Wash with warm soapy water.
- Wipe the hob surface with a damp cloth and mild detergent.

- Dry all parts thoroughly before reassembling.

Oven Cleaning

- The removable double glass oven door simplifies cleaning. Refer to the full manual for instructions on removing the door.
- Wipe the interior with a damp cloth and a non-abrasive oven cleaner suitable for gas ovens.
- Clean oven racks with warm soapy water.
- Ensure the oven is completely dry before next use.

TROUBLESHOOTING

Before contacting customer service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Burner not igniting	Gas supply off	Check gas supply valve.
Burner not igniting	Igniter dirty/blocked	Clean igniter with a small brush.
Oven not heating	Gas supply off	Check gas supply valve.
Oven not heating	Temperature dial not set	Ensure dial is set to a temperature.
Uneven cooking	Cookware placement	Ensure cookware is centered and appropriate size.

TECHNICAL SPECIFICATIONS

Model: SIM51GW

Brand: Simfer

Type: Single Cavity Gas Cooker

Capacity: 51 Liters (Oven)

Hob: 4 Gas Burners (1 large, 2 medium, 1 small)

Dimensions (H x W x D): 900mm x 498mm x 633mm

Fuel Type: Natural Gas

Ignition: Button Ignition

Oven Door: Removable Double Glass

ASIN: B0CH3TD853

Date First Available: November 3, 2021

WARRANTY AND CUSTOMER SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact

Simfer directly. Keep your proof of purchase for warranty claims.
For technical assistance or spare parts, please contact an authorized Simfer service center.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question