

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [AMONIDA](#) /

> [AMONIDA Bluetooth Clip-on Earbuds User Manual](#)

AMONIDA AMONIDA7xcevo2squ-11

AMONIDA Bluetooth Clip-on Earbuds User Manual

Model: AMONIDA7xcevo2squ-11

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the AMONIDA Bluetooth Clip-on Earbuds. These innovative open-ear headphones are designed for comfort and high-fidelity audio, featuring an ergonomic clip-on design, IPX5 water resistance, HiFi stereo sound, intuitive touch controls, and low-latency performance, making them ideal for sports and daily use.



Image: The AMONIDA Bluetooth Clip-on Earbuds resting in their open charging case, showcasing their compact design.

2. PACKAGE CONTENTS

- AMONIDA Bluetooth Clip-on Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Manual (this document)



Image: The earbuds in their charging case, accompanied by the USB-C charging cable, illustrating the complete package contents.

3. SETUP

3.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case, ensuring they are correctly seated.
2. Connect the USB-C charging cable to the charging port on the back of the case.
3. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.

4. The indicator lights on the case will show charging status. Once fully charged, the lights will indicate completion (refer to specific light behavior in product packaging if available).



Image: Rear view of the charging case, highlighting the USB-C charging port for easy connection.

3.2. Bluetooth Pairing

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode (indicator lights will flash, typically blue or white).
3. On your device (smartphone, tablet, computer), enable Bluetooth.
4. Search for "AMONIDA Earbuds" or a similar name in the list of available Bluetooth devices.
5. Select the earbuds to connect. Once connected, the indicator lights on the earbuds will stop flashing.
6. The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

3.3. Wearing the Earbuds

The AMONIDA earbuds feature an ergonomic clip-on design for a secure and comfortable fit, especially during physical activity.

1. Identify the Left (L) and Right (R) earbuds.
2. Gently clip the earbud onto your ear, positioning the speaker part over your ear canal and the clip securely around the back of your ear.
3. Adjust for optimal comfort and sound quality. The open-ear design allows you to remain aware of your surroundings.



Strenuous exercise can not be shaken off

Comfortable to wear, long wear no pain,
crazy can not shake off, free sports.

Image: A person wearing an AMONIDA earbud, illustrating how the ergonomic clip-on design fits securely and comfortably on the ear.

4. OPERATING THE EARBUDS

4.1. Power On/Off

- **Power On:** The earbuds automatically power on when removed from the charging case.
- **Power Off:** Place the earbuds back into the charging case to automatically power them off and begin charging.

4.2. Touch Controls

The earbuds feature intuitive touch controls on their outer surface. Specific functions may vary slightly by model or firmware version. Refer to the quick start guide included with your product for precise touch commands.

Action	Function
Single Tap (L/R)	Play/Pause music, Answer/End call

Action	Function
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (L/R)	Activate Voice Assistant (Siri, Google Assistant)
Long Press (L/R)	Reject Call
Long Press (Right)	Volume Up
Long Press (Left)	Volume Down

5. MAINTENANCE

5.1. Cleaning

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure charging contacts are clean and dry.

5.2. Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Store in a cool, dry place, away from extreme temperatures and direct sunlight.

5.3. Water Resistance (IPX5)

The AMONIDA earbuds are rated IPX5, meaning they are protected against low-pressure water jets from any direction. This makes them suitable for workouts and light rain.

- Do not submerge the earbuds in water.
- Do not expose them to saltwater, chlorinated water, or other liquids.
- If the earbuds get wet, dry them thoroughly before placing them back in the charging case to prevent damage to the charging contacts.

Sweat-proof for free sports

IPX5 professional waterproof, high sealing body,
Effectively resist the rain and sweat in daily life.



Image: The earbuds and charging case are shown with water droplets, visually representing their IPX5 sweat-proof and splash-proof capabilities.

6. TROUBLESHOOTING

6.1. Common Issues and Solutions

- **Earbuds not pairing:**
 - Ensure earbuds are charged and out of the case.
 - Turn off and on Bluetooth on your device.
 - Forget the device from your Bluetooth list and try pairing again.
 - Try pairing with another device to rule out device-specific issues.
- **No sound or low volume:**
 - Check volume levels on both earbuds and your connected device.

- Ensure earbuds are properly connected to your device.
- Clean any debris from the earbud speakers.

- **Earbuds not charging:**

- Ensure the charging cable is securely connected to both the case and power source.
- Check if the charging contacts on the earbuds and inside the case are clean and dry.
- Try a different USB-C cable or power adapter.

6.2. Resetting the Earbuds

If you experience persistent issues, a factory reset may resolve them. Refer to the specific instructions provided in your product's quick start guide, as reset procedures can vary. Typically, this involves placing earbuds in the case and holding a button for a certain duration.

7. SPECIFICATIONS

Feature	Detail
Brand	AMONIDA
Model Number	AMONIDA7xcevo2squ-11
ASIN	B0CH43FH63
Manufacturer	AMONIDA
Country of Origin	China
Connectivity	Bluetooth (version not specified, typically 5.0 or higher)
Water Resistance	IPX5 (Sweat-proof, splash-proof)
Design	Open-ear, Clip-on, Ergonomic
Audio Features	HiFi Stereo Sound, Low Latency
Control Type	Touch Control

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the seller directly. AMONIDA products typically come with a standard manufacturer's warranty covering defects in materials and workmanship.

For technical support, troubleshooting assistance beyond this manual, or inquiries about replacement parts, please contact the seller or visit the official AMONIDA website. Please have your model number (AMONIDA7xcevo2squ-11) and purchase details ready when seeking support.