

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [iWALK](#) /

> [iWALK DBL4500NC Portable Charger Instruction Manual](#)

## iWALK DBL4500NC

# iWALK DBL4500NC Portable Charger Instruction Manual

Model: DBL4500NC

## INTRODUCTION

Thank you for choosing the iWALK DBL4500NC Portable Charger. This compact and efficient power bank is designed to provide fast charging for your USB-C compatible devices, including the latest iPhone models and various Android smartphones. This manual will guide you through the setup, operation, and maintenance of your new portable charger.

## PRODUCT FEATURES

- **20W Fast Charging:** Delivers 20W power output, capable of charging an iPhone 15 Pro from 0% to 50% in approximately 30 minutes.
- **Compact and Lightweight Design:** Designed to be ultra-compact, similar in size to a lipstick, making it easy to carry in a pocket or purse for convenient on-the-go charging.
- **Built-in USB-C Connector:** Features a direct plug-in USB-C port, eliminating the need for extra cables when charging compatible devices.
- **Wide Compatibility:** Compatible with iPhone 15, iPhone 16, iPhone 17 series (including Plus, Pro, Pro Max models), iPad, AirPods, and Android phones such as Samsung Galaxy S22/S23/S24/S25 series, Pixel, OnePlus, and Huawei devices.
- **4,500mAh Capacity:** Provides sufficient power to charge an iPhone 15.
- **Safety Features:** Incorporates a self-developed safe circuit design to minimize heat generation and ensure a secure charging experience.
- **LED Indicator Lights:** Displays the remaining battery level of the power bank.

iWALK®

## Small Wireless Power Bank

Design for iPhone 17/16/15 Series & Android



Image: The iWALK portable charger demonstrating its 20W fast charging, capable of charging an iPhone 16 Pro to 50% in 30 minutes.

## Applicable to various models

**Not Applicable** iPhone 14 /iPhone 13 /iPhone 12 /iPhone 11 /iPhone XS /iPhone XR /iPhone X /iPhone 8.7.6.SE

### iPhone 17/16/15 Series



iPhone 17 Series



iPhone 16 Series



iPhone 15 Series

### SAMSUNG



S24 Ultra

S25+

W26




Z Flip7 FE



Tab S11 Ultra

### MOTOROLA



Edge 25

Razr 25

### GOOGLE



Pixel Series



Type-C / USB-C



Lightning

### iPad Series



Image: The iWALK portable charger shown next to a lipstick, illustrating its compact and lightweight design for easy portability.

## PACKAGE CONTENTS

- 1x iWALK 4,500 mAh Power Bank
- 1x USB-C to USB-C Cable
- 1x User Manual

## SETUP

1. **Initial Charge:** Before first use, fully charge your iWALK Portable Charger using the provided USB-C to USB-C cable. Connect one end of the cable to the power bank's USB-C input port and the other end to a compatible USB-C power adapter (not included).
2. **Check Battery Level:** Press the power button on the side of the power bank to check the current battery level via the LED indicator lights.

## OPERATING INSTRUCTIONS

### Charging the Power Bank

To recharge your iWALK Portable Charger:

1. Locate the USB-C input port on the side of the power bank.
2. Connect the provided USB-C to USB-C cable to this port.
3. Plug the other end of the cable into a USB-C power adapter (e.g., your phone's charger or a wall adapter).
4. The LED indicator lights will illuminate to show the charging progress. Once all lights are solid, the power bank is fully charged.



Image: A close-up view of the iWALK portable charger, highlighting the USB-C input port used for recharging the device.

## Charging Your Device

To charge your smartphone or other compatible device:

1. Remove the protective cap from the built-in USB-C connector on the power bank.
2. Carefully insert the built-in USB-C connector directly into your device's USB-C charging port.
3. The power bank will automatically begin charging your device. The LED indicator lights will show the power bank's

remaining charge.

4. Once your device is charged, or when you wish to stop charging, gently pull the power bank out of your device's port and replace the protective cap.



**20W PD**  
**Let's Fast Charge**

iPhone 16 Pro

0% → 30 Mins → 50%

\*Data is sourced from lab testing, actual results may vary.

Image: The iWALK portable charger directly connected to the charging port of a smartphone, illustrating its cable-free design for device charging.



Image: A woman holding a smartphone with the iWALK portable charger attached, demonstrating how the device can be used comfortably while charging.

### LED Indicator Lights

The LED lights on the power bank indicate its remaining battery capacity:

- **Three Solid Lights:** 67% - 100% charged
- **Two Solid Lights:** 34% - 66% charged
- **One Solid Light:** 1% - 33% charged
- **Flashing Lights:** Indicates the power bank is currently charging.

# Travel Essentials Charging Battery



iPhone 16 Pro  
≈ **91%** Charge

iPhone 15 Pro  
≈ **90%** Charge

Galaxy S23  
≈ **76%** Charge

Image: The iWALK portable charger with three illuminated LED lights, indicating a high battery charge level.

## MAINTENANCE

- Keep the power bank dry and away from moisture.
- Avoid extreme temperatures.
- Clean the device with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the power bank with a partial charge (around 50%) if not used for extended periods to prolong battery life.

## TROUBLESHOOTING

- **Device not charging:**
  - Ensure the power bank is sufficiently charged. Check LED indicators.
  - Verify the USB-C connector is fully and correctly inserted into your device.

- Confirm your device is compatible with a USB-C charging port.
- **Power bank not recharging:**
  - Check if the USB-C to USB-C cable is securely connected to both the power bank and the power adapter.
  - Try a different USB-C power adapter or wall outlet.
- **Slow charging:**
  - Ensure your power adapter supports 20W fast charging for optimal speed when recharging the power bank.
  - For device charging, ensure your device supports 20W fast charging.

## SPECIFICATIONS

<b>Model Number</b>	DBL4500NC
<b>Battery Capacity</b>	4500 Milliamp Hours (mAh)
<b>Output Power</b>	20W Fast Charging
<b>Connector Type</b>	USB Type C (Built-in)
<b>Recharge Input</b>	18W USB-C (via included cable)
<b>Product Dimensions</b>	1 x 1 x 1 inches (Approximate)
<b>Item Weight</b>	6.4 ounces
<b>Special Features</b>	Fast Charging, LED Indicator Lights, Lightweight, Pocket Size, Short Circuit Protection

# 18-Month After-sales service

**1**

Click on "seller ID" on the items details page

**2**

Click on the "Ask a Question" button located on the top right come of the screen.

**3**

Click on the "An Item for sale" button and then you can describe your problem to us.

**4**

We will get back to you within **24 hours** and provide you with a perfect solution.\*\*\*In order for us to better solve the problem for you, please provide us with your "ordernumber" and **more details of the problem.**




Image: A visual guide detailing the broad compatibility of the iWALK portable charger with various USB-C enabled devices, including iPhone 15/16/17 series, Samsung, Motorola, Google Pixel, and iPad models.

## OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official iWALK video showcasing the iPhone 15 Portable Charger, demonstrating its features and ease of use.

## WARRANTY AND SUPPORT

iWALK provides an **18-Month After-sales service** for this product. For any inquiries or support, please follow these steps:

1. Visit the product's page on Amazon.
2. Click on the "iWALK Direct" seller name (usually found near the "Add to Cart" button).
3. On the seller's page, locate and click the "Ask a question" button.
4. Describe your issue and provide your order number for faster assistance.

The iWALK service team aims to respond within 24 hours to provide a solution.