

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PRUNUS](#) /

› [PRUNUS C20 Mini Karaoke Machine User Manual](#)

## PRUNUS C20 Plus

# PRUNUS C20 Mini Karaoke Machine User Manual

Model: C20 Plus

Brand: PRUNUS

## INTRODUCTION

The PRUNUS C20 Mini Karaoke Machine is a portable Bluetooth speaker system designed for an enjoyable singing experience. It features dual wireless microphones and various sound modes, making it ideal for gatherings, family fun, and travel. This manual provides comprehensive instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.



Figure 1: PRUNUS C20 Mini Karaoke Machine with its two wireless microphones.

## WHAT'S IN THE BOX

Please check the package contents upon unboxing:

- Mini Karaoke Machine (Speaker) x 1
- Wireless Microphone x 2
- USB Cable x 1 (for charging)
- User Manual x 1



Figure 2: Illustration of the charging port, TF card slot, and included accessories.

## SETUP INSTRUCTIONS

- Initial Charge:** Before first use, fully charge the karaoke machine speaker and both wireless microphones using the provided USB-C cable. The charging port for the speaker is located on the side, and the microphones also have a charging port. A full charge provides up to 4 hours of playtime.
- Power On:** Press and hold the power button on the karaoke machine speaker and each microphone until the indicator lights illuminate. The speaker and microphones will automatically pair with each other.
- Bluetooth Connection:** To play music from your phone, activate Bluetooth on your device and search for "PRUNUS C20" (or similar model name). Select it to pair. Once connected, music played on your phone will stream through the karaoke machine speaker.
- TF Card Playback:** Alternatively, insert a TF (microSD) card loaded with music into the designated slot on the speaker for direct music playback without needing a Bluetooth connection.

# Powerful Functionalities

Not only a karaoke machine, but also a music player



Figure 3: The karaoke machine supports Bluetooth 5.0, TF card playback, and USB-C charging.

## OPERATING INSTRUCTIONS

### Speaker Controls:

- Power/Play/Pause:** The central button on the speaker controls power on/off (long press) and play/pause (short press) for music playback.


- **Previous/Next Track:** Use the left and right arrow buttons on the speaker to navigate between music tracks.
- **Volume Control:** Rotate the large dial on the speaker to adjust the overall volume.

## **Microphone Controls:**

- **Power/Volume:** The central button on the microphone powers it on/off (long press). Short presses adjust the microphone volume.
- **Sound Effect Switch:** The microphone features unique sound settings including Original, KTV Mode, Female Voice, Male Voice, Children's Voice, and Magical Sound Effects. Press the dedicated button to cycle through these modes.
- **Original Voice/Accompaniment Mode:** Easily switch between singing with the original vocal track or just the instrumental accompaniment.

# Simple Button Operation

Even kids can effortlessly figure it out



## SOUND EFFECT SWITCH

- KTV Mode
- Original Mode
- Male Mode
- Female Mode
- Baby Sound Mode
- Magic Sound Mode



Figure 4: Detailed view of the speaker and microphone controls, highlighting sound effect options.

# 5 Funny Voices + 1 Original




Figure 5: Explore various fun voice effects available on the microphone.

## Audio Quality:

The PRUNUS C20 features a bass diaphragm and digital signal processor for rich, clear-crystal sound with deep bass. It minimizes noise and interference for a high-fidelity audio experience.

**Note: To prevent howling sounds, avoid placing the microphone and speaker too close to each other when the speaker volume is loud.**

# Mini Body, Robust Sound

5W speaker complements a bass diaphragm ,

No distortion at high volume



Figure 6: Internal design of the speaker for robust sound quality.

## PRODUCT VIDEOS

Your browser does not support the video tag.

Video 1: Official product video from Prunus Store showcasing the Mini Karaoke Machine with 2 Wireless Mics.

Your browser does not support the video tag.

## MAINTENANCE

- Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker and microphones. Do not use liquid cleaners or abrasive materials.
- Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- Battery Care:** To prolong battery life, avoid fully discharging the device frequently. Charge it regularly, even if not in use for extended periods.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No power/Device won't turn on	Low battery	Charge the speaker and microphones fully.
No sound from speaker	Volume too low; Not connected via Bluetooth/TF card; Microphones not paired	Increase volume. Ensure proper Bluetooth connection or TF card insertion. Power on and pair microphones.
Microphone not working	Microphone not powered on; Not paired with speaker; Too far from speaker	Ensure microphone is powered on. Re-pair with speaker. Keep microphone within operating range.
Howling/Feedback sound	Microphone too close to speaker; Volume too high	Increase distance between microphone and speaker. Lower speaker volume.
Bluetooth connection unstable	Interference; Device too far from source	Move closer to the connected device. Avoid obstacles. Disconnect and reconnect Bluetooth.

## SPECIFICATIONS

Feature	Detail
Model Number	C20 Plus
Product Dimensions	4.09 x 1.97 x 2.8 inches
Item Weight	12.3 ounces
Color	Beige
Battery	1 A battery required (internal, rechargeable)
Playtime	Up to 4 hours (speaker)
Connectivity	Bluetooth 5.0, TF Card Slot
Special Features	Lightweight, Portable, Mini, Voice Changer, Rechargeable
Recommended Use	Indoor/Outdoor

# Mini KTV in Your Hand



Figure 7: Product dimensions for the speaker and microphone.

## WARRANTY AND SUPPORT

PRUNUS products are manufactured with high-quality standards. For any product-related inquiries, technical support, or warranty claims, please refer to the contact information provided on the product packaging or visit the official PRUNUS website. Please retain your proof of purchase for warranty purposes.

© 2023 PRUNUS. All rights reserved.