Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TECNR WF286773AAK

TECNR WF286773AAK Twin Size House Bed Frame Instruction Manual

Model: WF286773AAK | Brand: TECNR

Introduction Safety Information Parts List Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This instruction manual provides detailed guidance for the assembly, safe operation, and maintenance of your TECNR WF286773AAK Twin Size House Bed Frame. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and care will ensure the longevity and safety of the product.



Image 1.1: Assembled TECNR Twin Size House Bed Frame in a child's room, showing its design and potential use with bedding and decorations.

2. Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Keep all assembly hardware out of reach of children.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not allow children to jump on the bed frame.
- Do not use this bed frame if any parts are missing, damaged, or broken. Contact TECNR for replacement parts.
- Maximum weight capacity for this bed frame is 350 lbs. Do not exceed this limit.
- Use only a mattress of the recommended size (Twin size, 75"L x 39"W). Recommended mattress height is 4"-6".
- Assembly should be performed by at least two adults.

3. Parts List

Before beginning assembly, ensure all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

3.1. Frame Components

- A-Frame Side Panels (Left & Right)
- Top Crossbar
- Bottom Side Rails (2)
- Bottom End Rails (2)

3.2. Slat System

- Metal Slats (Quantity: 20)

3.3. Hardware & Tools

- Bolts (various sizes)
- Washers
- Nuts
- Allen Wrench (provided)
- Screwdriver (not always provided, may be required)



Image 3.1: Individual components of the TECNR Twin Size House Bed Frame, showing the metal frame pieces and slats before assembly.

4. Setup (Assembly Instructions)

Follow these steps carefully to assemble your bed frame. It is recommended to assemble the bed in the room where it will be used.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratching. Verify all parts listed in Section 3 are present.
2. **Assemble A-Frame Sides:** Connect the top crossbar to the two A-frame side panels using the provided bolts, washers, and nuts. Do not fully tighten bolts until all frame components are loosely assembled.
3. **Attach Bottom Rails:** Connect the bottom side rails and end rails to the A-frame side panels. Ensure the frame is square and stable.
4. **Install Slats:** Place the metal slats across the bottom side rails. Secure each slat to the frame using the designated

hardware. Ensure slats are evenly spaced and firmly attached.

5. **Final Tightening:** Once all frame components and slats are in place, systematically tighten all bolts and screws using the Allen wrench. Do not overtighten.
6. **Position Mattress:** Carefully place your Twin size mattress onto the assembled slat system.




Image 4.1: Front view of the assembled TECNR Twin Size House Bed Frame, illustrating the completed structure before mattress placement.





Image 4.2: Side view of the assembled TECNR Twin Size House Bed Frame, showing the A-frame design and slat support system.

5. Operating Instructions

The TECNR WF286773AAK House Bed Frame is designed to support a standard Twin size mattress. Once assembled, the bed is ready for use.

- Ensure the mattress is properly centered on the slat system.
- Avoid placing excessive weight on any single point of the bed frame.
- The open design allows for creative decoration with blankets, pillows, or lights, but ensure any additions do not

compromise the structural integrity or safety of the bed.

6. Maintenance

Regular maintenance will help prolong the life of your bed frame.

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) check all bolts and screws to ensure they remain tight. Re-tighten if necessary to prevent wobbling or noise.
- **Inspection:** Inspect the frame for any signs of wear, damage, or bending. If any issues are found, discontinue use and contact customer support.

7. Troubleshooting

If you encounter issues with your bed frame, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable.	Loose hardware.	Check and tighten all bolts and screws. Ensure all connections are secure.
Squeaking noises.	Loose connections or friction between metal parts.	Tighten all hardware. If squeaking persists, disassemble and reassemble the affected section, ensuring all parts are correctly aligned.
Parts do not align during assembly.	Incorrect orientation of parts or overtightened bolts.	Loosen all bolts slightly. Re-check part orientation against the assembly diagram. Ensure parts are not forced.

8. Specifications

Detailed specifications for the TECNR WF286773AAK Twin Size House Bed Frame:

Model Number: WF286773AAK

Brand: TECNR

Product Dimensions (L x W x H): 75" x 47.95" x 67.11"

Size: Twin

Color: White

Material: Metal

Included Components: Slat

Maximum Weight Capacity: 350 lbs

Recommended Mattress Height: 4"-6"

Height from Ground: 6.65"

UPC: 786194242128

ASIN: B0CH87XTZX




Image 8.1: Detailed dimensions diagram for the TECNR Twin Size House Bed Frame, showing length, width, and height measurements.

9. Warranty & Support

For specific warranty information regarding your TECNR WF286773AAK Twin Size House Bed Frame, please refer to the documentation included with your purchase or contact TECNR customer support directly. If you require assistance with assembly, missing parts, or have any questions, please reach out to the manufacturer's customer service department.
Manufacturer: Nantong Yepusi Textile Technology Co., Ltd

© 2023 TECNR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CH87XTZX

More documents and user manuals: **https://manuals.plus/**