

[Manuals.plus](#) /

› [InnovaGoods](#) /

› InnovaGoods Portable Safe Box with 3-Digit Combination and Security Cable Manual

InnovaGoods 8435527825751

InnovaGoods Portable Safe Box with 3-Digit Combination and Security Cable

Model: 8435527825751

INTRODUCTION

Thank you for choosing the InnovaGoods Portable Safe Box. This manual provides essential information for the safe and effective use of your new portable safe. Designed for securing valuables such as jewelry, bank cards, cash, documents, and passports, this safe features a durable iron construction, a customizable 3-digit combination lock, a padded interior, and an integrated steel security cable for added protection. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

- Keep the safe out of reach of children.
- Do not store the combination inside the safe.
- Ensure the safe is closed and locked properly after each use.
- This safe is not water-resistant. Avoid exposure to water or high humidity.
- The security cable is designed as a deterrent; it does not guarantee absolute theft prevention.

SETUP

1. Unpacking

Carefully remove the safe and all accessories from the packaging. Verify that all components are present: the portable safe, security cable, and optional mounting dowels and screws.

2. Setting the Combination

Your safe comes with a default combination, typically 0-0-0. To set your personal combination:

1. Ensure the safe is open and the current combination is set to 0-0-0 (or the last known combination).
2. Locate the reset button or lever inside the safe, usually near the combination dials.
3. While the safe is open, use a pointed object (like a pen) to press and hold the reset button, or move the reset lever

to the 'SET' position.

4. With the button/lever held, set your desired 3-digit combination by rotating the dials. Choose a memorable but secure combination.
5. Release the reset button or return the lever to its original position. Your new combination is now set.
6. Test the new combination with the safe open before closing it.



Image: Setting the 3-digit combination on the safe.

3. Attaching the Security Cable

The included steel security cable allows you to anchor the safe to a fixed object, providing an additional layer of security.

1. Locate the cable attachment point on the safe (usually a slot or loop).
2. Thread the loop end of the steel cable through the attachment point on the safe.
3. Pass the other end of the cable (with the larger loop) through the smaller loop you just threaded.
4. Secure the larger loop around a sturdy, immovable object such as a desk leg, shelf, or bed frame. Ensure the object

is robust enough to prevent easy removal.



Image: Portable safe secured to a desk using the security cable.

4. Optional Wall Mounting

For permanent installation, the safe can be mounted to a wall using the provided dowels and screws. This option is suitable for home or office use where a fixed location is preferred.

1. Choose a suitable wall location, ensuring it is a solid surface capable of supporting the safe's weight and resisting force.
2. Mark the drilling points on the wall using the safe's pre-drilled holes as a template.
3. Drill holes at the marked points. Insert the wall dowels into the drilled holes.
4. Align the safe with the dowels and secure it to the wall using the provided screws. Ensure the screws are tightened firmly.

OPERATING INSTRUCTIONS

1. Opening the Safe

1. Rotate the combination dials to your personal 3-digit code.
2. Turn the knob or press the release button (if present) to unlock the lid.
3. Lift the lid to open the safe.



Image: Open portable safe with items inside and security cable.

2. Closing and Locking the Safe

1. Place your valuables inside the padded interior.
2. Close the lid firmly.
3. Scramble the combination dials to a random set of numbers to lock the safe.
4. Gently try to open the lid to ensure it is securely locked.



Image: Portable safe stored inside a suitcase.

3. Changing the Combination

To change your combination after the initial setup, follow the same steps as in the "Setting the Combination" section under Setup. Always ensure the safe is open when changing the combination and test the new code before closing.

MAINTENANCE

- **Cleaning:** Wipe the exterior of the safe with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Interior:** The polyurethane foam interior can be gently wiped if necessary. Ensure it is completely dry before closing the safe.
- **Mechanism:** The combination mechanism is designed for maintenance-free operation. Do not attempt to lubricate or disassemble it.
- **Storage:** When not in use, store the safe in a dry place away from extreme temperatures.

TROUBLESHOOTING

Safe Will Not Open

- **Incorrect Combination:** Ensure you are entering the correct 3-digit combination. Double-check each number.
- **Dials Not Aligned:** Make sure each dial is precisely aligned with the indicator mark.
- **Knob/Button Issue:** Ensure the knob is turned fully or the button is pressed completely after entering the combination.
- **Forgotten Combination:** If you have forgotten your combination, there is no master key or override. You may need to contact InnovaGoods customer support for assistance, though recovery of a forgotten combination for a mechanical lock is generally not possible without destructive methods.

Safe Will Not Close/Lock

- **Obstruction:** Check if any items inside the safe are preventing the lid from closing completely.
- **Lid Alignment:** Ensure the lid is properly aligned with the base before attempting to close it.
- **Dials Scrambled:** After closing, ensure the combination dials are scrambled to lock the safe.

SPECIFICATIONS

Brand	InnovaGoods
Model Number	8435527825751
Material	Iron
Color	Black
Closure Type	Mechanical Combination Lock (3-digit)
Special Feature	Portable, Padded Interior, Security Cable
Mounting Type	Portable / Optional Wall Mount
Item Weight	1.38 Kilograms
Chamber Height	16.5 Centimeters
Chamber Depth	16.5 Centimeters
Water Resistance Level	Not water resistant

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or visit the official InnovaGoods website. Keep your proof of purchase for any warranty claims.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question