MYNTA MYNT-MC4100G

MYNTA 4D Massage Chair User Manual

Model: MYNT-MC4100G

1. Introduction

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your MYNTA 4D Massage Chair. Please read this manual thoroughly before using the product and retain it for future reference.



Image 1: The MYNTA 4D Massage Chair in Grey, showcasing its design and features.

2. Safety Information

To ensure safe operation, observe the following guidelines:

- Ensure user weight does not exceed 205 pounds (93 kg).
- Use the chair only on hard, stable floors.
- This product is electric and must be properly grounded. Do not operate with wet hands or in damp environments.
- Keep children and pets away from the chair during operation.
- Do not insert any objects into the chair's openings.
- If you experience discomfort, discontinue use immediately.

3. Product Features

3.1. Dual Mechanism (4D+2D Massage)

The chair features an advanced dual massage mechanism. The 4D mechanism targets the back, offering varied massage modes and intensities. The 2D mechanism focuses on the glutes and thighs, providing a comprehensive massage experience.



Image 2: Illustration detailing the 4D Dual Roller Mechanism for the back and the 2D Seat Shiatsu Mechanism for the glutes and thighs.

Your browser does not support the video tag.

Video 1: Demonstrates the dual mechanism of the MYNTA massage chair, showing how the 4D and 2D rollers operate to provide a full-body massage.

3.2. Extended SL-Track

The 52-inch SL track is designed to conform to the natural curve of the body, providing massage from the neck

down to the thighs. This design ensures a broad massage range and includes a Thai stretching function to help relax muscles.



Image 3: Visual representation of the 51.6-inch SL-Track, illustrating its path along the spine from neck to hip.

3.3. Full Body Airbag Massage & Heat Therapy

The chair incorporates 36 airbags strategically placed in the shoulders, arms, calves, and feet to relieve muscle tension. Back and shawl heat therapy functions are included to promote blood circulation and enhance relaxation.



Image 4: Overview of the full body massage features, including shoulder, hand, calf, and foot airbags, along with lumbar and shawl heating.

3.4. Music Sync with Hi-Fi Bluetooth Speakers

The chair features a music rhythm mode that adjusts massage intensity and speed in synchronization with music played through its Hi-Fi Bluetooth speakers. This creates an immersive sensory experience.



Image 5: A person relaxing in the massage chair, illustrating the innovative rhythmic massage feature where intensity changes with music.

3.5. Zero Gravity Reclining

The zero gravity feature reclines the chair to a position that minimizes pressure on the spine, promoting deeper relaxation. It offers multiple stages of recline for personalized comfort.



Image 6: Visual explanation of the 3-stage Zero Gravity function, showing initial, comfort, and deep recline positions.

4. Setup

The MYNTA 4D Massage Chair is designed for minimal assembly. Ensure you have adequate space for the chair, considering its dimensions and the required wall distance for reclining.

4.1. Unpacking and Placement

The chair is delivered largely pre-assembled. Carefully remove all packaging materials. Place the chair on a hard, level floor. A minimum doorway size of 30.7 inches is required for transport. The chair requires only 4 inches of space behind it for full recline.



Image 7: Dimensions of the fully assembled chair and the minimum doorway size required for placement.

4.2. Power Connection

Connect the power cord to a properly grounded electrical outlet. Ensure the power switch on the chair is in the 'off' position before plugging it in.

5. Operating Instructions

The chair can be operated using the integrated shortcut keys or the touch screen remote control.

5.1. Initial Body Scan

Upon first use or when a new user sits in the chair, an automatic body scan will initiate. This scan detects your body shape and position to customize the massage for optimal comfort and effectiveness.

5.2. Control Panel and Remote

The chair features a user-friendly control panel with shortcut keys for quick adjustments and a touch screen remote for detailed program selection and customization.



Image 8: Detailed view of the shortcut keys on the armrest and the touch screen remote control for operating the massage chair.

5.3. Auto Programs

Select from a variety of pre-programmed massage modes, such as Rejuvenate, Shiatsu, Swedish, Deep Tissue, Gentle Touch, Sports, Relax, Neck & Shoulders, Waist & Hip, Thai, and Sleep. These programs are designed to address different needs and preferences.

Your browser does not support the video tag.

Video 2: Overview of the MYNTA 4D+2D Massage Chair, demonstrating various features and auto programs available for a full body massage.

5.4. Customization

In manual mode, you can customize massage speed, spots, strength, width, and time to create a personalized massage experience. The touch screen remote allows for easy adjustment of these settings.

5.5. Music Sync Mode

Connect your smartphone via Bluetooth to the chair's Hi-Fi speakers. Activate the 'Sync Music' mode on the remote, and the massage intensity will dynamically adjust to the rhythm of your music.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your massage chair.

- **Cleaning:** Wipe the faux leather surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Foot Pads:** The foot pads are removable for cleaning or replacement.
- **Storage:** When not in use for extended periods, unplug the chair and cover it to protect from dust.

7. Troubleshooting

If you encounter any issues with your MYNTA 4D Massage Chair, refer to the following common solutions:

- **Chair not powering on:** Ensure the power cord is securely plugged into a grounded outlet and the power switch is on. Check the circuit breaker.
- **Massage rollers not moving:** Verify that an auto program or manual massage mode is selected. Ensure no obstructions are present.
- **Airbags not inflating:** Check if the airbag massage function is activated in your selected program or manual settings.
- **No heat:** Confirm the heat therapy function is turned on via the remote or shortcut keys.
- **Bluetooth connectivity issues:** Ensure your device's Bluetooth is enabled and within range. Try restarting both the chair and your device.

For persistent issues, please contact customer service.

8. Specifications

Feature	Detail
Brand	MYNTA
Model Number	MYNT-MC4100G
Color	Grey

Feature	Detail
Material	Faux Leather, Foam
Product Dimensions (D x W x H)	62.6"D x 30"W x 45"H
Item Weight	205 Pounds
Maximum Weight Recommendation	205 Pounds
Track Type	SL Track (52 inches)
Control Mode	Shortcut Keys And Touch Screen
Heating Function	Shawl And Waist Heating
Body Scanning Function	Yes
Zero Gravity	Yes
Bluetooth	Yes
Dual Movement	Yes




Image 9: A visual summary of the MYNTA 4D Massage Chair's key specifications.

9. Warranty and Support

MYNTA provides a 3-year limited coverage for this product. For any questions or support needs, please contact customer service through Amazon. Our team is available 7 days a week, 24 hours a day, to assist you.

© 2026 MYNTA. All rights reserved.