**ChooChoo SB2302**

# ChooChoo Farmhouse Console Table (Model SB2302)

Instruction Manual

## 1. Introduction

This manual provides detailed instructions for the assembly, setup, operation, and maintenance of your ChooChoo Farmhouse Console Table, Model SB2302. Please read this manual thoroughly before beginning assembly or use to ensure proper function and safety.



Image 1.1: The ChooChoo Farmhouse Console Table, Model SB2302, featuring a white body, dark brown top, and X-shaped side accents.

## 2. Safety Information

**WARNING:**

- This product requires assembly. Use appropriate tools and follow the instructions carefully to avoid injury.
- Do not exceed the weight limit of the product (50 pounds).
- Be aware of potential pinch points and other hazards during assembly, use, and maintenance.
- Ensure all fasteners are securely tightened before use. Periodically check and re-tighten fasteners as needed.
- Keep small parts and packaging materials away from children.

## 3. Package Contents

Before assembly, verify that all components listed in the included Assembly Guide are present and undamaged. If any

parts are missing or damaged, please contact customer service.

- Table Panels (Top, Side, Bottom, Shelf, Drawer, Door)
- Hardware Pack (Screws, dowels, cam locks, handles, hinges, drawer slides)
- Assembly Guide

## 4. Assembly Instructions

Assembly of the ChooChoo Farmhouse Console Table is designed to be straightforward. All parts and accessories are numbered to correspond with the detailed instructions provided in the separate Assembly Guide. It is recommended that two people assemble this unit.

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part by its corresponding number in the Assembly Guide.
2. **Follow the Guide:** Refer to the step-by-step illustrations and instructions in the Assembly Guide. Pay close attention to the orientation of each panel.
3. **Assemble Frame:** Begin by assembling the main frame, including the side panels with the X-shaped decorative elements.
4. **Install Drawer and Cabinet:** Install the drawer slides, assemble the drawer, and attach the cabinet doors using the provided hinges. Ensure the elegant black handles are securely fastened.
5. **Attach Shelves:** Secure the bottom slatted shelf and any internal shelves as indicated.
6. **Final Check:** Once assembled, ensure all screws and fasteners are tightened. Do not overtighten.



Image 4.1: Key features of the console table, including the X-shaped side decor, the spacious storage drawer, and the black handles on the cabinet doors.

## 5. Setup

Once assembled, place the console table in your desired location, such as an entryway, hallway, living room, or kitchen. Consider the following:

- **Level Surface:** Ensure the table is placed on a flat, level surface to prevent wobbling and ensure stability.
- **Environment:** Avoid placing the table in direct sunlight or near heat sources to prevent material damage or discoloration. Keep away from areas with high humidity.
- **Wall Anchoring (Optional):** For added stability and safety, especially in homes with children or pets, consider anchoring the table to a wall using appropriate hardware (not included).



Image 5.1: The console table configured as a coffee bar cabinet in a kitchen, demonstrating its versatile placement options.

## 6. Operating

The ChooChoo Farmhouse Console Table features a large drawer, a two-door cabinet, and a decorative slatted bottom

shelf for storage and display.

- **Drawer:** To open the drawer, gently pull the knob. To close, push until it is fully seated. Avoid overloading the drawer to ensure smooth operation.
- **Cabinet Doors:** The two cabinet doors open outwards. Use the handles to open and close them. Magnets are typically integrated to keep the doors securely closed.
- **Shelves:** The interior cabinet shelf and the bottom slatted shelf can be used for storing various items or displaying decorative objects. Distribute weight evenly.



Image 6.1: The console table with its drawer open, illustrating the available storage space for small items.

## 7. Maintenance

Proper care will help maintain the appearance and longevity of your console table.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.

- **Spills:** Clean spills immediately with a dry cloth to prevent staining or water damage.
- **Fasteners:** Periodically check all screws and connections to ensure they remain tight. Re-tighten as necessary.
- **Weight Distribution:** Avoid placing excessively heavy items on the table or concentrating weight in one area.

## 8. Troubleshooting

- **Wobbling Table:**
  *Solution:* Ensure the table is on a level surface. Check and tighten all assembly screws. If the floor is uneven, use furniture pads or shims under the legs.
- **Drawer or Door Misalignment:**
  *Solution:* Review the assembly steps for the drawer slides and door hinges in the Assembly Guide. Adjust hinges if necessary to align doors. Ensure the drawer is correctly seated on its slides.
- **Strong Odor:**
  *Solution:* New furniture may have a slight odor from manufacturing. Ensure the room is well-ventilated. The odor should dissipate over time.
- **Damaged or Missing Parts:**
  *Solution:* Do not proceed with assembly. Contact ChooChoo customer service immediately for assistance.

## 9. Specifications





Image 9.1: Detailed dimensions of the console table, including height, width, and depth measurements.

| Feature | Detail |
|---|---|
| Brand | ChooChoo |
| Model Number | SB2302 |
| Product Dimensions (D x W x H) | 13.8"D x 33.5"W x 35.8"H |
| Color | White |
| Maximum Weight Recommendation | 50 Pounds |
| Frame Material Type | Engineered Wood |
| Top Material Type | Engineered Wood |
| Number of Drawers | 1 |

| Feature | Detail |
| --- | --- |
| Number of Doors | 2 |
| Number of Shelves | 1 (bottom slatted shelf) |
| Recommended People for Assembly | 2 |
| Indoor/Outdoor Usage | Indoor |

## 10. Customer Service & Support

If you have any questions about the product, assembly, or require assistance with after-sales issues, please do not hesitate to contact ChooChoo customer service. We are committed to providing timely support.
Please refer to your purchase documentation or the ChooChoo brand store for specific contact information.

© 2025 ChooChoo. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question