

Holstein Housewares H-0911501

Holstein Housewares Personal Coffee Maker

MODEL: H-0911501

Your guide to effortless coffee brewing.

1. Important Safety Information

Please read all instructions carefully before using your Holstein Housewares Personal Coffee Maker. Retain this manual for future reference.

- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycle.
- This appliance has boil-dry protection and automatic shut-off after brewing for enhanced safety.

2. Product Overview

The Holstein Housewares Personal Coffee Maker is designed for convenience and efficiency, allowing you to enjoy a fresh cup of coffee quickly.



Figure 1: Front view of the Holstein Housewares Personal Coffee Maker, showcasing its compact design and included travel mug.

Key Features:

- **Compact Design:** Space-saving for small kitchens, offices, or dorms.
- **One-Touch Operation:** Simple and intuitive brewing process.
- **Reusable Filter:** Eliminates the need for paper filters, reducing waste.
- **14oz Travel Mug:** Stainless steel and silicone mug for on-the-go convenience.
- **Auto Shut-Off:** Automatically turns off after brewing for safety.

Video 1: A product summary video demonstrating the key features and compact nature of the Holstein Housewares Personal Coffee Maker.

3. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the reusable filter, funnel, and travel mug in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the coffee maker with a damp cloth.
3. **Initial Rinse:** Fill the water reservoir with clean water up to the MAX line. Place the empty travel mug on the drip tray. Run a brewing cycle without coffee to clean the internal components. Discard the water.
4. **Placement:** Place the coffee maker on a stable, flat, heat-resistant surface near an electrical outlet.



Figure 2: Side view of the coffee maker, illustrating its slim profile suitable for various spaces.

4. Operating Instructions


Follow these steps to brew your perfect cup of coffee:

1. **Fill Water Reservoir:** Open the lid of the coffee maker. Fill the included 14oz travel mug with fresh, cold water to your desired level (up to 14oz). Pour the water into the water reservoir located at the back of the coffee maker. Do not exceed the MAX fill line.

2. **Add Coffee Grounds:** Place the reusable filter into the funnel. Add your preferred amount of ground coffee into the reusable filter. For a standard 14oz cup, 2-3 tablespoons of ground coffee are typically recommended. Close the lid securely.
3. **Position Mug:** Place the empty 14oz travel mug (or another mug of appropriate size) onto the drip tray, ensuring it is centered under the coffee dispenser.
4. **Start Brewing:** Plug the coffee maker into a standard electrical outlet. Press the ON/OFF button located on the side of the appliance. A blue indicator light will illuminate, signifying that the brewing process has started.
5. **Enjoy:** Once the brewing cycle is complete, the coffee maker will automatically shut off, and the blue indicator light will turn off. Carefully remove your travel mug and enjoy your freshly brewed coffee.



Figure 3: Demonstrates adding ground coffee to the reusable filter basket.



Compact and space-saving

Fits seamlessly into your kitchen space



Figure 4: Illustrates the simple one-touch operation to start the brewing process.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your coffee maker.

1. **Unplug and Cool:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Clean Removable Parts:** The reusable filter and funnel are dishwasher-safe (top rack recommended) or can be washed by hand in warm, soapy water. Rinse thoroughly.
3. **Clean Travel Mug:** The 14oz stainless steel travel mug should be hand-washed with warm, soapy water. The lid is also dishwasher-safe.
4. **Clean Exterior:** Wipe the exterior of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
5. **Descaling:** Over time, mineral deposits can build up in the coffee maker. To descale, fill the water reservoir with a mixture of 1 part white vinegar and 2 parts water. Run a brewing cycle. Repeat with clean water to rinse. Descale every 2-4 weeks depending on water hardness.



Brewing made simple

Unbox, set up & enjoy



Figure 5: The included 14oz stainless steel travel mug, designed for convenience and easy cleaning.

6. Troubleshooting

Problem	Possible Cause	Solution
Coffee maker does not turn on.	Not plugged in; power button not pressed.	Ensure the appliance is securely plugged into a working outlet. Press the ON/OFF button firmly.
Coffee does not brew.	No water in reservoir; reservoir lid not closed properly.	Fill the water reservoir with water. Ensure the lid is securely closed.
Coffee tastes weak.	Insufficient coffee grounds; too much water.	Increase the amount of coffee grounds. Ensure water level matches desired strength.

Problem	Possible Cause	Solution
Coffee overflows.	Too much water in reservoir; mug not positioned correctly.	Do not exceed the MAX fill line in the reservoir. Ensure mug is centered on the drip tray.

7. Specifications

- **Model Number:** H-0911501
- **Product Dimensions:** 26.3"D x 14.3"W x 19.1"H (approx. 10.35"H x 5.63"W x 7.52"D)
- **Weight:** 2.12 Pounds
- **Color:** White/Gold
- **Coffee Maker Type:** Drip Coffee Machine
- **Special Feature:** Permanent Filter, Auto Shut-Off, Boil-Dry Protection
- **Included:** 14oz Stainless Steel Travel Mug, Reusable Filter

Video 2: A short video showcasing the elegant design of the Holstein Housewares Personal Coffee Maker in White & Gold.

8. Warranty and Support

For product support, warranty information, or to explore other Holstein Housewares products, please visit the official Holstein Housewares Store:

[Visit Holstein Housewares Store](#)

You can also find more information and recipes by scanning the QR code on the product packaging or visiting <https://qr1.be/46YD>.