Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GRIFEMA GAK1201-9

GAK1201-9 5-Digit Combination Bike Chain Lock

User Manual

Introduction

The GRIFEMA GAK1201-9 5-Digit Combination Bike Chain Lock provides a secure and convenient solution for protecting your bicycle, scooter, or other valuable items from theft. Its robust design and resettable combination offer enhanced security without the need for keys.

Product Overview

Key Features

- **High Security & Resettable:** 5-digit resettable combination offers 100,000 possible combinations, significantly safer than 4-digit locks. No key required, just remember your code.
- **Sturdy & Durable:** Constructed from zinc alloy, making it drill-resistant and anti-tech unlocking.
- **Nylon Cover Protection:** Features a nylon cloth cover that is scratch-proof, wear-resistant, anti-hot, and anti-icing. This protects the chain and prevents scratching your bicycle frame, ensuring a long lifespan.
- **Multi-Purpose:** With a length of 900mm (35.43 inches) and a chain diameter of 7mm, this lock can secure various items including motorcycles, E-bikes, skateboards, grills, scooters, doors, and lawnmowers.

Product Dimensions and Weight

The GAK1201-9 lock measures approximately 35.43 x 1.57 x 1.57 inches (L x W x H) and weighs 730 grams (1.61 pounds). The chain itself has a diameter of 7mm.



Figure 1: Product dimensions and weight overview.

Components

The lock features an ABS lock shell with a humanized arc design, a strong and sturdy zinc alloy lock cylinder, a durable nylon chain cover, and an anti-theft zinc alloy lock head.



Figure 2: Key components of the GAK1201-9 lock.

Security and Durability

The lock's 5-digit combination provides a high level of security with a 1 in 100,000 unlocking rate. The high-quality steel chain is environmentally-friendly and protected by a durable cloth cover to prevent abrasion and damage to your belongings.



Figure 3: Professional 5-digit combination for enhanced security.

Figure 4: High-quality steel chain for maximum protection.

Setup: Setting Your Combination

Your GAK1201-9 lock comes with a default combination of**00000**. To set your personal combination, follow these steps:

1. Open the lock using the default combination "00000".
2. Locate the rotary knob on the lock mechanism. Rotate this knob forward 90° according to the indicated direction.
3. Set your new desired 5-digit combination by aligning each key with the markings. Choose a memorable but secure code.
4. Rotate the knob backward 90° to its default position. Your new combination is now set.

Important: It is highly recommended to take a picture of your set password or write it down in a secure place to prevent forgetting it. Once the combination is changed, the default code will no longer work.



Figure 5: Visual guide for setting your custom combination.

Operating Your Lock

To lock your item, ensure the chain passes through both the item (e.g., bicycle frame and wheel) and a strong, immovable object. Align the combination to your set code, insert the lock head into the mechanism, and then scramble the numbers to secure it. To unlock, simply dial your personal combination and pull the lock head out.

Multi-Purpose Use

The flexibility and length of the GAK1201-9 chain lock allow it to be used in various scenarios beyond just bicycles. It can effectively secure a wide range of items.



Figure 6: Examples of multi-purpose applications for the lock.

Maintenance

To ensure the longevity and smooth operation of your GRIFEMA GAK1201-9 lock, consider the following maintenance tips:

- **Cleaning:** Periodically wipe down the lock and its nylon cover with a damp cloth to remove dirt and debris. Avoid harsh chemicals that could damage the materials.
- **Lubrication:** If the combination wheels or locking mechanism feel stiff, apply a small amount of silicone-based lubricant to ensure smooth operation.
- **Storage:** While the lock is weather-resistant, storing it in a dry place when not in use can further extend its lifespan, especially in harsh weather conditions.

Troubleshooting

- **Lock not opening after setting new code:** Ensure all five digits of your new combination are perfectly aligned with

the marking line. If you have forgotten your new code, unfortunately, there is no master key or reset button to revert to the default. It is crucial to remember or securely record your combination.

- **Combination wheels are stiff:** This can occur due to dirt accumulation or lack of lubrication. Clean the wheels and apply a silicone-based lubricant as described in the Maintenance section.
- **Lock mechanism is jammed:** Check for any foreign objects obstructing the mechanism. Ensure the lock head is inserted straight and fully before attempting to lock or unlock.

Specifications

Feature	Detail
Brand	GRIFEMA
Model Name	GAK1201-9
Lock Type	Combination Lock
Combination	5-Digit Resettable
Material	Alloy Steel, Nylon, Zinc
Item Dimensions (L x W x H)	35.43 x 1.57 x 1.57 inches
Item Weight	730 Grams (1.61 pounds)
Chain Diameter	7mm
Special Features	Cut Resistant, Passcode Unlock, Scratch-Resistant, Weather Resistant
Color	Black, White
Included Components	1 x anti-theft chain lock

Warranty and Support

For warranty information or technical support regarding your GRIFEMA GAK1201-9 lock, please refer to the product packaging or contact GRIFEMA customer service directly. Contact details can typically be found on the manufacturer's official website or through your point of purchase.

© 2023 GRIFEMA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CHB77Y6P

More documents and user manuals: **https://manuals.plus/**