**VELECO SHARPY**

# VELECO SHARPY Mobility Scooter User Manual

Model: SHARPY (SHA)

## 1. Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and care of your VELECO SHARPY mobility scooter. Please read this manual thoroughly before operating the device and retain it for future reference. Proper understanding and adherence to these instructions will ensure optimal performance and longevity of your scooter.




*Figure 1: The VELECO SHARPY mobility scooter in black.*

## 2. Safety Guidelines

Your safety is paramount. Always observe the following safety precautions:

- Always wear a seatbelt when operating the scooter.
- Ensure the magnetic brake system is functioning correctly before each use.
- Avoid sudden stops or turns, especially on uneven terrain.
- Do not exceed the maximum weight recommendation of 160 kg (352.7 lbs).
- Always engage the drive system before an occupant is left unattended or attempts to operate the mobility scooter.
- The mobility scooter is designed for single-person use only. Do not carry passengers.

- Exercise caution when navigating different terrains and avoid obstacles.
- Regularly check tires, brakes, and battery for optimal safety.



(EN) A mobility scooter is not designed to carry passengers in other vehicles. (BG) Скутерът за инвалидни колички не е предназначен за превоз на пътници в други превозни средства. (HR) Skuter za mobilnost nije namijenjen za prijevoz ljudi u drugim vozilima. (CZ) Mobilní skútr není určen k přepravě osob v jiných vozidlech. (DK) Mobilitetsscooteren er ikke beregnet til at transportere personer i andre køretøjer. (EST) Mobiilne roller ei ole ette nähtud inimeste transportimiseks teistes sõidukites. (FI) Skootteria ei ole tarkoitettu ihmisten kuljettamiseen muissa ajoneuvoissa. (FR) Le scooter de mobilité n'est pas destiné à transporter des personnes dans d'autres véhicules. (GR) Το σκούτερ κινητικότητας δεν προορίζεται για τη μεταφορά ατόμων σε άλλα οχήματα. (ES) El scooter de movilidad no está diseñado para transportar personas en otros vehículos. (IRL) Níl an scútar soghluaisteachta beartaithe chun daoine a iompar i bhfeithiclí eile. (LT) Mobilus paspirtukas nėra skirtas žmonėms vežti kitose transporto priemonėse. (LV) Mobilais skrejritenis nav paredzēts cilvēku pārvadāšanai citos transportlīdzekļos. (MT) L-iskuter tal-mobilità mhuwiex maħsub biex jittrasporta nies f'vetturi oħra. (NL) De scootmobiel is niet bedoeld om mensen in andere voertuigen te vervoeren. (DE) Der Elektromobil ist nicht dazu bestimmt, Personen in anderen Fahrzeugen zu transportieren. (PL) Skuter inwalidzki nie jest przeznaczony do przewozu osób w innych pojazdach. (PT) A scooter de mobilidade não se destina a transportar pessoas em outros veículos. (RO) Scuterul de mobilitate nu este destinat transportului de persoane în alte vehicule. (SK) Mobilný skúter nie je určený na prepravu osôb v iných vozidlách. (SLO) Skuter za mobilnost ni namenjen prevozu ljudi v drugih vozilih. (SE) Skotern är inte avsedd att transportera människor i andra fordon. (HU) A mobilrobogó nem alkalmas személyek más járművekben történő szállítására. (IT) Lo scooter elettrico non è destinato al trasporto di persone in altri veicoli.

*Figure 2: Important safety notice: This mobility scooter is not designed to carry passengers.*

(EN) Drive system should be re-engaged before an occupant is left unattended or attempts to operate the mobility scooter. (BG) Системата за задвижване трябва да се включи отново, преди пътник да остане без надзор или да се опита да управлява скутера за мобилност. (HR) Pogonski sustav treba ponovno uključiti prije nego što putnik ostane bez nadzora ili pokuša upravljati pokretnim skuterom. (CZ) Pohonný systém by měl být znovu zapojen dříve, než cestující zůstane bez dozoru nebo se pokusí řídit skútr. (DK) Drivsystemet skal genindkobles, før en passager efterlades uden opsyn eller forsøger at betjene scooteren. (EST) Ajamisüsteem tuleb uuesti sisse lülitada enne, kui sõitja jäetakse järelevalveta või ta proovib rollerit juhtida. (FI) Ajojärjestelmä tulee kytkeä uudelleen päälle, ennen kuin matkustaja jätetään ilman valvontaa tai hän yrittää käyttää mopedia. (FR) Le système d'entraînement doit être réengagé avant qu'un occupant soit laissé sans surveillance ou tente d'utiliser le scooter de mobilité. (GR) Το σύστημα μετάδοσης κίνησης θα πρέπει να ενεργοποιηθεί ξανά πριν αφεθεί ένας επιβάτης χωρίς επίβλεψη ή επιχειρήσει να χειριστεί το σκούτερ κινητικότητας. (ES) El sistema de conducción debe volver a activarse antes de que un ocupante quede desatendido o intente operar el scooter de movilidad. (IRL) Ba cheart an córas tiomána a athfhostú sula bhfágtar áititheoir gan duine ina aire nó sula ndéanann sé iarracht an scútar soghluaisteachta a oibriú. (LT) Vairavimo sistema turi būti vėl įjungta, kol keleivis paliekamas be priežiūros arba prieš bandant valdyti mobilųjį paspirtuką. (LV) Piedziņas sistēma ir jāieslēdz no jauna, pirms kāds pasažieris tiek atstāts bez uzraudzības vai viņš mēģina vadīt motorolleru. (MT) Is-sistema tas-sewqan għandha terġa' tiġi attivata qabel ma okkupant jitħalla waħdu jew jipprova jħaddem l-iskuter tal-mobilità. (NL) Het aandrijfsysteem moet opnieuw worden ingeschakeld voordat een inzittende onbeheerd wordt achtergelaten of de scootmobiel probeert te bedienen. (DE) Das Antriebssystem sollte wieder eingekuppelt werden, bevor ein Insasse unbeaufsichtigt gelassen wird oder versucht, den Elektromobil zu bedienen. (PL) Układ napędowy powinien zostać załączony, zanim użytkownik zostanie pozostawiony bez nadzoru lub uruchomi funkcje skutera inwalidzkiego. (PT) O sistema de acionamento deve ser reativado antes que um ocupante seja deixado sem vigilância ou tente operar a scooter. (RO) Sistemul de propulsie trebuie recuplat înainte ca un ocupant să fie lăsat nesupravegheat sau să încerce să opereze scuterul pentru mobilitate. (SK) Pohonný systém by mal byť znovu zapnutý predtým, ako cestujúci zostane bez dozoru alebo sa pokúsi ovládať mobilný skúter. (SLO) Pogonski sistem je treba ponovno vklopiti, preden potnik ostane brez nadzora ali poskusi upravljati skuter za mobilnost. (SE) Drivsystemet bör kopplas in igen innan en passagerare lämnas utan uppsikt eller försöker använda skotern. (HU) A hajtásrendszert újra be kell kapcsolni, mielőtt egy utast felügyelet nélkül hagynának, vagy megkísérelné működtetni a robogót. (IT) Il sistema di guida deve essere riattivato prima che un occupante venga lasciato incustodito o tenti di azionare lo scooter elettrico.

*Figure 3: Important safety notice: Re-engage the drive system before operation or leaving unattended.*

## 3. Components Overview

Familiarize yourself with the key components of your SHARPY mobility scooter:




*Figure 4: Annotated diagram of the SHARPY mobility scooter components.*

- **Adjustable Captain's Seat:** Ergonomic, swivel seat for comfort and easy transfer.
- **Control Panel:** Intuitive interface with digital display for speed, battery, and essential information.
- **Dual Control Levers:** Forward and reverse operation on both sides for flexible, single-hand driving.
- **Adjustable Steering Column:** Customize the steering position for personalized driving.
- **Magnetic Brake System:** Ensures reliable and safe stopping.
- **Anti-tip Wheels:** Provides enhanced stability.
- **Integrated Bluetooth Speaker:** For entertainment during travel.
- **USB Port & Card Slot:** For charging devices and media access.
- **Rearview Mirrors & Phone Holder:** Included for convenience and safety.
- **Full Suspension:** For a smooth and stable ride on various terrains.

## 4. Setup and Initial Use

### 4.1 Unpacking and Assembly

Carefully remove all components from the packaging. Assembly typically involves attaching the seat, mirrors, and any other accessories. Refer to the quick start guide included with your scooter for detailed assembly instructions.

### 4.2 Charging the Battery

Before first use, fully charge the scooter's battery. Locate the charging port (refer to Figure 4) and connect the provided charger. The digital display will indicate the charging status. Do not interrupt the charging cycle until the battery is full.

### 4.3 Adjusting the Seat and Steering

Adjust the captain's seat for optimal comfort and accessibility. The seat can swivel and its height can be adjusted. The

steering column is also adjustable to suit your preferred driving posture. Ensure all adjustments are securely locked before operation.

## 5. Operating Instructions

### 5.1 Starting the Scooter

1. Ensure you are seated comfortably and the seatbelt is fastened.
2. Insert the key into the ignition and turn it to the 'ON' position.
3. The digital display will illuminate, showing battery level and speed.



*Figure 5: The scooter's control panel and digital display.*

### 5.2 Driving the Scooter

The SHARPY is operated using dual control levers located on both sides of the handlebars. Push the levers forward to move forward, and pull them back to reverse. Release the levers to engage the magnetic brake and stop the scooter.

- **Speed Control:** Use the speed adjustment dial on the control panel to set your desired maximum speed.
- **Steering:** Use the handlebars to steer the scooter.
- **Lights and Indicators:** Utilize the LED headlights and indicators for visibility and signaling.

### 5.3 Using Multimedia Features

The scooter features an integrated Bluetooth speaker, USB port, and card slot. Pair your mobile device via Bluetooth to play music. Use the USB port to charge your devices or play media from a USB drive. The card slot supports compatible memory cards for media playback.



*Figure 6: Front storage compartment and charging access.*

## 6. Maintenance and Care

Regular maintenance ensures the longevity and safe operation of your SHARPY scooter.

- **Cleaning:** Wipe down the scooter with a damp cloth. Avoid using abrasive cleaners or direct water spray.
- **Battery Care:** Always fully charge the battery after each use. If storing the scooter for an extended period, charge the battery at least once a month.
- **Tire Pressure:** Periodically check the tire pressure and inflate to the recommended levels.
- **Brake System:** Inspect the magnetic brake system regularly for proper function. If you notice any issues, contact customer support.
- **General Inspection:** Routinely check all nuts, bolts, and connections for tightness. Ensure all lights and indicators are working.

## 7. Troubleshooting

This section addresses common issues you might encounter with your SHARPY mobility scooter.

| Problem | Possible Cause | Solution |
|---|---|---|
| Scooter does not power on. | Battery is discharged; key is not in 'ON' position; loose battery connection. | Charge the battery; turn the key to 'ON'; check battery connections. |
| Scooter moves slowly or lacks power. | Low battery charge; incorrect speed setting; motor issue. | Recharge battery; adjust speed setting; contact service if issue persists. |
| Brakes are not engaging properly. | Brake system malfunction; obstruction. | Inspect for obstructions; contact service for brake system inspection. |
| Bluetooth speaker not connecting. | Device not in pairing mode; speaker not powered on. | Ensure speaker is on and in pairing mode; check device's Bluetooth settings. |

If you encounter an issue not listed here or if the suggested solutions do not resolve the problem, please contact VELECO customer support.

## 8. Product Specifications

| Feature | Detail |
|---|---|
| Brand | VELECO |
| Model Name | SHARPY |
| Model Number | SHA |
| Product Dimensions (L x W x H) | 57.1 x 27.6 x 58.3 cm (22.5 x 10.9 x 22.9 inches) |
| Product Weight | 135 kg (297.6 lbs) |
| Maximum Weight Recommendation | 160 kg (352.7 lbs) |

| Feature | Detail |
|---|---|
| Material | Aluminum |
| Brake Style | Magnetic Brake |
| Power Source | Battery |
| Color Options | Black, Blue, Red, White |

## 9. Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or visit the official VELECO website. If you require technical support, spare parts, or have any questions regarding your SHARPY mobility scooter, please contact your retailer or VELECO customer service directly.

**VELECO Contact Information:**

- **Website:** VELECO Official Store on Amazon (for general inquiries and product information)
- For specific support, please consult the contact details provided in your product packaging.

© 2023 VELECO. All rights reserved. Information in this manual is subject to change without notice.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question