**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## ANCTOR HK-TBF-25

# ANCTOR Twin Bed Frame Instruction Manual

Model: HK-TBF-25

### Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your ANCTOR Twin Bed Frame, Model HK-TBF-25. This upholstered platform bed features a storage headboard with an integrated charging station and three under-bed storage drawers. Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation.

### Safety Information

**Important Safety Warnings:**

- Do not exceed the weight capacity of 700 lbs.
- Be cautious of sharp edges and moving parts during assembly.
- Always follow the assembly instructions carefully to prevent injury.
- Ensure all connections are securely tightened before use.
- Keep children and pets away from the assembly area.

### Package Contents

Verify that all components are present before beginning assembly. The ANCTOR Twin Bed Frame is shipped in a single box and includes:

- Upholstered Headboard with Integrated Charging Station
- Upholstered Side Rails and Footboard
- Metal Bed Frame Components
- Wooden Slats with Hook and Loop Fasteners
- Three Under-Bed Storage Drawers with Wheels
- Assembly Hardware (bolts, nuts, washers, Allen wrench)
- Instruction Manual



Figure 1: Exploded view of all bed frame components, including the headboard, frame, wooden slats, and three under-bed drawers.

## Setup and Assembly

Assembly of the ANCTOR Twin Bed Frame is designed to be straightforward. It is recommended to assemble the bed in the room where it will be used.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Headboard:** Attach the headboard support legs to the upholstered headboard section. Ensure the charging station is correctly oriented.
3. **Construct Bed Frame:** Connect the side rails and footboard to the headboard using the provided hardware. Do not fully tighten bolts until all major components are aligned.
4. **Install Slats:** Position the wooden slats across the bed frame. The hook and loop fastener design simplifies this step.

Ensure the EVA silent strip is properly placed to reduce noise.

5. **Secure Support Bar:** Install the heavy-duty steel support bar under the headboard for additional stability.
6. **Insert Drawers:** Place the three storage drawers under the bed. The drawers are equipped with rolling wheels for easy movement and a special lock design to keep them in place.
7. **Final Tightening:** Once all components are in place and aligned, fully tighten all bolts and connections.





Figure 2: Detail of the heavy frame structure, illustrating the wooden slats, metal frame, and iron support legs for stability.




Figure 3: The ANCTOR Twin Bed Frame fully assembled, showcasing the storage headboard and accessible under-bed drawers.

## Operating Instructions

### Charging Station

The integrated charging station in the headboard provides convenient access to power for your electronic devices.

- **Power Connection:** Plug the 6.5-foot power cord extending from the headboard into a standard 110V wall outlet.
- **AC Outlets:** Two 110V/12A AC outlets are available for larger electronics like laptops or lamps.
- **USB Ports:** Two 5V/2A USB ports are provided for charging smartphones, tablets, and other USB-powered devices.
- **Storage Shelf:** The headboard also features a shelf for placing items such as glasses, books, or decorative objects.
- **Side Pockets:** Small pockets are located on both sides of the headboard for additional storage of small items like remote controls or phones.




Figure 4: The headboard's integrated charging station, featuring two AC outlets and two USB ports, with a 6.5-foot power cord.

## Storage Drawers

The three under-bed drawers offer practical storage solutions for your belongings.

- **Access:** Gently pull the drawers outward to access their contents. They are fitted with rolling wheels for smooth operation.
- **Securing Drawers:** A special lock design ensures the drawers remain in place when pushed fully under the bed.
- **Capacity:** Utilize the drawers for storing bedding, clothing, books, or other personal items.




Figure 5: Detail of the under-bed storage drawer, showing its wheels for easy sliding and the snap-in mechanism for secure placement.

## Maintenance

Regular maintenance helps prolong the life and appearance of your bed frame.

- **Cleaning Upholstery:** For general cleaning, gently vacuum the upholstered parts. For spills, blot immediately with a clean, damp cloth. Avoid harsh chemicals.
- **Frame Cleaning:** Wipe metal and wood surfaces with a soft, dry cloth.
- **Check Connections:** Periodically inspect all bolts and screws to ensure they remain tight. Re-tighten as necessary to maintain stability and prevent noise.
- **Drawer Maintenance:** Keep drawer wheels free of debris to ensure smooth operation.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Bed frame is noisy or creaks | Loose bolts or slats not properly seated. | Check and tighten all assembly bolts. Ensure wooden slats are correctly positioned and the EVA silent strip is intact. |
| Drawers do not slide smoothly | Obstruction in wheels or misaligned drawer. | Clear any debris from the drawer wheels. Ensure the drawer is properly aligned with the bed frame opening. |
| Charging station not working | Power cord not connected or wall outlet issue. | Verify the power cord is securely plugged into both the headboard and a functional wall outlet. Test the wall outlet with another device. |

## Specifications

- **Model Number:** HK-TBF-25
- **Size:** Twin
- **Product Dimensions (L x W x H):** 81.9" x 40.9" x 46.1"
- **Weight Capacity:** 700 lbs
- **Compatible Mattress Size:** Twin (8" - 12" thickness recommended)
- **Color:** Linen Beige
- **Materials:** Upholstered (Linen), Wood (Slats, Headboard Shelf), Metal (Frame, Drawers)
- **Item Weight:** 79 pounds
- **Charging Station:**
  - AC Outlets: 2 x 110V/12A
  - USB Ports: 2 x 5V/2A
  - Power Cord Length: 6.5 feet





Figure 6: Detailed dimensions of the ANCTOR Twin Bed Frame and its components.




Figure 7: Headboard height and recommended mattress thickness range.

## Warranty and Support

ANCTOR is committed to providing quality products and customer satisfaction.

- **Customer Service:** If you have any questions regarding the quality of the product, assembly, or installation, please contact ANCTOR customer service.
- **Response Time:** Our customer service team aims to provide a solution within twenty-four hours.
- **Contact Information:** Please refer to the contact details provided with your purchase documentation or visit the official ANCTOR website for support.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0CHBHHFYF**

More documents and user manuals: **https://manuals.plus/**