

Crown 43 Inch Smart LED

CROWN 43 Inch Smart LED TV User Manual

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all safety and operating instructions carefully before using this television. Keep these instructions for future reference. Adhere to all warnings on the product and in the operating instructions.

- **Power Source:** Operate this product only from the type of power source indicated on the marking label.
- **Ventilation:** Slots and openings in the cabinet are provided for ventilation. Do not block or cover these openings.
- **Water and Moisture:** Do not use this product near water.
- **Cleaning:** Unplug this product from the wall outlet before cleaning. Use a damp cloth for cleaning. Do not use liquid cleaners or aerosol cleaners.
- **Lightning:** For added protection during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package. If any items are missing or damaged, contact your retailer.

- CROWN 43 Inch Smart LED TV
- Remote Control
- Power Cord
- Table Stand (2 pieces)
- Screws for Table Stand
- User Manual

3. PRODUCT OVERVIEW

The CROWN 43 Inch Smart LED TV offers a Full HD viewing experience with smart features powered by Linux OS.

It includes multiple connectivity options for various devices and integrated Wi-Fi for internet access.



Figure 3.1: Front view of the CROWN 43 Inch Smart LED TV displaying its smart interface with various applications.

4. SETUP

4.1 Unpacking

Carefully remove the TV from its packaging. It is recommended to retain the packaging materials for future transport or servicing.

4.2 Stand Installation

1. Place the TV screen-down on a soft, flat surface to prevent scratches.
2. Align the table stand pieces with the corresponding slots at the bottom of the TV.
3. Secure the stand pieces using the provided screws. Ensure they are tightened firmly.



Figure 4.1: CROWN 43 Inch Smart LED TV with its dimensions, useful for stand placement or wall mounting considerations.

4.3 Wall Mounting (Optional)

This TV supports wall mounting. A separate wall mount bracket (not included) is required. Follow the instructions provided with your wall mount kit. Ensure proper ventilation when wall-mounted.

4.4 Connecting Peripherals

Connect your external devices to the TV using the appropriate ports:

- **HDMI Ports (2):** For connecting set-top boxes, Blu-ray players, gaming consoles, and other HDMI-enabled devices.
- **USB Ports (2):** For connecting USB hard drives, flash drives, and other USB devices for media playback.
- **AV Input Slots (3):** For connecting older devices using composite video and stereo audio cables.
- **AV Output Slots (3):** For connecting to external audio/video systems.
- **Headphone Jack (1):** For connecting headphones for private listening.
- **RF Slot (1):** For connecting an antenna or cable TV input.

5. OPERATING THE TV

5.1 Initial Setup

1. Connect the power cord to the TV and a power outlet.
2. Press the power button on the remote control or TV.
3. Follow the on-screen instructions to select your language, country, and perform channel scanning.
4. Connect to your Wi-Fi network by selecting your network and entering the password.

5.2 Basic Functions

- **Power On/Off:** Use the power button on the remote or TV.
- **Volume Control:** Use the VOL +/- buttons on the remote.
- **Channel Selection:** Use the CH +/- buttons or number pad on the remote.
- **Mute:** Press the MUTE button to temporarily turn off sound.

5.3 Smart TV Features

Your CROWN Smart LED TV runs on Linux OS and features built-in Wi-Fi, allowing access to various online content and applications.

- **App Store:** Access and download various applications.
- **Browser:** Browse the internet directly from your TV.
- **Voice Support:** Utilize voice commands for navigation and control (if remote supports voice input).
- **Memory:** The TV is equipped with 1GB RAM and 8GB ROM for smooth operation and app storage.

5.4 Input Source Selection

Press the 'Source' or 'Input' button on your remote control to cycle through available input sources (HDMI 1, HDMI 2, AV 1, AV 2, AV 3, etc.) and select the desired one.

6. MAINTENANCE

6.1 Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and cabinet. For stubborn marks, use a slightly damp cloth with a mild, non-abrasive cleaner specifically designed for electronics.
- Do not spray cleaners directly onto the screen or cabinet.

6.2 Power Care

- Ensure the power cord is not pinched or walked on.
- Unplug the TV during lightning storms or when unused for extended periods.

7. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions before contacting support.

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
No power	Check if the power cord is securely plugged into the TV and the wall outlet. Test the outlet with another device.
No picture, but sound is present	Ensure the correct input source is selected. Check cable connections to external devices.
No sound, but picture is present	Check the volume level and ensure the TV is not muted. Check audio cable connections.
Remote control not working	Replace the batteries in the remote. Ensure there are no obstructions between the remote and the TV's IR sensor.
Cannot connect to Wi-Fi	Ensure your Wi-Fi router is on and working. Re-enter the Wi-Fi password. Try restarting both the TV and the router.

8. SPECIFICATIONS

Detailed technical specifications for the CROWN 43 Inch Smart LED TV.

Feature	Specification
Model Number	f1111255-38a9-4052-90af-1841643b059b
Display Size	43 Inches (109 Centimetres)
Display Type	LED
Resolution	Full HD (1920 x 1080p)
Refresh Rate	90 Hz
Viewing Angle	178 Degrees
Operating System	Linux
RAM	1 GB
ROM	8 GB
Sound Output	20 Watts, Dolby Audio
HDMI Ports	2
USB Ports	2
AV Input Slots	3
AV Output Slots	3
Headphone Jack	1
RF Slot	1
Connectivity	In-Built Wi-Fi
Product Dimensions (LxWxH)	110 x 20 x 70 cm

Feature	Specification
Manufacturer	CROWN PVT LTD

9. WARRANTY INFORMATION

This CROWN 43 Inch Smart LED TV comes with a **1 Year Standard Manufacturer Warranty** from Crown, effective from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims or technical support, please contact the manufacturer's customer service. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question