

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Walfront](#) /

› [Walfront WALFRONTanqg7pte84 Indoor Security Camera User Manual](#)

Walfront WALFRONTanqg7pte84

Walfront WALFRONTanqg7pte84 Indoor Security Camera User Manual

Model: WALFRONTanqg7pte84

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Walfront WALFRONTanqg7pte84 Indoor Security Camera. Please read this manual carefully before using the product to ensure proper functionality and safety. This camera is designed for indoor surveillance, offering 720P video resolution and a 120° wide-angle view.

2. SAFETY INFORMATION

- Ensure the camera is used within its specified operating temperature and humidity ranges.
- Do not expose the camera to water or moisture, as it is designed for indoor use only.
- Use only the provided power cable and adapter to prevent damage.
- Keep the camera out of reach of children and pets.
- Avoid placing the camera in direct sunlight or near heat sources.
- Do not attempt to disassemble or repair the camera yourself. Contact customer support for assistance.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Walfront WALFRONTanqg7pte84 Indoor Security Camera
- USB Charging Cable
- Mounting Bracket
- User Manual (this document)



Figure 3.1: Included components of the Walfront Indoor Security Camera.

4. PRODUCT OVERVIEW

The Walfront WALFRONTanqg7pte84 camera is a compact device designed for discreet indoor monitoring. It features a 720P lens, a Micro SD card slot for local storage, and buttons for power and mode selection.



Figure 4.1: Walfront Indoor Security Camera in a typical indoor setting.

5. SETUP

5.1 Charging the Camera

Before initial use, fully charge the camera using the provided USB cable. Connect the small end of the USB cable to the camera's charging port and the larger end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status.

5.2 Inserting a Micro SD Card

Locate the Micro SD card slot on the camera. Gently insert a Micro SD card (up to 128GB, not included) into the slot until it clicks into place. Ensure the card is inserted in the correct orientation. The camera supports AVI and MP4 video formats.

5.3 Mounting the Camera

The camera comes with a mounting bracket for flexible placement. Attach the camera to the bracket. The bracket can be affixed to a clean, flat surface using its adhesive base or screws (not included). Ensure the camera is positioned to cover the desired monitoring area.

Your browser does not support the video tag.

Video 5.1: Demonstrates the assembly and basic setup of the Walfront Security Camera, including attaching the camera to

its stand and powering it on.

6. OPERATING INSTRUCTIONS

6.1 Powering On/Off

Press and hold the "ON/OFF" button to power the camera on or off. An indicator light will confirm the power status.

6.2 Connecting to Wi-Fi

The camera supports **2.4G WiFi networks only**. It does not support 5G WiFi. Before connecting the camera, ensure your mobile phone is connected to a 2.4G WiFi network. If your router supports both 2.4G and 5G, temporarily disable 5G or ensure your phone prioritizes 2.4G during the setup process to avoid connection failures.

6.3 App Download and Connection

Download the designated mobile application for iOS or Android devices (refer to the packaging or included quick start guide for the specific app name). Follow the in-app instructions to add your camera. This typically involves scanning a QR code on the camera or manually entering its device ID.

6.4 Real-Time Viewing

Once connected, you can view live video feed from the camera anywhere via the mobile application. The camera provides a 120° wide-angle view and 720P resolution for clear monitoring.

Surveillance System

The camera features 120° wide angle lens and 720P, camera is able to take and record details clearly.



Figure 6.1: The camera's wide-angle view captures a broad area, suitable for rooms like kitchens.




Figure 6.2: Real-time monitoring of the camera feed on a smartphone.

6.5 Motion Detection and Alarms

The camera features mobile detection alarm capabilities. When movement is detected within its field of view, the camera will push an information prompt to your connected mobile device, alerting you to any abnormalities. This feature helps in monitoring for object movement.

Your browser does not support the video tag.

Video 6.1: Illustrates various applications and features of the Walfront Security Camera, including its wide-angle view and mobile detection capabilities.

7. SPECIFICATIONS

Feature	Detail
Brand	Walfront
Model Name	WALFRONTanqg7pte84
Connectivity Technology	Wireless (Wi-Fi)

Special Feature	2-Way Audio, Motion Detection
Indoor/Outdoor Usage	Indoor
Compatible Devices	Smartphone (iOS, Android)
Video Capture Resolution	720p
Wide Angle Lens	120°
Storage	Micro SD Card (up to 128GB)
Battery	3.7V, 600mAh polymer lithium battery (built-in)
Item Weight	0.05 Kilograms

8. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Avoid using liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the camera in a cool, dry place away from direct sunlight.
- **Battery Care:** To prolong battery life, avoid fully discharging the camera frequently. Charge it regularly, even if not in constant use.

9. TROUBLESHOOTING

Camera not powering on:

Ensure the camera is fully charged. Connect it to a power source and check the charging indicator light.

Cannot connect to Wi-Fi:

Verify that your router is broadcasting a 2.4G WiFi network. The camera does not support 5G WiFi. Ensure your phone is connected to the 2.4G network during setup. Restart your router and camera, then try connecting again.

Poor video quality:

Check your Wi-Fi signal strength. A weak signal can affect video streaming quality. Ensure the camera lens is clean and free from obstructions.

Motion detection not working:

Ensure motion detection is enabled in the mobile application settings. Adjust sensitivity settings if necessary.

10. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the contact details provided on the product packaging or the official Walfront website. Keep your purchase receipt as proof of purchase.