

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Walfront](#) /

› [Walfront Indoor Security Camera WALFRONTrins8xzdpy User Manual](#)

Walfront WALFRONTrins8xzdpy

Walfront Indoor Security Camera WALFRONTrins8xzdpy User Manual

Model: WALFRONTrins8xzdpy

1. INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Walfront Indoor WiFi Wireless Surveillance Camera, model WALFRONTrins8xzdpy. This compact security camera is designed for indoor use, offering 720P video resolution and a 120° wide-angle lens for clear monitoring. It features motion detection capabilities and real-time viewing via a mobile application for both iOS and Android devices.



Image 1.1: Walfront Indoor Security Camera, including the camera unit, magnetic bracket, and USB data cable.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1 x Walfront Indoor Security Camera
- 1 x Magnetic Bracket
- 1 x USB Data Cable
- 1 x User Manual (this document)



Image 2.1: The Walfront camera, its magnetic bracket, and USB charging cable as included in the package.

3. SETUP

3.1 Charging the Camera

The camera includes a built-in 3.7V, 600mAh polymer lithium battery. Before first use, fully charge the camera using the provided USB data cable connected to a standard USB power adapter (not included). The camera can also operate continuously when connected to a USB power source.

3.2 Inserting a Memory Card (Optional)

For local video storage, insert a memory card (Micro SD card) into the designated slot. The camera supports memory cards up to 128GB. The memory card is not included in the package.



Image 3.1: Side view of the Walfront camera, highlighting the Micro SD card slot for local storage.

3.3 App Download and Installation

To access real-time video and camera settings, download the compatible mobile application. The app is available for both iOS and Android devices. Refer to the packaging or a quick start guide for the specific app name or QR code.

3.4 Connecting to Wi-Fi

1. Power on the camera using the ON/OFF button.
2. Open the installed mobile application on your smartphone.
3. Follow the in-app instructions to add a new device and connect the camera to your home Wi-Fi network. Ensure your Wi-Fi network is 2.4GHz, as 5GHz networks may not be supported.
4. Once connected, you can view the live feed and manage settings from your mobile device.

Surveillance System

The camera features 120° wide angle lens and 720P, camera is able to take and record details clearly.



Image 3.2: A user interacting with the Walfront camera's mobile application to view live surveillance footage.

3.5 Mounting the Camera

The camera comes with a magnetic bracket for flexible placement. Attach the camera to the bracket and position it on a flat surface or mount it to a wall. The small size of the camera allows for discreet placement.



Image 3.3: The Walfront camera mounted on a wall, illustrating its wide-angle coverage in a room setting.

4. OPERATING INSTRUCTIONS

4.1 Real-Time Monitoring

Once the camera is connected to your Wi-Fi network and linked to the mobile app, you can view real-time video from any location with internet access. Open the app and select your camera to access the live feed.

4.2 Motion Detection and Alerts

The camera is equipped with motion detection. When movement is detected within its field of view, the camera can send an alert notification to your mobile device. You can configure motion detection sensitivity and alert preferences within the mobile application.

Wireless WiFi Camera

The camera supports for IOS and for Android devices, download APP and connect to the network, you can view real time video from anywhere on the App.




Image 4.1: The Walfront camera's motion detection feature, illustrating an alert being sent to a smartphone when activity is detected.

4.3 Video Recording

The camera records video in 720P resolution with a 120° wide-angle view. If a memory card is inserted, recordings can be stored locally. The camera supports continuous recording when powered via USB. Recording settings, such as continuous recording or motion-activated recording, can typically be managed through the mobile app.




Image 4.2: The Walfront camera positioned to monitor a kitchen, demonstrating its surveillance capability.

4.4 Playback

Recorded videos stored on the memory card can be played back using compatible software such as VLCPlayer or SMLayer on a computer. Some mobile applications also offer direct playback of recorded footage.

5. MAINTENANCE

5.1 Cleaning

To maintain optimal performance, periodically clean the camera lens and exterior with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the camera.

5.2 Environmental Conditions

Ensure the camera operates within the specified environmental ranges:

- **Operating Temperature:** -10°C to 60°C (14°F to 140°F)
- **Operating Humidity:** 15% to 85% RH (non-condensing)
- **Storage Temperature:** -20°C to 80°C (-4°F to 176°F)

Avoid exposing the camera to extreme temperatures, direct sunlight for prolonged periods, or high humidity, as this can affect its functionality and lifespan.

6. TROUBLESHOOTING

If you encounter issues with your Walfront Indoor Security Camera, refer to the following common problems and solutions:

- **Camera does not power on:**
 - Ensure the camera is fully charged or connected to a stable USB power source.
 - Verify the ON/OFF button is pressed correctly.

- **Cannot connect to Wi-Fi / Unreliable connection:**
 - Confirm your Wi-Fi network is 2.4GHz. This camera may not support 5GHz networks.
 - Ensure the camera is within range of your Wi-Fi router. Obstacles like thick walls can weaken the signal.
 - Restart your Wi-Fi router and the camera.
 - Check if the Wi-Fi password entered in the app is correct.
 - If using a mobile hotspot, ensure it is stable and configured correctly.

- **No video feed in the app:**
 - Check your internet connection on your smartphone.
 - Ensure the camera is powered on and connected to Wi-Fi.
 - Close and reopen the mobile application.
 - If the issue persists, try resetting the camera (refer to app instructions for reset procedure) and re-pairing it with the app.

- **Motion detection alerts are not received:**
 - Verify that motion detection is enabled in the camera settings within the mobile app.
 - Check your phone's notification settings to ensure the app is permitted to send notifications.
 - Ensure the camera has a stable internet connection.

7. SPECIFICATIONS

Feature	Specification
Item Type	Wireless WiFi Camera
Material	ABS
Color	Black
Resolution	720P
Video Format	AVI
Number of Frames	25 FPS
Horizontal Angle of View	120°

Feature	Specification
Minimum Illumination	1LX
Recording Duration	USB plug (continuous when powered)
Compression Format	H.264
Voice Recording Range	5
Power Consumption	300mA, 3.7V
Operating Temperature	-10°C to 60°C
Operating Humidity	15% to 85% RH
Storage Temperature	-20°C to 80°C
Memory Card Type	Max 128GB (not included)
Playback Software	VLCPlayer, SMLayer
Mobile Operating System	Android, iOS
Battery	3.7V, 600mAh Polymer Lithium Battery (built-in)
Connectivity Protocol	Wi-Fi
Mounting Type	Wall Mount

8. WARRANTY AND SUPPORT

Specific warranty information for the Walfront Indoor Security Camera WALFRONTTrins8xzdpy is not provided in this manual. For details regarding warranty coverage, return policies, or technical support, please refer to the documentation included with your purchase or contact the retailer or manufacturer directly.