

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SONGMICS](#) /

› [SONGMICS ULCB150W01 50L Laundry Hamper Instruction Manual](#)

SONGMICS ULCB150W01

SONGMICS 50L Collapsible Laundry Hamper

MODEL: ULCB150W01

Introduction

Thank you for choosing the SONGMICS 50L Collapsible Laundry Hamper. This manual provides essential information for the safe and efficient assembly, use, and maintenance of your new laundry hamper. Please read these instructions carefully before use and retain them for future reference.



Image: The SONGMICS 50L Collapsible Laundry Hamper in Cream White, showcasing its metal wire frame and fabric liner.

Safety Instructions

- Do not overload the hamper beyond its stated weight capacity to prevent damage or injury.
- Keep the hamper away from open flames or heat sources.
- Ensure the hamper is placed on a stable, level surface to prevent tipping.
- This product is intended for laundry storage only. Do not use it for climbing or as a toy.
- Keep out of reach of small children and pets to avoid potential hazards.

Package Contents

Please check to ensure all components are present:

- 1 x Metal Wire Frame (collapsible)
- 1 x Removable Fabric Liner with Handles and Drawstring


Setup and Assembly

Assembly of your SONGMICS laundry hamper is quick and straightforward:

1. **Unfold the Wire Frame:** Carefully unfold the metal wire frame until it forms a rectangular shape. Ensure all hinges are fully extended and locked into place for stability.
2. **Insert the Bottom:** Place the bottom panel of the frame into position, ensuring it sits securely at the base.
3. **Attach the Fabric Liner:** Position the fabric liner inside the metal frame. Secure the liner to the top edge of the frame using the hook-and-loop fasteners provided on the liner. Ensure it is evenly distributed and firmly attached on all sides.

Foldable

- Saves space when not in use
- Easy to assemble



Unfold the frame



Attach the liner



Image: Visual guide showing the unfolding of the frame and attachment of the liner.

Operating Instructions

Using your laundry hamper is designed for convenience:

- **Placing Laundry:** Simply place your dirty clothes into the fabric liner. The sturdy frame will maintain the hamper's shape, preventing it from collapsing.
- **Securing Contents:** The liner features a drawstring at the top edge. Pull the drawstring to close the opening, keeping laundry out of sight and containing odors.
- **Removing the Liner:** When it's time for laundry, detach the hook-and-loop fasteners from the frame. Use the integrated handles on the liner to easily lift and carry your laundry to the washing machine. This eliminates the need to transport the entire hamper.

Removable Liner

To use it anywhere around the house



Breathable Fabric



Machine Washable



Convenient Handles

Image: The removable fabric liner being lifted from the metal frame using its handles.

Easy to Secure and Close



Secured with hook-and-loop fastener



Drawstring closure for added privacy

Image: Close-up of the drawstring mechanism on the fabric liner for securing contents.

Maintenance and Care

- **Fabric Liner:** The poly-cotton blend liner is machine washable. For best results, wash in cold water on a gentle cycle and tumble dry on low heat or air dry. Do not bleach.
- **Metal Frame:** Wipe the metal wire frame with a damp cloth and mild detergent as needed. Dry thoroughly to prevent rust. Avoid using abrasive cleaners.
- **Storage:** When not in use, the metal frame can be folded flat for compact storage.

Troubleshooting

- **Hamper not standing upright:** Ensure the metal frame is fully unfolded and the bottom panel is securely in place. Check that the fabric liner is correctly attached with all hook-and-loop fasteners.
- **Liner slipping:** Verify that all hook-and-loop fasteners are firmly attached to the metal frame. If the liner is heavily loaded, ensure the weight is evenly distributed.

Specifications

Product Dimensions	15.7"L x 11.8"W x 16.1"H (40 x 30 x 41 cm)
Brand	SONGMICS
Color	Cream White
Material	Steel, Poly-Cotton Blend Fabric
Capacity	11 Gallons (50 L)
Max. Static Load (Liner)	22 lb (10 kg)
Max. Static Load (Frame)	44 lb (20 kg)
Item Weight	4.29 pounds
Model Number	ULCB150W01

High Load Capacity

Supported by a metal frame and thick fabric

11 Gal.
(50L)

↓ ↓ ↓
22 lb
(10 kg)

Max. Static Load
of the Liner

↓ ↓ ↓
44 lb
(20 kg)

Max. Static Load of
the Metal Frame




Image: Diagram illustrating the dimensions and load capacities of the laundry hamper.

Warranty and Support

For any questions, concerns, or warranty inquiries regarding your SONGMICS laundry hamper, please contact our customer support team. Refer to your purchase documentation for specific warranty details and contact information.