

[Manuals.plus](#) /

> [JUMMICO](#) /

> JUMMICO Electric Height Adjustable Desk 160 x 70 cm (Black) - Instruction Manual

JUMMICO 0183

JUMMICO Electric Height Adjustable Desk (Model 0183) Instruction Manual

Model: 0183 | Size: 160 x 70 cm | Color: Black

1. INTRODUCTION

Thank you for choosing the JUMMICO Electric Height Adjustable Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before use and retain them for future reference.



2. SAFETY INFORMATION

- Ensure all connections are secure before operating the desk.
- Keep children and pets away from the desk during operation to prevent injury.
- Do not overload the desk. Refer to the specifications for maximum weight capacity.
- Avoid placing liquids directly on the control panel or near electrical components.
- If the desk makes unusual noises or movements, discontinue use immediately and consult the troubleshooting section.
- Only use the provided power adapter and cables.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. Refer to the assembly video for a visual guide to parts.



Image 2: Overview of desk components and hardware included in the package.

4. SETUP GUIDE

Assembly typically takes approximately 30 minutes with clear instructions provided. For a detailed visual guide, please watch the official assembly video below.

Your browser does not support the video tag.

Video 1: JUMMICO Electric Height Adjustable Desk Assembly Guide. This video demonstrates the step-by-step process of assembling the desk, including attaching the frame, motor, and tabletop sections.


Assembly Steps Overview:

1. **Step 1: Connect the Crossbar Sections.** Join the two main crossbar sections using the provided screws and tools.
2. **Step 2: Attach the Lifting Columns.** Secure the lifting columns to the assembled crossbar. Ensure they are oriented correctly.
3. **Step 3: Install the Side Brackets.** Attach the side brackets to the lifting columns for additional stability.
4. **Step 4: Secure the Feet.** Fasten the T-shaped feet to the bottom of the lifting columns. These provide a stable base.
5. **Step 5: Assemble the Tabletop.** The tabletop consists of multiple sections. Use the wooden dowels and connecting plates to align and secure these sections together.
6. **Step 6: Attach the Tabletop to the Frame.** Carefully place the assembled tabletop onto the frame and secure it using the designated screws.

7. **Step 7: Connect the Drive Rod.** Insert the drive rod between the motor and the opposite lifting column to enable height adjustment.
8. **Step 8: Mount the Control Panel.** Attach the electric control panel to the underside of the desk in the designated area.
9. **Step 9: Connect Power and Control Cables.** Plug in the power adapter and connect all necessary control cables to the motor and control panel.
10. **Step 10: Organize Cables.** Use the provided cable ties and clips to manage and secure cables neatly under the desk.
11. **Step 11: Install Headphone Hook.** Attach the headphone hook to the underside of the desk as desired.
12. **Step 12: Insert Cable Pass-through.** Place the cable pass-through grommet into the pre-drilled hole on the tabletop.



Easy to Install




Clear instructions

+



Installation video

=



30 minutes to set up

Image 3: Visual representation of the desk components during assembly.

5. OPERATING INSTRUCTIONS

The JUMMICO Electric Height Adjustable Desk offers intuitive controls for a personalized workspace experience.

Your browser does not support the video tag.

Video 2: JUMMICO Electric Height Adjustable Desk Features Overview. This video demonstrates the desk's height

adjustment, memory presets, and USB charging capabilities.

Control Panel Functions:



Image 4: The multi-function intelligent keypad with labeled controls.

- **LED Display:** Shows the current desk height in centimeters.
- **Up/Down Buttons (+/-):** Press and hold to adjust the desk height continuously.

- **Memory Presets (1/2):**

- a. Adjust the desk to your desired height.
- b. Press the 'M' button, then press '1' or '2' to save the current height to that preset.
- c. To recall a saved height, simply press '1' or '2'.

- **Sedentary Reminders:** The desk features a timed reminder function to encourage alternating between sitting and standing positions. Consult the full manual for detailed programming instructions.
- **USB Charging Port:** Located on the control panel for convenient charging of mobile devices.

Anti-Collision Function:

The motor system is equipped with an anti-collision feature. If the desk encounters an obstacle during height adjustment, it will automatically stop and reverse slightly to prevent damage.



Image 5: The desk's wide height range allows for comfortable sitting and standing positions.


6. MAINTENANCE

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cable Management:** Regularly check and organize cables to prevent tangles and damage. The integrated cable hub and clips help maintain a tidy workspace.

- **Inspection:** Periodically inspect all screws and connections to ensure they are tight.




Humanized Design



Protective Edge Humanized Design



Cable pass-through



Seamless Splicing



Easy to Clean

Image 6: Features like rounded edges, cable pass-through, and an easy-to-clean surface contribute to desk maintenance.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected, motor cable loose, overload.	Check all cable connections. Reduce weight on the desk. Reset the system by unplugging for 30 seconds and plugging back in.
Uneven height adjustment.	Obstruction, uneven load.	Clear any obstructions. Distribute weight evenly on the desk.
Anti-collision sensor triggers frequently.	Sensitive setting, nearby objects.	Ensure no objects are near the desk's path. Refer to the full manual for sensitivity adjustment if available.
Noise during operation.	Loose components, normal motor sound.	Tighten any loose screws. The motor operates below 55 dB, which is considered quiet.

8. SPECIFICATIONS

Feature	Detail
Brand	JUMMICO
Model Number	0183
Color	Black
Product Dimensions (L x W x H)	160 x 70 x 73-118 cm
Adjustable Height Range	73 cm to 118 cm
Item Weight	22 Kilograms
Material (Base)	Metal
Material (Top)	Engineered Wood (Laminated)
Motor Noise Level	Below 55 dB
Special Features	Electric Height Adjustment, USB Charging Port, Memory Presets, Anti-Collision Function, Sedentary Reminders, Cable Management

9. WARRANTY AND SUPPORT

JUMMICO products are designed for durability and performance. For specific warranty details, product support, or to inquire about replacement parts, please refer to the warranty card included with your purchase or contact JUMMICO customer service through the retailer where the product was purchased.

Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question