

IVIGA VHD01RB

IVIGA Pull Down Faucet Sprayer Head Replacement

Model: VHD01RB

1. OVERVIEW

This manual provides instructions for the installation, operation, and maintenance of your IVIGA Pull Down Faucet Sprayer Head Replacement. This product is designed to replace existing faucet sprayer heads, offering three distinct spray functions and broad compatibility with various faucet brands.

2. PRODUCT FEATURES

- **3-Function Spray Modes:** Easily switch between Stream (2.5 GPM), Spray (2.8 GPM), and Aquablade Sweep (1 GPM) modes. The Aquablade sweep mode provides a powerful blade of water for effective cleaning.
- **Wide Compatibility:** Includes 9 connector adapters to fit most major faucet brands such as Moen, Delta, Kohler, GIMILI, Hansgrohe, and Grohe. Designed for G1/2 Male Connection.
- **Easy Installation:** Features a simple thread design for quick, tool-free replacement.
- **Durable Construction:** Made from engineering-grade ABS plastic with an Oil Rubbed Bronze finish, ensuring durability and resistance to daily rust and tarnishing.
- **Removable and Washable Aerator:** The aerator can be easily removed and cleaned using the included gadget to maintain optimal water flow and hygiene.

9 ADAPTER KIT FOR UNIVERSAL USE



Figure 1: Three distinct spray modes for versatile cleaning.

FAUCET HEAD FEATURE

choose one fitted
connector

Oil Rubbed
Bronze Finish

Rust Corrosion
Resistant

high quality ABS
for durable use

keep pressing for
aquablade mode

push for stream
mode

push for spray
mode




Figure 2: Oil Rubbed Bronze finish with a premium aerator to prevent splashing.



Oil Rubbed Bronze Finish

Perfectly match your faucet



Premium Aerator
No Water Splashing

Figure 3: Key features and controls of the faucet sprayer head.

PRODUCT SIZE

Universal length, suitable for most families



Figure 4: Product dimensions for compatibility assessment.

3. SETUP & INSTALLATION

The IVIGA Pull Down Faucet Sprayer Head is designed for straightforward installation without the need for specialized tools. Follow these steps to replace your old sprayer head:

1. **Remove Old Sprayer Head:** Unscrew your existing faucet sprayer head from the hose.
2. **Select Adapter:** Identify the correct adapter from the included 9-piece kit that matches your faucet hose connection. The kit includes various sizes to ensure broad compatibility.
3. **Attach Adapter:** Screw the selected adapter onto the faucet hose. Ensure a snug fit to prevent leaks.
4. **Install New Sprayer Head:** Screw the new IVIGA sprayer head onto the adapter. Hand-tighten until secure.
5. **Test for Leaks:** Turn on the water supply and check for any leaks around the connection points. Tighten if necessary.

Your browser does not support the video tag. Please update your browser.

Video 1: Official installation guide for the iVIGA Pull Down Faucet Sprayer Head Replacement.

Your browser does not support the video tag. Please update your browser.

Video 2: Demonstration of the Faucet Sprayer Head Replacement features and ease of use.



Figure 5: The 9-in-1 adapter kit ensures compatibility with most kitchen sink faucets.

4. OPERATING INSTRUCTIONS

Your iVIGA faucet sprayer head features three distinct spray modes for various tasks. To switch between modes, simply press and release the button located on the side of the sprayer head.

- **Stream Mode:** Ideal for filling pots and general washing with a steady flow of water.
- **Spray Mode:** Provides a wider spray pattern for rinsing dishes and produce.
- **Aquablade Sweep Mode:** Delivers a powerful blade of water, perfect for dislodging stubborn food debris and cleaning the sink basin.

9 ADAPTER KIT FOR UNIVERSAL USE



Figure 6: Visual representation of the three spray functions.

5. MAINTENANCE

To ensure optimal performance and longevity of your faucet sprayer head, regular maintenance is recommended, especially cleaning the aerator.

1. **Remove Aerator:** Use the provided orange gadget to unscrew and remove the aerator from the sprayer head.
2. **Clean Aerator:** Rinse the aerator under running water to remove any mineral deposits or debris. For stubborn buildup, soak the aerator in a vinegar solution for a few minutes before scrubbing gently with a soft brush.
3. **Reinstall Aerator:** Once clean, screw the aerator back into the sprayer head using the gadget. Do not overtighten.

Regular cleaning helps prevent clogs and maintains consistent water flow.

VERSATILE TO MEET DAILY NEEDS

Stream(2.5GPM) Spray(2.8GPM) Aquablade Sweep(1GPM)



2.5GPM



2.8GPM



1GPM

Supply the demand different cleaning purposes in daily life, kitchen work more convenient

Figure 7: Detachable and washable aerator for easy cleaning.

6. TROUBLESHOOTING

If you encounter any issues with your IVIGA faucet sprayer head, refer to the following common problems and solutions:

- **Low Water Pressure:** Check if the aerator is clogged. Refer to the Maintenance section for cleaning instructions. Ensure the water supply valves are fully open.
- **Leaking from Connection:** Ensure the adapter and sprayer head are securely tightened. Check if the rubber washers (O-rings) are properly seated and not damaged. Replace if necessary.
- **Difficulty Switching Modes:** Ensure the button is pressed firmly. If the mechanism feels stiff, mineral buildup might be affecting it. Try cleaning the exterior of the sprayer head.
- **Incompatible Fit:** Double-check that you have selected the correct adapter from the 9-piece kit for your specific faucet hose connection. Not all faucets are compatible, especially those with curved shapes or non-standard connections.

If problems persist, please contact customer support.

7. SPECIFICATIONS

Attribute	Value
Brand	IVIGA
Model Number	VHD01RB
Material	ABS Plastic
Finish Type	Oil Rubbed Bronze
Maximum Flow Rate	2.8 Gallons Per Minute
Connection Type	G1/2 Male Conn

8. WARRANTY & SUPPORT

This product comes with a standard return policy allowing for refund or replacement within 30 days of purchase. For any questions, concerns, or warranty claims, please contact IVIGA Home customer service through the retailer where the product was purchased.

Manufacturer: KaiPingShiJiaDunWeiYuYouXianGongSi

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question