

[Manuals.plus](#) /

› [Dell](#) /

› Dell 14 Plus Laptop DB14250 User Manual

Dell DB14250

Dell 14 Plus Laptop DB14250 User Manual

Model: DB14250

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Dell 14 Plus Laptop DB14250. Please read this manual thoroughly to ensure optimal performance and longevity of your device.



Figure 1: Dell 14 Plus Laptop DB14250

2. INITIAL SETUP

2.1. Unboxing and Contents

Carefully unpack your Dell 14 Plus Laptop and verify all components are present:

- Dell 14 Plus DB14250 Laptop
- 65W Type-C Adapter
- Power Cord
- Documentation

2.2. Connecting to Power

Connect the 65W Type-C adapter to the laptop's USB-C port and then to a power outlet. The laptop is designed for

optimal performance when connected to power.

2.3. First Power On

Press the power button located on the keyboard to turn on your laptop. Follow the on-screen instructions to complete the initial Windows 11 setup.



Figure 2: Windows 11 Operating System

3. OPERATING YOUR LAPTOP

3.1. Key Features

- **Intel Core Ultra Processors:** Experience enhanced performance for AI-driven tasks and efficient multitasking.
- **2.5K Display:** Enjoy crisp and vibrant visuals on the 14-inch 2.5K (2560x1600) display.
- **Backlit Keyboard:** Work comfortably in various lighting conditions with the illuminated keyboard.
- **Copilot Key:** Access AI assistance quickly with the dedicated Copilot key.





Figure 3: Backlit Keyboard Detail

3.2. Ports and Connectors

Your Dell 14 Plus Laptop is equipped with various ports for connectivity:

- **Thunderbolt™ 4 (40 Gbps) with DisplayPort™ 2.1 and Power Delivery:** For high-speed data transfer, video output, and charging.
- **USB 3.2 Gen 2 (10 Gbps) Type-C® port with DisplayPort™ 1.4 and Power Delivery:** Versatile port for data, video, and power.
- **HDMI 2.1:** For connecting to external displays.
- **USB 3.2 Gen 1 Type-A (5 Gbps):** Standard USB port for peripherals.
- **Headset Jack:** For audio input/output.




Live captions

Instantly translate* your video calls or movies from any app or video platform into English subtitles, in real time.

**From 44 languages into English.*

Figure 4: Right Side Ports



Recall

Using simple prompts and natural language, Recall* instantly scans apps, files, emails and websites you've seen before to retrieve exactly the content you're looking for.

Figure 5: Left Side Ports

3.3. AI-Powered Experiences

Leverage the Intel Core Ultra processors for enhanced AI features:

- **Recall:** Instantly find content you've seen using simple prompts.
- **Live Captions:** Translate audio into English subtitles in real-time.
- **Cocreator:** Generate custom images from text prompts.
- **Windows Studio Effects:** Enhance video calls with AI-powered camera and audio effects.




Figure 6: Windows 11 Recall Feature




Figure 7: Live Captions




Figure 8: Cocreator AI Tool



Figure 9: Windows Studio Effects

4. MAINTENANCE AND CARE

To maintain your Dell 14 Plus Laptop in optimal condition:

- Keep the laptop clean by wiping surfaces with a soft, lint-free cloth.

- Avoid exposing the laptop to extreme temperatures or direct sunlight.
- Ensure proper ventilation by not blocking air vents.
- Regularly back up your data to prevent loss.
- Keep software and drivers updated for security and performance.

5. TROUBLESHOOTING

If you encounter issues with your Dell 14 Plus Laptop, consider the following basic troubleshooting steps:

- **No Power:** Ensure the power adapter is securely connected to both the laptop and a working power outlet.
- **Display Issues:** Check external display connections if applicable. Try adjusting brightness settings.
- **Slow Performance:** Close unnecessary applications, check for malware, or restart the system.
- **Connectivity Problems:** Verify Wi-Fi and Bluetooth settings. Restart your router if network issues persist.

For more advanced issues, refer to Dell's official support website or contact customer service.

6. SPECIFICATIONS

Feature	Detail
Brand	Dell
Model Name	Dell DB14250 Laptop
Screen Size	14 Inches
Resolution	2560x1600 (2.5K)
CPU Model	Intel Core Ultra 7 258V
RAM Memory Installed Size	32 GB LPDDR5X (8533 MHz)
Hard Disk Size	1 TB SSD
Graphics Coprocessor	Intel Arc Graphics
Operating System	Windows 11 Home
Special Feature	Anti Glare Coating, Backlit Keyboard, HD Audio
Connectivity Technology	Bluetooth 5.4, Wi-Fi 7
Total USB Ports	3 (including Thunderbolt 4 and USB 3.2 Gen 2 Type-C)
HDMI Ports	1
Item Weight	3.4 Pounds
Item Dimensions L x W x Thickness	8.9"L x 12.36"W x 0.67"Th

7. WARRANTY AND SUPPORT

7.1. Warranty Information

Your Dell 14 Plus Laptop DB14250 comes with a **1 Year Mail-in-service** warranty. Additionally, it includes **6 Months Dell Migrate** service to assist with data transfer to your new PC.

7.2. Dell Technologies - Sustainability

Dell is committed to circular design, utilizing recycled and repurposed materials in their products. This commitment helps protect the planet and future generations.

Your browser does not support the video tag.

Video 1: Dell Technologies - Sustainability. This video highlights Dell's commitment to using recycled and repurposed materials in product design.

7.3. Product Overview

For a visual overview of the Dell 14 Plus DB14250, including its design and features, please watch the official product video:

Your browser does not support the video tag.

Video 2: Dell 14 Plus DB14250. This video provides a general overview of the Dell 14 Plus Laptop DB14250, showcasing its design and key functionalities.

© 2025 Dell Technologies. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

