Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wielio e19b489f-8ce1-47f9-9e0a-3493331c7c70

Wielio Android 12 Tablet PC 10 inch User Manual

Model: e19b489f-8ce1-47f9-9e0a-3493331c7c70

Introduction

This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your Wielio Android 12 Tablet PC 10 inch. Please read this manual thoroughly before using your device to ensure optimal performance and longevity.



Image: Front view of the Wielio Android 12 Tablet PC 10 inch, displaying the home screen with various app icons.

Package Contents

Ensure all items are present in the package:

- Wielio Android 12 Tablet PC 10 inch
- Screen Protector
- Charging Cable (Type-C)
- Power Adapter
- User Manual (this document)

Device Overview



Image: Detailed view of the tablet showing the location of the front camera, microphone, power ON/OFF button, volume buttons, rear camera, Type-C port, and TF Card slot.

Buttons and Ports:

- **Power ON/OFF Button:** Press and hold to power on/off or restart the tablet.
- **Volume +/- Buttons:** Adjust the volume level.
- **Front Camera:** For video calls and selfies (5MP).
- **Rear Camera:** For taking photos and videos (8MP).
- **Microphone:** For audio input during calls or recordings.
- **Type-C Port:** For charging and data transfer.

- **TF Card Slot:** For inserting a microSD card to expand storage up to 1TB.

Setup

1. Initial Charge:

Before first use, fully charge the tablet using the provided charging cable and power adapter. The tablet features a 6000mAh fast-charge battery.

2. Power On:

Press and hold the **Power ON/OFF Button** until the screen lights up.

3. Initial Setup Wizard:

Follow the on-screen instructions to complete the initial setup, including:

- Language selection
- Wi-Fi connection (supports 2.4G/5G WiFi)
- Google account sign-in
- Date and time settings

4. Insert TF Card (Optional):

To expand storage, insert a compatible microSD (TF) card into the TF Card Slot. Ensure the tablet is powered off before inserting or removing the card.

Operating Instructions

Navigation:

- **Touchscreen:** Navigate the interface by tapping, swiping, pinching, and spreading on the 10-inch 1920x1200 IPS display.
- **Home Screen:** Access frequently used apps and widgets.
- **App Drawer:** Swipe up from the home screen to view all installed applications.
- **Notifications & Quick Settings:** Swipe down from the top of the screen to access notifications and quick settings toggles.



Image: The tablet displaying a vibrant image, highlighting its 10.1-inch 1920x1200 IPS screen and dual camera capabilities (8MP rear, 5MP front).

Connecting to Wi-Fi:

1. Go to **Settings** > **Network & internet** > **Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network from the list and enter the password if required.

Bluetooth Connectivity:

The tablet supports Bluetooth 5.0 for connecting wireless accessories.

1. Go to **Settings** > **Connected devices** > **Connection preferences** > **Bluetooth**.
2. Toggle Bluetooth **On**.
3. Select the device you wish to pair from the list of available devices.

Using the Cameras:

The tablet is equipped with a 5MP front camera and an 8MP rear camera.

1. Open the **Camera** app.
2. Switch between front and rear cameras using the camera icon.

3. Tap the shutter button to take a photo or start/stop video recording.

Your browser does not support the video tag.

Video: An overview of the Wielio Android 12 Tablet, demonstrating its features, screen quality, and pre-installed applications. The video highlights the tablet's usability and speed for various tasks.

Parental Control:

The tablet includes parental control features to manage usage and content access for children. Refer to the "Kids Space" app or Android settings for configuration.

Maintenance

Cleaning:

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- Avoid using abrasive cleaners or solvents.

Battery Care:

- Avoid extreme temperatures, which can affect battery life.
- Do not leave the tablet fully charged or fully discharged for extended periods.

Software Updates:

Regularly check for system updates to ensure your tablet has the latest features and security patches. Go to **Settings** > **System** > **System update**.




Image: The tablet displaying various popular applications, emphasizing its Android 12 operating system and GMS certification for smooth performance and app compatibility.

Troubleshooting

Problem	Possible Solution
Tablet won't turn on	Ensure the battery is charged. Connect to the charger for at least 30 minutes. If still unresponsive, press and hold the power button for 10-15 seconds to force a restart.
Apps are crashing or freezing	Clear the cache of the problematic app (Settings > Apps > [App Name] > Storage & cache > Clear cache). Restart the tablet. Ensure the app is updated to the latest version.
Wi-Fi connection issues	Restart the tablet and your Wi-Fi router. Forget the network and reconnect. Check if other devices can connect to the Wi-Fi.
Slow performance	Close unused apps running in the background. Clear cache and temporary files. Consider uninstalling rarely used apps. Ensure sufficient storage space is available.

Specifications

Feature	Detail
Brand	Wielio
Model Name	Wielio Android 12 Tablet PC 10 inch
Item Model Number	e19b489f-8ce1-47f9-9e0a-3493331c7c70
Operating System	Android 12
Screen Size	10 Inches
Screen Resolution	1920 x 1200 IPS
Memory (RAM)	6GB
Storage (ROM)	128GB (Expandable up to 1TB via TF Card)
Processor Brand	ARM (Octa-Core)
Wireless Type	802.11ac (2.4G/5G WiFi)
Bluetooth	Bluetooth 5.0
Battery	6000mAh (Fast Charge)
Cameras	Front: 5MP, Rear: 8MP
Item Weight	1.74 pounds
Product Dimensions	9 x 6 x 0.3 inches



Image: Visual representation of the tablet's core features including Octa-Core processor, Android 12, 2.4G+5G WiFi, 6000mAh battery, Bluetooth 5.0, 1TB Expandable storage, GPS, 6GB RAM, 128GB ROM, IPS display, 10.1-inch screen, 1920*1080 resolution, and Parental Control.

Warranty and Support

For warranty information and technical support, please refer to the contact details provided on the product packaging or visit the official Wielio website. Keep your purchase receipt for warranty claims.

Online Support: Visit the Wielio Store on Amazon

© 2024 Wielio. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CHF2DFT2

More documents and user manuals: **https://manuals.plus/**