Haoyijor 001-05A

Instruction Manual for Haoyijor Vacuum Cleaner Attachment

Model: 001-05A

Product Overview

This manual provides detailed instructions for the installation, operation, and maintenance of your Haoyijor Vacuum Cleaner Attachment. This soft roller brush head is designed to enhance the cleaning performance of compatible Dyson vacuum cleaners, particularly on hard floor surfaces.



Image: The Haoyijor soft roller brush head, featuring its main body, soft roller, and quick-release button, along with a small cleaning tool.

Compatibility

The Haoyijor Vacuum Cleaner Attachment is designed for direct compatibility with the following Dyson vacuum cleaner models:

- Dyson V7
- Dyson V8
- Dyson V10
- Dyson V11
- Dyson V15

Note: This attachment is not compatible with Dyson V6, DC, Slim, or Ball Series vacuum cleaners.



Image: A Dyson vacuum cleaner with the Haoyijor attachment, illustrating its compatibility with V7, V8, V10, V11, and V15 models. A note indicates incompatibility with V6, DC, Slim, and Ball series.

Key Features

- **Soft Roller Brush:** Specifically designed for hard floors (glass, tile, marble, wood) to prevent scratches while effectively collecting dust and debris.
- **V-Shaped Brush Design:** Features an enhanced V-shaped brush for superior dust removal and efficient cleaning of stubborn stains.



Image: Close-up of the V-shaped brush head, demonstrating its design for effective dust and stain removal.

- **Integrated LED Lights:** Built-in LED lights illuminate dark corners and under furniture, ensuring no dust or hair is missed.



Image: The brush head with its LED lights illuminated, showing how it brightens dark areas for thorough cleaning.

- **Flexible Maneuverability:** The motor head can pivot 90° left and right, and 180° front and back, allowing for comprehensive cleaning under tables and in tight corners.



Image: Diagrams illustrating the brush head's ability to rotate 180 degrees left and right, and 90 degrees front and back for enhanced maneuverability.

Setup and Installation

To attach the Haoyijor Vacuum Cleaner Attachment to your compatible Dyson vacuum, follow these steps:

1. Ensure your vacuum cleaner is turned off and unplugged.
2. Align the quick-release button on the attachment with the corresponding slot on your Dyson vacuum cleaner wand.
3. Push the attachment firmly onto the wand until it clicks securely into place.

4. To remove, press the quick-release button and pull the attachment away from the wand.

Operating Instructions

Once the attachment is securely installed, you can begin cleaning:

- Turn on your Dyson vacuum cleaner.
- Guide the brush head across the floor surface. The soft roller is ideal for delicate hard floors, preventing scratches.
- Utilize the integrated LED lights to illuminate dark areas, ensuring thorough cleaning under furniture and in corners.
- The flexible pivot mechanism allows you to easily navigate around obstacles and reach tight spaces by rotating the head as needed.



Image: The brush head cleaning a hardwood floor, demonstrating its suitability for various hard surfaces like tile, marble, vinyl, and wood.

Maintenance

Regular maintenance ensures optimal performance and longevity of your Haoyijor Vacuum Cleaner Attachment.

Cleaning the Roller Brush

The roller brush is designed for quick disassembly and washing:

1. **Step 1: Push the buckle.** Locate the quick-release buckle on the side of the brush head and push it to unlock the roller.
2. **Step 2: Take out the roller brush.** Gently pull the roller brush out from the brush head housing.
3. **Step 3: Clean the roller brush.** Rinse the roller brush under running water to remove accumulated dust, hair, and debris. You may use a mild soap if necessary.
4. **Step 4: Dry thoroughly.** Allow the roller brush to air dry completely before reinstallation. Ensure no moisture remains.
5. **Step 5: Install this end facing in.** Reinsert the roller brush into the housing, ensuring the correct end is facing inward.
6. **Step 6: Keep the knob parallel to brush.** Push the roller brush back into place until the buckle clicks, securing it.




Image: A four-panel image demonstrating the steps to remove and reinstall the roller brush: pushing the buckle, taking out the roller, installing the end facing in, and keeping the knob parallel to the brush.



Image: A hand holding the roller brush under running water, illustrating its removable and washable design.

Troubleshooting

Problem	Possible Cause	Solution
Attachment does not fit Dyson vacuum.	Incompatible Dyson model.	Ensure your Dyson model is V7, V8, V10, V11, or V15. This attachment is not compatible with V6, DC, Slim, or Ball series.

Problem	Possible Cause	Solution
Roller brush not spinning.	Hair or debris tangled in brush; brush not properly installed.	Remove and clean the roller brush. Ensure it is reinstalled correctly and clicks into place.
LED lights not working.	No power from vacuum; internal wiring issue.	Ensure the attachment is securely connected to the vacuum. If the issue persists, contact customer support.
Reduced cleaning performance.	Brush is dirty or worn; vacuum suction issue.	Clean the roller brush. Check your Dyson vacuum's filter and bin for clogs.

Specifications

Attribute	Detail
Model Number	001-05A
Brand	Haoyijor
Dimensions (L x W x H)	25.4 x 24.38 x 6.1 cm (10 x 9.6 x 2.4 inches)
Weight	739 grams (1.63 lbs)
Compatibility	Dyson V7, V8, V10, V11, V15 series
Features	Soft roller, V-shaped brush, LED lights, Quick-release design

Warranty and Support

Information regarding specific warranty terms and customer support contact details for the Haoyijor Vacuum Cleaner Attachment is not available in the provided product data. Please refer to the product packaging or the manufacturer's official website for warranty information and customer service inquiries.

© 2023 Haoyijor. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question