ALLIMITY CV-KKG9A-C1-SH

Instruction Manual for ALLIMITY Replacement A/C Remote Control

Model: CV-KKG9A-C1-SH (Compatible with KKG9A-C1, KKG9B-C1, KKG9B-C2)

Brand: ALLIMITY

Introduction

This manual provides detailed instructions for the ALLIMITY KKG9A-C1 KKG9B-C2 Replacement Remote Control. This remote is designed to be a direct replacement for original remote controls of Mirage, Agratto, and Changhong A/C Air Conditioners that use the KKG9B-C1, KKG9A-C1, or KKG9B-C2 models. Please read this manual carefully before use to ensure proper operation and longevity of your remote control.

Product Overview



Front view of the ALLIMITY replacement remote control, showing the display screen and all buttons clearly labeled.



Rear view of the remote control with the battery compartment cover removed, showing slots for two AAA batteries.



An illustrative image highlighting the remote control's compatibility with Mirage, Agratto, and Changhong Air Conditioners, along with its model numbers KKG9A-C1 and KKG9B-C2.

Setup

1. Battery Installation

The remote control requires two (2) AAA batteries for operation. Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: *Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage. Do not mix old and new batteries, or different types of batteries.*

2. Initial Setup / Pairing

This ALLIMITY replacement remote control is designed to work out of the box with compatible Mirage, Agratto, and Changhong A/C Air Conditioners (models KKG9B-C1, KKG9A-C1, KKG9B-C2). **No programming or pairing is required.** Simply insert the batteries, and the remote is ready for use.

Operating Instructions

Familiarize yourself with the buttons on your remote control:

- **Power:** Turns the air conditioner ON or OFF. This button is typically red and located at the top-left.
- **Display:** Toggles the display on the air conditioner unit.
- **Sleep:** Activates or deactivates the sleep mode, which adjusts temperature for comfortable sleep and saves energy.
- **Swing:** Controls the vertical swing of the air conditioner's louvers.
- **Mode:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temp ▲ / ▼:** Adjusts the desired temperature setting. These are typically green arrow buttons.
- **Turbo:** Activates the rapid cooling/heating function for quick temperature changes.
- **Fan:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Hour:** Used for setting the timer in hours.
- **Timer:** Sets the ON/OFF timer for the air conditioner.
- **Lock:** Locks the remote control buttons to prevent accidental changes.
- **Minu:** Used for setting the timer in minutes.
- **Settime:** Confirms time settings for the timer.
- **Quiet:** Activates a low-noise operation mode.
- **Reset:** Resets the remote control to its default settings. This is often a small recessed button requiring a pointed object to press.

Maintenance

Battery Replacement

Replace batteries when the remote control's range decreases or if the display becomes dim. Always replace both batteries at the same time with new AAA alkaline batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**
  - Check if batteries are inserted correctly with correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Verify that the remote is pointed directly at the air conditioner unit.
- **Remote works intermittently:**
  - Batteries may be low; replace them.

- Ensure the remote is within effective operating range (typically up to 8 meters).

- **Remote does not control my A/C unit:**
  - This remote is specifically designed for Mirage, Agratto, and Changhong A/C Air Conditioners that originally used KKG9B-C1, KKG9A-C1, or KKG9B-C2 model remotes. Please verify your original remote's model number or your A/C unit's compatibility.
  - While this remote is a replacement, some specific functions or advanced features of your original unit might not be fully supported if they are unique to your original remote's programming.

Specifications

Feature	Detail
Model Number	CV-KKG9A-C1-SH
Compatible Models	KKG9B-C1, KKG9A-C1, KKG9B-C2
Brand	ALLIMITY
Product Dimensions	6.5 x 1.38 x 0.72 inches
Item Weight	2.39 ounces
Color	Black
Power Source	2 x AAA Batteries (not included)
Special Feature	No Programming Required

Warranty and Support

For any issues or inquiries regarding your ALLIMITY replacement remote control, please contact the seller or manufacturer directly through your purchase platform. Please refer to your purchase receipt for specific warranty details, if applicable.
For general troubleshooting or operational questions, refer to the relevant sections of this manual.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question