

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Anker](#) /

> [Anker Nano Charging Station \(100W Max\) 7-in-1 USB C Power Strip User Manual](#)

## Anker A91C4

# Anker Nano Charging Station (100W Max) 7-in-1 USB C Power Strip User Manual

Brand: Anker | Model: A91C4

## 1. INTRODUCTION

---

Thank you for choosing the Anker Nano Charging Station. This 7-in-1 USB C Power Strip is designed to provide efficient and safe power delivery for a wide range of devices, including smartphones, tablets, and laptops. With its compact design and versatile port selection, it helps keep your workspace organized and your devices charged.

## 2. PRODUCT FEATURES

---

- **Tidy Up Your Space:** Features 4 USB ports at the front and a sleek AC cord to maintain a clutter-free and organized workstation.
- **100W Full-Speed Charging:** Delivers exceptional charging speed, powering your MacBook Pro 16" (96W) to 50% in approximately 33 minutes.
- **One Charging Station, Seven Devices:** Equipped with two USB-C and two USB-A ports on the front, plus three AC outlets at the back, ensuring all your devices remain powered.
- **Safety Beyond Standards:** Incorporates Anker's proprietary ActiveShield safety system, which rigorously monitors temperature 3,000,000 times daily to keep your devices safe.

## 3. PACKAGE CONTENTS

---

The Anker Nano Charging Station package includes:

- Anker Nano Charging Station (7-in-1, 100W)
- Welcome Guide

## 4. SETUP INSTRUCTIONS

---

### 4.1 Connecting to Power

1. Uncoil the integrated 5ft (1.5m) power cord from the charging station.
2. Plug the 3-prong power plug into a standard AC wall outlet.
3. The power indicator light on the station will illuminate, confirming it is receiving power.

## 4.2 Connecting Your Devices

The Anker Nano Charging Station offers a variety of ports for your devices:

- **USB-C Ports (2):** For fast charging compatible devices like MacBook Pro/Air, iPhone 16/15/14, and Samsung Galaxy S23 Ultra.
- **USB-A Ports (2):** For charging devices that use standard USB-A cables.
- **AC Outlets (3):** Located on the back, these are for plugging in larger appliances or chargers that require a standard wall plug.

Simply connect your device's charging cable to the appropriate port on the charging station.

# Eliminate Desk Clutter



Image: The Anker Nano Charging Station helps organize your desk by consolidating multiple chargers into one sleek unit, reducing cable clutter.

Your browser does not support the video tag.

Video: An unboxing and overview of the Anker 7-in-1 Charging Station, demonstrating its compact size and various ports for connecting devices.

## 5. OPERATING INSTRUCTIONS

### 5.1 Charging Your Devices

The Anker Nano Charging Station intelligently adjusts power output to match your connected devices, ensuring optimal charging speed and safety.

# USB-C High-Power Charging




Image: The Anker Nano Charging Station delivers 100W USB-C high-power charging, capable of charging a MacBook Pro 16" to 50% in 33 minutes.

## 5.2 Power Distribution (USB Ports)

The 2 USB-C ports do not have a fixed output; power is automatically allocated based on the connected device. Below are typical power distributions:



Image: Diagram showing single-port charging scenarios, with USB-C ports delivering up to 100W Max and USB-A ports up to 12W Max.



Image: Diagram illustrating power distribution when two USB ports are used simultaneously, showing various wattage combinations for USB-C and USB-A.



Image: Diagram detailing power distribution when three USB ports are in use, indicating dynamic wattage allocation across USB-C and USB-A ports.



Image: Diagram showing power distribution when all four USB ports are utilized, with wattage adjusted for optimal charging of multiple devices.

## 6. SAFETY INFORMATION

---

The Anker Nano Charging Station is equipped with the proprietary ActiveShield safety system to protect your devices. This system continuously monitors temperature to prevent overheating.

- Do not expose the device to liquids, extreme temperatures, or direct sunlight.
- Avoid dropping or subjecting the device to strong impacts.
- Do not disassemble or attempt to repair the device yourself.

- Ensure proper ventilation when in use; do not cover the device.
- Use only indoors and in dry locations.

## 7. MAINTENANCE

---

- To clean the charging station, disconnect it from the power outlet and use a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- Store the device in a cool, dry place when not in use.

## 8. TROUBLESHOOTING

---

- **Device not charging:** Ensure the charging station is properly plugged into a live wall outlet. Check that the device's charging cable is securely connected to both the station and the device.
- **Slow charging:** Verify that your device and cable support fast charging. If multiple devices are connected, the power output may be distributed, potentially reducing individual charging speeds.
- **Power indicator not lit:** Confirm the charging station is plugged into a functional power outlet. If the issue persists, contact customer service.

## 9. SPECIFICATIONS

---

Specification	Detail
Product Dimensions	4.61 x 2.52 x 1.73 inches
Item Weight	1.3 pounds
Item Model Number	A91C4
Connector Type	Proprietary, USB Type A, USB Type C
Input Voltage	240 Volts
Total USB Ports	4
Wattage	100 watts (Max)
Special Feature	Fast Charging
Color	Black

## 10. WARRANTY AND SUPPORT

---

Your Anker Nano Charging Station comes with an 18-month warranty and a lifetime\* \$25,000 connected equipment warranty. For any inquiries or support, please refer to the contact information provided in your Welcome Guide or visit the official Anker website. Our friendly customer service team is ready to assist you.

