

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Costzon](#) /
- › [Costzon Kids 3-in-1 Art Easel Instruction Manual - Model B0CHF8HSL](#)

### Costzon B0CHF8HSL

# Costzon Kids 3-in-1 Art Easel Instruction Manual

Model: B0CHF8HSL

## 1. INTRODUCTION AND OVERVIEW

The Costzon Kids 3-in-1 Art Easel is designed to provide a versatile and engaging creative space for children. This easel features a double-sided drawing board, offering both a magnetic whiteboard and a chalkboard, along with a convenient pull-down paper roll. It also includes integrated storage solutions to keep art supplies organized.



Image: The Costzon Kids 3-in-1 Art Easel in pink, demonstrating its three primary functions: whiteboard, chalkboard, and pull-down paper roll.

## 2. PACKAGE CONTENTS

Please ensure all components are present before beginning assembly. The package includes:

- 1 x Double-Sided Art Easel Frame
- 1 x Drawing Paper Roll (16.5 ft)
- 2 x Magnetic Beads
- 2 x Fabric Storage Bins
- 2 x Anti-Spill Paint Cups with Covers
- Assembly Hardware (screws, etc.)
- Instruction Manual



Image: A visual representation of the included accessories: a paper roll, two paint cups with covers, and two fabric storage bins.

## 3. ASSEMBLY INSTRUCTIONS

The Costzon Kids Art Easel is designed for quick and straightforward assembly. Follow the detailed instructions provided in the included manual. Ensure all screws are securely tightened for stability.

Key assembly features include:

- **A-shape Structure:** Provides enhanced stability for safe use.
- **Hidden Screws:** Designed for a smooth finish and child safety.
- **Replaceable Paper Roll Holder:** Allows for easy changing of paper rolls.



Image: Detailed view of the easel's construction, highlighting the stable A-shape, hidden screws, and the replaceable paper roll mechanism.

## 4. OPERATING INSTRUCTIONS

### 4.1. Whiteboard Use

The whiteboard surface is suitable for use with dry-erase markers. It is also magnetic, allowing children to attach papers or magnetic letters using the included magnetic beads.

### 4.2. Chalkboard Use

The chalkboard surface is designed for use with standard chalk. Ensure to use a chalkboard eraser or a

damp cloth for cleaning.

### 4.3. Paper Roll Functionality

The easel includes a pull-down paper roll (16.5 ft). To use, simply pull down the desired length of paper over either the whiteboard or chalkboard surface. Secure the paper with the magnetic beads if using the whiteboard side, or use clips (not included) if preferred.

### 4.4. Storage Features

The easel is equipped with two trays located under the drawing boards for easy access to markers, chalk, or other small art supplies. Additionally, two 2-tier storage shelves with two fabric storage bins are provided at the base for organizing larger items like paint brushes, extra paper, or toys.



Image: The easel's storage capabilities, including three upper storage trays and two large fabric bins on the lower shelves.

## 5. MAINTENANCE AND CARE

To ensure the longevity of your Costzon Kids Art Easel, follow these maintenance guidelines:

- **Initial Setup:** Before first use, tear off the protective film on the surface of the whiteboard.
- **Cleaning Surfaces:** The whiteboard can be cleaned with a dry-erase eraser or a damp cloth. The

chalkboard can be cleaned with a chalkboard eraser or a slightly damp cloth.

- **Paint Cups:** The anti-spill paint cups are designed for easy cleaning after use.
- **General Cleaning:** Wipe down the wooden frame with a soft, damp cloth as needed. Avoid abrasive cleaners.
- **Paper Roll Replacement:** The paper roll holder is designed for easy replacement. Unscrew the end caps to change the roll.



Image: Visual guide on removing the protective film from the whiteboard and demonstrating how to clean both the whiteboard and chalkboard surfaces with an eraser.

## 6. SPECIFICATIONS

Feature	Detail
Product Dimensions	23.5"D x 46"W x 19.5"H
Material	Engineered Wood, Fabric
Item Weight	22 Pounds

Easel Type	A Frame Easel
Assembly Required	Yes
Recommended Age	Over 3 years old



Image: A diagram illustrating the various dimensions of the art easel, including height, width, and depth, suitable for children over 3 years old.

## 7. TROUBLESHOOTING

If you encounter any issues with your Costzon Kids Art Easel, please refer to the following common solutions:

- **Stability Issues:** Ensure all screws are tightened according to the assembly instructions. Check that the easel is placed on a flat, stable surface.
- **Whiteboard Marks:** If dry-erase marks are difficult to remove, try using a specialized whiteboard cleaner or a small amount of rubbing alcohol on a soft cloth.
- **Chalkboard Residue:** For stubborn chalk residue, wipe the board with a damp cloth and allow it to dry completely.

- **Paper Roll Not Dispensing:** Check that the paper roll is correctly installed and not jammed. Ensure the end caps are not overtightened, allowing the roll to spin freely.

## 8. WARRANTY AND SUPPORT

---

For any questions about the product, please contact Costzon customer service for assistance. We are committed to providing a satisfying shopping experience and support for our products.

The product is sold by Costzon, ensuring direct support from the manufacturer.

For further information or to purchase replacement parts, please visit the official [Costzon Store on Amazon](#).