

MONTERAL WL561

MONTERAL Fridge Door Handle User Manual

Model: WL561

1. PRODUCT OVERVIEW

The MONTERAL Fridge Door Handle is a high-quality replacement part designed for Liebherr fridge and freezer appliances. This universal handle is engineered for durability and ease of use, fitting both top and bottom doors. It provides a comfortable grip and robust construction for long-lasting performance.



Image 1.1: The MONTERAL Fridge Door Handle, showing its design and an attached tag with compatibility codes and dimensions.

2. COMPATIBILITY

This fridge door handle is compatible with various Liebherr fridge freezer models. Please verify the original code of your existing handle to ensure proper fit. The handle is designed to replace original parts with the following codes:

- 743260000
- 743260
- 7432600
- 742690900
- 7426909
- 7426942
- 7432716

LIEBHERR



Image 2.1: A Liebherr refrigerator, illustrating the type of appliance this handle is compatible with, alongside a graphic highlighting the compatible original part codes.

3. PRODUCT SPECIFICATIONS

The MONTERAL Fridge Door Handle is manufactured from strong, high-quality plastic, ensuring durability and a long lifespan. Its precise dimensions are crucial for a perfect fit.



Image 3.1: Detailed dimensions of the handle, showing a total length of 210 mm and a hole spacing of 155 mm.

Table 3.1: Technical Specifications

Attribute	Value
Manufacturer	Monteral
Part Number	WL561
Product Dimensions	21 x 15.5 x 15.5 cm
Item Model Number	WL561
Colour	White
Finish	Powder Coated
Material	Plastic
Number of Pieces	1
Handle Material	Plastic

Attribute	Value
Usage	Fridgebox
Item Weight	120 g



Image 3.2: Visual representation emphasizing the strong plastic and high-quality material used in the handle's construction.

4. INSTALLATION GUIDE

The MONTERAL Fridge Door Handle is designed for easy installation, requiring no special tools or professional skills. Follow these general steps for replacement:

- 1. Preparation:** Ensure the refrigerator door is stable and accessible. You may need to slightly open the door for better access to the handle's mounting points.
- 2. Remove Old Handle:** Locate the screws or fasteners securing the old handle. Carefully unscrew them using an appropriate screwdriver (e.g., flathead or Phillips, depending on your appliance). Keep the screws if they are reusable.
- 3. Clean Mounting Area:** Once the old handle is removed, gently clean the area where the new handle

will be mounted to ensure a secure fit.

4. **Position New Handle:** Align the new MONTERAL handle with the existing mounting holes on the refrigerator door.
5. **Secure New Handle:** Insert the screws through the handle's mounting holes and into the door. Tighten the screws firmly but do not overtighten, as this could damage the plastic or the door.
6. **Test:** Gently pull on the new handle to ensure it is securely attached and functions correctly.



Image 4.1: An illustration of the easy installation process, showing a hand using a screwdriver to secure the handle.

5. CARE AND MAINTENANCE

To ensure the longevity and appearance of your MONTERAL Fridge Door Handle, follow these simple care instructions:

- **Cleaning:** Wipe the handle regularly with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the plastic finish.
- **Drying:** After cleaning, dry the handle thoroughly with a clean, dry cloth to prevent water spots.
- **Inspection:** Periodically check the handle's mounting screws to ensure they remain tight. If they become loose, gently retighten them.

6. TROUBLESHOOTING

While the MONTERAL Fridge Door Handle is designed for durability, here are some common issues and their potential solutions:

- **Handle Feels Loose:**

- Check the mounting screws. They may have loosened over time. Gently tighten them with a screwdriver.
- Ensure the handle is correctly aligned with the mounting points.

- **Handle is Cracked or Broken:**

- If the handle is physically damaged, it will need to be replaced. Refer to the "Installation Guide" section for replacement steps.

- **Difficulty Opening Door:**

- Ensure the handle is securely attached and not obstructing the door's movement.
- This issue is typically related to the refrigerator's door seal or hinges, not the handle itself. Consult your refrigerator's manual for further troubleshooting.

7. WARRANTY AND SUPPORT


The MONTERAL Fridge Door Handle comes with a **10-year warranty**, reflecting our commitment to quality and durability. This warranty covers manufacturing defects and ensures peace of mind.

If you have any questions regarding the product, its compatibility, installation, or require assistance with selecting a replacement part, please do not hesitate to contact MONTERAL customer support. Our specialists are available to assist you.

For support, please refer to the contact information provided with your purchase or visit the official MONTERAL store page on Amazon.

© 2024 MONTERAL. All rights reserved.

Related Documents - WL561





Monterál Drain Pump for Bosch & Siemens Dishwashers - BLP3 01/003 475.190 54V 55Hz

Technical overview of the Monterál BLP3 01/003 475.190 54V 55Hz drain pump, compatible with Bosch and Siemens dishwashers. Includes product codes 00620774 and 620774, specifications, and application details.