

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [NautyPaws](#) /

> [NautyPaws 108oz/3.2L Stainless Steel Automatic Pet Water Fountain Instruction Manual](#)

NautyPaws G108-4-4

NautyPaws 108oz/3.2L Stainless Steel Automatic Pet Water Fountain Instruction Manual

Model: G108-4-4

PRODUCT OVERVIEW

The NautyPaws Automatic Pet Water Fountain is designed to provide fresh, filtered water for pets. Constructed from 304 stainless steel, it offers durability and ease of cleaning. The fountain features a large capacity, a visible water level window, and a double filtration system to ensure water quality. Its ultra-quiet pump operates with minimal disturbance.

Key Features:

- **Stainless Steel Construction:** Entirely made of 304 stainless steel, resistant to rust and corrosion. Stainless steel parts are dishwasher safe for easy cleaning.
- **Transparent Water Level Window:** A 3.2L (108oz) capacity with marked high and low water level lines allows for easy monitoring of water volume without opening the unit. An integrated blue LED light enhances visibility in various lighting conditions.
- **Double Filtration System:** Equipped with an activated carbon filter and a replaceable round filter sponge. The external foam filter captures impurities and hair, while the activated carbon filter removes odors and softens water, improving taste.
- **Ultra-Quiet Water Pump:** Features a pump operating below 20dB with 1.5W low power consumption, ensuring a quiet environment for both pets and owners.
- **Encourages Water Drinking:** Dynamic, 360° multi-directional water flow aerates the water, increasing oxygen and freshness, which can encourage pets to drink more.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components are present: stainless steel base, stainless steel top tray, water pump, foam filter, activated carbon filter, and power adapter.
2. **Clean Components:** Wash all stainless steel parts (base and top tray) thoroughly with soap and

water or place them in a dishwasher. Rinse the water pump, foam filter, and activated carbon filter under running water.

3. Assemble Pump and Filters:



Image: Exploded view showing the individual components of the NautyPaws pet water fountain, including the stainless steel base, top tray, water pump, pre-filter sponge, and activated carbon filter.

- Attach the round foam filter to the bottom of the water pump.
 - Insert the activated carbon filter into its designated compartment on the underside of the top tray.
4. **Place Pump Assembly:** Position the water pump assembly into the designated area on the underside of the top tray. Ensure the suction cups on the pump are securely attached to the tray.
 5. **Route Power Cord:** Guide the power cord through the small channel on the side of the top tray to ensure a snug fit when the lid is placed.
 6. **Fill with Water:** Place the stainless steel base on a flat, stable surface. Fill the base with clean water, ensuring the water level is between the 'MIN' and 'MAX' lines indicated inside the base.

VISIBLE WATER LEVEL

Easy to monitor the water level at a glance
Unable to observe water level



Unable to observe
water level

Image: The NautyPaws pet water fountain highlighting the transparent water level window and the 'MIN' and 'MAX' indicators inside the stainless steel base.

7. **Place Top Tray:** Carefully place the assembled top tray onto the stainless steel base, aligning the edges. Ensure the power cord is properly routed and not pinched.
8. **Connect Power:** Plug the power adapter into a standard electrical outlet. The fountain will begin operating, and the blue LED light in the water level window will illuminate.

Visual Setup Guide:

Your browser does not support the video tag.

Video: A step-by-step demonstration of assembling the NautyPaws Cat Water Fountain, including placing filters, pump, and filling with water.

Once assembled and plugged in, the NautyPaws Pet Water Fountain will immediately begin circulating water. The pump continuously draws water from the base, filters it, and dispenses it through the faucet, creating a flowing stream.

- **Water Flow:** The fountain provides a dynamic water flow that encourages pets to drink. Some pets may prefer drinking directly from the flowing stream, while others may drink from the pooled water in the top tray.
- **Water Level Monitoring:** The transparent water level window on the front of the base, illuminated by a blue LED light, allows for easy visual monitoring of the water volume. Refill water when it approaches the 'MIN' line.
- **Quiet Operation:** The ultra-quiet pump ensures that the fountain operates discreetly, minimizing noise disturbance in your home.



Image: A cat drinking from the NautyPaws pet water fountain, illustrating the fountain's appeal to pets and its large water capacity.

ULTRA QUIET

Operates quietly without disturbing the life and sleep of you and your pets




Image: A cat sleeping undisturbed next to the NautyPaws pet water fountain, emphasizing the product's ultra-quiet operation.

MAINTENANCE

Regular cleaning and filter replacement are essential to maintain optimal performance and water quality.

Cleaning:

- **Disassembly:** Unplug the fountain and disassemble all components (top tray, base, pump, filters).
- **Stainless Steel Parts:** The stainless steel base and top tray can be washed by hand with mild soap and water or placed in a dishwasher for thorough cleaning.

- **Pump Cleaning:** Disassemble the pump and clean any debris or hair from the impeller and pump housing. Rinse thoroughly.
- **Filter Cleaning:** Rinse the foam filter and activated carbon filter under running water to remove trapped debris.
- **Reassembly:** Reassemble all components after cleaning, ensuring they are dry and correctly positioned.

BPA-Free & Dishwasher Safe

Easy to take apart for more thorough cleaning



Image: The stainless steel base and top tray of the NautyPaws pet water fountain placed in a dishwasher, demonstrating their dishwasher-safe feature.

Filter Replacement:

- **Activated Carbon Filter:** Replace the activated carbon filter every 2-4 weeks, or more frequently depending on water quality and pet usage.
- **Foam Filter:** Replace the foam filter every 2-4 weeks, or when visibly dirty.
- Regular replacement ensures optimal filtration and pump longevity.

TROUBLESHOOTING

If you encounter issues with your NautyPaws Pet Water Fountain, consider the following:

- **No Water Flow:**

- Ensure the power adapter is securely plugged into both the fountain and the electrical outlet.
- Check the water level; the pump requires sufficient water to operate. Refill if below the 'MIN' line.
- Disassemble and clean the pump, especially the impeller, to remove any blockages from hair or debris.

- **Loud Noise:**

- Ensure the water level is above the 'MIN' line. Low water levels can cause the pump to run dry and make noise.
- Clean the pump and filters thoroughly. Accumulated debris can affect pump operation and increase noise.
- Ensure the top tray is seated correctly on the base.

- **Water Quality Issues (e.g., odor, cloudy water):**

- Replace the activated carbon filter and foam filter.
- Perform a thorough cleaning of all fountain components.

- **LED Light Not Working:**

- Verify the power connection.
- If the pump is working but the light is not, the LED component may require service.

SPECIFICATIONS

Feature	Detail
Brand	NautyPaws
Model Name	cat water fountain
Item Model Number	G108-4-4
Material	Stainless Steel
Color	stainless steel
Capacity	3.2 Liters (108oz)
Power Source	Corded Electric

Item Weight	1.7 pounds
Item Dimensions (LxWxH)	8.4 x 8.4 x 4.8 inches
Target Audience	dogs, house-cats
Age Range Description	All Life Stages
Included Components	cat water fountain (main unit), 4 replacement filters, 4 sponges
Specific Uses for Product	Indoor, Outdoor

WARRANTY & SUPPORT

This product is sold without an explicit manufacturer's warranty. For any product inquiries or support needs, please refer to the seller or retailer from whom the product was purchased.