

ZMISHIBO B0CHJC2V25

ZMISHIBO 19.7-inch Low Profile Ceiling Fan with Dimmable LED Light and Remote - Instruction Manual

[Introduction](#) [Safety Information](#) [Features](#) [Specifications](#) [Setup & Installation](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the ZMISHIBO 19.7-inch Low Profile Ceiling Fan with Dimmable LED Light and Remote. This manual provides detailed instructions for safe installation, operation, and maintenance of your new ceiling fan. Please read this manual thoroughly before installation and keep it for future reference.

2. SAFETY INFORMATION

- Always disconnect power at the circuit breaker before installation or servicing.
- Ensure all electrical connections comply with local codes and ordinances.
- Consult a qualified electrician if you are unsure about wiring or installation.
- Mount the fan securely to a ceiling joist or a suitable support structure capable of holding the fan's weight.
- Do not insert objects into the fan blades while the fan is operating.
- This appliance is for indoor use only.

3. PRODUCT FEATURES

- **2-in-1 Design:** Enclosed modern design protects from fan blades. Lights and fan can be controlled independently or together.
- **LED Light:** 110V output, 10%-100% brightness (3300LM), stepless color temperature from warm (3000K) to white (6500K), with light memory function.
- **APP and Remote Control:** Features 5 blades, 6 fan speeds, and timer settings (1H or 2H). Smart control via remote or app for convenience.
- **Wide Application:** Ultra-low profile installation, ideal for rooms with low ceilings such as bedrooms, living

rooms, kids' rooms, kitchens, studies, and offices.

- **Easy Installation:** Detailed instructions provided for quick and straightforward setup.



Image: The ZMISHIBO low profile ceiling fan with integrated light, showcasing its modern design and compact size.

4. SPECIFICATIONS

Brand	ZMISHIBO
Model Name	19.7inch
Color	Black
Material	Acrylic, Iron, Plastic
Style	Modern
Light Fixture Form	Close to Ceiling (Flush Mount)
Room Type	Bedroom, Dining Room, Home Office, Kids Room, Study Room, Living Room, Kitchen
Indoor/Outdoor Usage	Indoor
Power Source	DC
Special Features	LED Light, Remote Controlled, Timer
Control Method	App, Remote, Wall Switch
Light Source Type	LED
Voltage	120 Volts
Light Color	Warm White to Cool White (3000K - 6500K)
Included Components	Remote Control
Wattage	60 watts
Brightness	3300 Lumen
Product Dimensions	20.4 x 20.4 x 7 inches

Item Weight	6.3 pounds
Number of Speeds	6



Image: Illustration showing the three adjustable color temperatures (3000K, 4500K, 6000K) and dimming range (10%-100%) of the LED light.

5. SETUP & INSTALLATION

The ZMISHIBO ceiling fan is designed for easy installation. Please follow the detailed steps provided in the included installation guide. Ensure all components are present before beginning. A qualified electrician is recommended for installation if you are unfamiliar with electrical wiring.

5.1. Pre-Installation Checklist

- Verify all parts are included in the package.
- Turn off power at the main circuit breaker.
- Ensure the mounting location can support the fan's weight (6.3 lbs).
- Gather necessary tools (screwdriver, wire strippers, ladder, etc.).

5.2. Mounting the Fan

1. Attach the mounting bracket to the ceiling junction box.
2. Connect the electrical wires (live, neutral, ground) according to the wiring diagram in the full manual.
3. Secure the fan assembly to the mounting bracket.



Image: A visual representation of the ceiling fan's components and dimensions, aiding in pre-installation planning.

6. OPERATING INSTRUCTIONS

Your ZMISHIBO ceiling fan can be operated using the included remote control or a dedicated smartphone application.

6.1. Remote Control Functions

- **Power On/Off:** Turn the fan and light on or off.
- **Fan Speed:** Select from 6 fan speeds (1-6).
- **Light On/Off:** Control the LED light independently.
- **Color Temperature Adjustment:** Cycle through warm, neutral, and cool white light (3000K-6500K).
- **Brightness Dimming:** Adjust light brightness from 10% to 100%.
- **Timer Settings:** Set the fan to turn off after 1 or 2 hours.
- **Forward/Reverse Function (F/R):** Change fan direction for summer (downward airflow) or winter (upward

airflow).

- **Code Pair/Setup:** For initial pairing of the remote or app.




Image: The remote control and smartphone app interface for operating the ceiling fan's light and fan functions.

6.2. App Control

Download the "Fanlamp Pro" app from Google Play or the Apple App Store. Follow the in-app instructions to pair your device with the ceiling fan. The app provides all remote control functionalities and may offer additional smart features.

Your browser does not support the video tag.

Video: An official ZMISHIBO video demonstrating the features of the Low Profile Fandelier Ceiling Fan with Light Crystal Design, including light and fan operation.

Your browser does not support the video tag.

Video: A user review demonstrating the remote control functionality of the ceiling fan light, showing how to adjust settings.

7. MAINTENANCE

- **Cleaning:** Before cleaning, ensure the power is off. Use a soft, damp cloth to wipe down the fan and light fixture. Do not use abrasive cleaners or solvents.
- **Blade Cleaning:** Gently wipe the fan blades with a soft cloth to remove dust.
- **Inspection:** Periodically check all connections and mounting hardware to ensure they are secure.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not operate.	No power, loose wiring, remote not paired.	Check circuit breaker. Ensure all wires are securely connected. Pair the remote control with the fan (refer to remote pairing instructions).
Light does not turn on.	No power, loose wiring, LED failure.	Check power supply. Verify wiring connections. If issues persist, contact customer support.
Fan makes excessive noise.	Loose mounting, unbalanced blades.	Ensure mounting screws are tight. Check if blades are securely attached and balanced.

Remote control not working.	Dead batteries, remote not paired, obstruction.	Replace remote batteries. Re-pair the remote with the fan. Ensure no obstructions between remote and fan receiver.
-----------------------------	---	--

Your browser does not support the video tag.

Video: A user demonstrating an issue where the light function of the ceiling fan is not working, despite attempts to use the remote control and app.

9. WARRANTY & SUPPORT

ZMISHIBO provides 2-year support for this product. If you encounter any problems during purchase, installation, or operation, please contact our customer service team. We are committed to working with you to resolve any issues. For warranty claims or technical assistance, please refer to the contact information provided in your purchase documentation or visit the official ZMISHIBO website.

Warranty Type: Limited