

Polardo SCP-220V

Polardo Handheld Portable Travel Garment Steamer (SCP-220V) Instruction Manual

Model: SCP-220V | Brand: Polardo

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the Polardo Handheld Portable Travel Garment Steamer. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- This product is designed for 220V electrical systems ONLY. Do NOT use with 120V sockets or any voltage converters/adapters, as this may cause malfunction or damage to the unit.
- Always unplug the steamer from the electrical outlet immediately after use and before cleaning, filling, or emptying.
- Do not immerse the steamer in water or other liquids.
- Keep the steam head away from your body and hands during operation to avoid burns.
- Do not leave the steamer unattended while it is plugged in or operating.
- Keep out of reach of children.
- Use only tap water. The NANO water filter helps prevent calcification.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Polardo Garment Steamer.



Image: Overview of the Polardo Handheld Portable Travel Garment Steamer, highlighting its magnetic removable water tank, power button, steam button, and included brush attachment. The image also indicates "220V ONLY!" and "EU Stecker" (EU Plug).

- **Steam Head:** Metal plate for wrinkle removal.
- **Water Tank:** Removable, 100ml capacity.
- **Power Button:** To turn the unit on/off.
- **Steam Button:** To activate steam.
- **Power Cord:** With EU plug (220V).
- **Brush Attachment:** For use on delicate fabrics or to remove lint.

SETUP

1. **Fill Water Tank:** Remove the magnetic water tank from the main unit. Open the rubber stopper and fill the tank with clean tap water up to the MAX line (100ml). Close the stopper securely and reattach the tank to the steamer.
2. **Attach Brush (Optional):** For delicate fabrics or to remove lint, attach the brush accessory to the steam head.
3. **Plug In:** Ensure your hands are dry. Plug the steamer into a 220V electrical outlet. The indicator light will illuminate.

OPERATING INSTRUCTIONS

The Polardo steamer heats up quickly and provides continuous steam for effective wrinkle removal.

EINFACHE ANWENDUNG



SCHNELLES
AUFHEIZEN



BIS ZU 10 MINUTEN
KONTINUIERLICHER
DAMPF



Image: A user demonstrating the Polardo steamer on a hanging shirt, illustrating its quick 25-second heat-up time and up to 10 minutes of continuous steam.

1. **Power On:** Press the power button. The steamer will begin to heat up. It typically heats in less than 25 seconds.
2. **Steam Application:** Once heated, press the "STEAM" button to release steam. Hold the steamer upright and move it slowly over the fabric, maintaining a slight distance. For best results, pull the fabric taut with your free hand.
3. **360° Anti-Spill Design:** The electronic pump system allows for steaming at any angle, including upside down, without water spitting or leaks.
4. **Continuous Steaming:** The steamer provides up to 10 minutes of continuous steam on a full tank. If paused, it resumes steaming immediately when reactivated.
5. **Fabric Compatibility:** Suitable for various fabrics including wool, cotton, satin, linen, nylon, sequins, embroidery, and beads. Use the brush attachment for delicate items like silk and lace.
6. **Power Off:** After use, press the power button to turn off the steamer. Unplug the unit from the electrical outlet.

EDELSTAHL-DAMPFKOPF

ENTFERNT FALTEN AUS VERSCHIEDENEN
STOFFARTEN



Image: The metal steam head of the Polardo steamer, designed to remove wrinkles from various fabric types such as cotton, wool, and synthetics.

MAINTENANCE

- **Empty Water Tank:** After each use, ensure the steamer is unplugged and cooled. Remove the water tank and empty any remaining water.
- **Cleaning:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Descaling:** The NANO water filter minimizes calcification. However, if you notice reduced steam output or mineral buildup, you may perform a descaling process. Fill the tank with a 50/50 mixture of water and white vinegar. Run the steamer until the tank is empty. Repeat with clean water to rinse.
- **Storage:** Store the steamer in a cool, dry place, away from direct sunlight and moisture. Ensure the water tank is empty before storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank is empty or low. Unit not fully heated. Mineral buildup.	Refill water tank. Allow 25 seconds for heating. Perform descaling procedure.
Water spitting or leaking.	Water tank not securely attached. Overfilling the tank. Unit not fully heated.	Ensure water tank is properly seated. Do not overfill. Allow unit to heat completely before use.
Steamer not turning on.	Not plugged in correctly. Power outlet issue.	Check power connection. Try a different 220V outlet.

SPECIFICATIONS

- **Brand:** Polardo
- **Model Number:** SCP-220V
- **Color:** Black
- **Voltage:** 220 Volts (for Europe ONLY)
- **Heat Time:** Less than 25 seconds
- **Continuous Steam Time:** Up to 10 minutes
- **Water Tank Capacity:** 100 Milliliters
- **Item Weight:** 1.72 pounds
- **Package Dimensions:** 9.17 x 4.65 x 4.37 inches
- **Product Benefits:** Portable and powerful garment steaming, 360° Anti-Spill Design, NANO water filter.

DÉFROISSEUR VAPEUR DE VOYAGE POUR L'EUROPE



COMPACT



ULTRALÉGER



PORTABLE



polardo



220V



PRISE
EUROPÉENNE

Image: The Polardo steamer, compact and lightweight, shown packed in a suitcase alongside travel essentials, emphasizing its suitability for European travel.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your product packaging or visit the official Polardo website. Keep your purchase receipt as proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question