

ALLIMITY AKB76037001

User Manual for ALLIMITY AKB76037001 Remote Control

Model: **AKB76037001** | Brand: **ALLIMITY**

1. INTRODUCTION

The ALLIMITY AKB76037001 is a replacement remote control designed for various LG LCD LED TVs, Q.Bell TVs, and Oscar TVs. It is compatible with specific models including IHC13FA401, QT50WX73, QT39WY73, QT32WY73, QT45WX73, and B219. This remote control is engineered for ease of use, requiring no complex setup or programming.

Constructed from durable ABS materials, this remote offers a comfortable grip and is built to withstand regular use, serving as an ideal replacement for lost or damaged original remote controls.

2. PACKAGE CONTENTS

Upon opening the package, you should find the following item:

- 1 x ALLIMITY AKB76037001 Remote Control

Note: Batteries and a separate user manual are not included in the package.

3. SETUP AND BATTERY INSTALLATION

The ALLIMITY AKB76037001 remote control is designed for immediate use without any programming or complex setup procedures. Simply install the required batteries to begin operation.

3.1. Battery Requirements

- Required Battery Type: 2 x AAA Alkaline Batteries

3.2. Installing Batteries

1. Locate the battery compartment on the back of the remote control.

2. Gently slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two new AAA alkaline batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Figure 1: Battery compartment with batteries inserted.

Once batteries are installed, the remote control is ready for use with your compatible television.

4. OPERATING THE REMOTE CONTROL

This remote control functions identically to your original remote for compatible TV models. Point the remote directly at your television's infrared receiver for optimal performance.

4.1. Compatible TV Models

The ALLIMITY AKB76037001 remote control is compatible with the following known TV models:

- LG LCD LED TV models (specific models may vary, general compatibility)
- Q.Bell TV models
- Oscar TV models
- Specific models: IHC13FA401, QT50WX73, QT39WY73, QT32WY73, QT45WX73, B219

4.2. Basic Functions

The remote features standard buttons for TV operation. Refer to the layout below for common button functions:





Figure 2: Front view of the remote control with button layout.

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** For direct channel input.
- **Volume Up/Down:** Adjusts the sound volume.
- **Channel Up/Down:** Changes TV channels.
- **Mute Button:** Mutes or unmutes the TV sound.
- **Navigation Pad (Up/Down/Left/Right/OK):** For menu navigation and selection.
- **Back/Exit Buttons:** Returns to the previous screen or exits a menu.
- **Home Button:** Accesses the TV's smart home or main menu.
- **Netflix/Prime Video Buttons:** Direct access to streaming services (if supported by your TV).
- **Other Function Buttons:** Depending on your TV model, buttons like GUIDE, LIST, QUICK ACCESS, AD, TEXT, T.OPT, MOVIES, REC, and colored buttons will perform their respective functions.

5. CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your remote control, please follow these care guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Avoid Drops:** While made of durable ABS materials, excessive drops or impacts can damage the internal components. Handle with care.
- **Liquid Exposure:** Keep the remote control away from liquids. Liquid damage is not covered under typical product support.

6. TROUBLESHOOTING

If you experience issues with your ALLIMITY AKB76037001 remote control, please refer to the following common troubleshooting steps:

Problem	Possible Cause / Solution
Remote is not responding.	<ul style="list-style-type: none">◦ Batteries: Ensure batteries are inserted correctly with correct polarity (+/-). Replace old or depleted batteries with new AAA alkaline batteries.◦ Line of Sight: Ensure there are no obstructions between the remote control and the TV's infrared sensor. Point the remote directly at the TV.◦ TV Sensor: Check if the TV's infrared sensor is clean and not blocked.
Remote works intermittently.	<ul style="list-style-type: none">◦ Low Batteries: Batteries may be low. Replace them with new ones.◦ Interference: Strong light sources (like direct sunlight or fluorescent lights) can interfere with the IR signal. Try using the remote in a different lighting condition.
Certain buttons do not work.	<ul style="list-style-type: none">◦ Compatibility: Some advanced functions or specific app buttons may not be supported by all compatible TV models. Verify your TV's original remote functionality.◦ Damage: If only specific buttons fail, there might be internal damage.

If the issue persists after trying these steps, please contact customer support for further assistance.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	ALLIMITY
Model Number	AKB76037001
Compatible Devices	LG LCD LED TVs, Q.Bell TVs, Oscar TVs (Specific models: IHC13FA401, QT50WX73, QT39WY73, QT32WY73, QT45WX73, B219)
Max Number of Supported Devices	1
Power Source	2 x AAA Alkaline Batteries (not included)
Material	ABS
Color	Black
Special Feature	Ergonomic design
Product Dimensions	6 x 2 x 0.6 inches (approximately)
Item Weight	2.29 ounces (approximately)
Manufacturer	YUDAXINFACTORY
Date First Available	September 7, 2023

8. WARRANTY AND SUPPORT

This product has been strictly inspected before shipping to ensure quality. While specific warranty details are not provided in this manual, ALLIMITY is committed to customer satisfaction.

If you have any questions, concerns, or require assistance with your remote control, please do not hesitate to contact the seller or ALLIMITY customer support. We aim to reply to inquiries within 24 hours.

For support, please refer to the contact information provided by your retailer or on the product's packaging. You may also visit the ALLIMITY brand page on Amazon for potential contact options: [ALLIMITY Amazon Store](#)