



Manuals.plus /

› HOYECHI /

› HOYECHI Lighted Christmas Reindeer & Sleigh Set (Model HYC0805) Instruction Manual

**HOYECHI HYC0805**

# HOYECHI Lighted Christmas Reindeer & Sleigh Set (Model HYC0805) Instruction Manual

*Model: HYC0805*

## 1. PRODUCT OVERVIEW

---

The HOYECHI Lighted Christmas Reindeer & Sleigh Set is designed to enhance your indoor or outdoor holiday decorations. This 2-piece set features a reindeer and a sleigh adorned with LED lights, creating a festive ambiance. The set is constructed with durable materials suitable for various weather conditions.



*Image 1: The HOYECHI Lighted Reindeer and Sleigh Set, showcasing the illuminated reindeer and sleigh.*

## 2. SAFETY INFORMATION

---

### Important Safety Precautions:

- For outdoor use only.
- Unplug the decoration during inclement weather conditions (heavy rain, snow, strong winds).
- Keep away from flammable materials.
- Do not allow children to play on or near the display.
- Ensure all electrical connections are secure and protected from moisture.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly:

- 1 x Lighted Reindeer Figure
- 1 x Lighted Sleigh Figure
- 1 x Plug Adapter (100~240V)
- 1 x 32FT Outdoor Plug Extension Cord
- Ground Stakes (quantity may vary, typically 8)

- Cable Ties (quantity may vary, typically 20)
- Instruction Manual

## 4. SETUP INSTRUCTIONS

---

Follow these steps for effortless assembly and setup:

1. **Unpack Components:** Carefully remove all parts from the packaging. It is recommended to assemble the decoration outdoors to manage any glitter shedding.
2. **Assemble Reindeer:** Connect the body sections, legs, and antlers of the reindeer figure. Ensure all connections are secure.
3. **Assemble Sleigh:** Connect the various sections of the sleigh figure.
4. **Attach Bows:** Secure the decorative bows to the reindeer and sleigh as desired.
5. **Connect Electrical Components:** The reindeer and sleigh lights connect to a single power source via a Y-shaped cable. Connect the individual light strings from the reindeer and sleigh to the provided plug adapter.
6. **Position the Set:** Place the reindeer and sleigh in your desired outdoor location. The 32FT extension cord provides flexibility for placement.
7. **Secure to Ground:** Use the provided ground stakes to firmly anchor the reindeer and sleigh to the ground. This is crucial for stability, especially in windy conditions. For rocky terrain, additional methods may be required to ensure stability.
8. **Power On:** Plug the adapter into a suitable outdoor power outlet (100-240V).



# Use it your way

A 32FT long extension cord is added to extend the power outlet and connectors as a spare accessory. Perfect for outdoor use



Accessory: 32FT Extension Cord

Instructions:



Power input voltage :100-240v

Image 2: Visual representation of the reindeer and sleigh dimensions, aiding in proper placement.



*Image 3: Diagram showing the power input voltage and the 32FT extension cord accessory.*



## Rich color combinations

Let Your Home Shine with Festive Magic!



Bright lighting



Exquisite  
workmanship



Shine  
Christmas



*Image 4: Illustration of ground stakes and how they secure the decoration.*

## 5. OPERATING INSTRUCTIONS

---

The HOYECHI Lighted Christmas Reindeer & Sleigh Set is designed for simple operation:

- Once assembled and plugged into a power source, the LED lights will illuminate automatically.
- The set features 160 LED lights in total: 90 on the reindeer and 70 on the sleigh.
- No additional controls or settings are required for basic illumination.

# Shine Christmas

160 LED lights illuminate the decoration together



Reindeer



Sleigh



Image 5: The illuminated reindeer and sleigh, highlighting the 160 LED lights.

## 6. MAINTENANCE

To ensure the longevity and optimal appearance of your decoration:

- **Cleaning:** Gently wipe the surfaces with a soft, dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Glitter Shedding:** Some glitter shedding is normal during assembly and handling. This does not affect the product's functionality or overall appearance.
- **Storage:** After the holiday season, carefully disassemble the set. Store all components in their original packaging or a protective container in a cool, dry place to prevent damage and preserve the glitter finish.
- **Electrical Inspection:** Periodically check the power cord and connections for any signs of wear or damage. Replace any damaged parts immediately.

# Christmas atmosphere decoration



*Image 6: The reindeer and sleigh set displayed in a snowy outdoor setting, demonstrating its weather suitability.*

## 7. TROUBLESHOOTING

---

If you encounter any issues with your HOYECHI Lighted Christmas Reindeer & Sleigh Set, refer to the following common solutions:



Problem	Possible Cause	Solution
Lights are not illuminating.	Power connection is loose or unplugged. Faulty bulb or wiring.	Check all power connections and ensure the adapter is securely plugged into a working outlet. Inspect for any visible damage to wires or bulbs.
Decoration is unstable or tips over.	Insufficiently secured to the ground. Strong winds.	Ensure all ground stakes are fully inserted and the decoration is firmly anchored. Consider using additional weights or stronger stakes in very windy areas.
Glitter is falling off.	Normal during initial setup and handling.	This is expected. Assemble outdoors to minimize indoor mess. The overall appearance will not be significantly affected.
Difficulty during assembly.	Unclear instructions or complex parts.	Refer to the instructional videos provided by the manufacturer (if available) for visual guidance. Ensure all parts are correctly oriented before securing.

Your browser does not support the video tag.

*Video 1: Official HOYECHI video demonstrating the assembly and features of the Christmas Reindeer & Sleigh.*

Your browser does not support the video tag.

*Video 2: Official HOYECHI video showcasing the lighted Christmas Reindeer Sleigh in action.*

Your browser does not support the video tag.

*Video 3: Official HOYECHI video demonstrating the lighted Christmas Reindeer Sleigh in white.*

## 8. SPECIFICATIONS

Feature	Detail
Brand	HOYECHI
Model Number	HYC0805
Product Dimensions (Reindeer)	25.5" (L) x 10.5" (W) x 48" (H)
Product Dimensions (Sleigh)	35" (L) x 12" (W) x 22.5" (H)
Item Weight	11.13 pounds
Number of Light Sources	160 LED Lights (90 on reindeer, 70 on sleigh)
Light Color	White
Power Source	AC (Plug Adapter 100~240V)
Recommended Use	Outdoor
Material	Metal frame with shimmering fabric (glitter finish)

## 9. WARRANTY AND SUPPORT

---

For warranty information, product support, or to inquire about replacement parts, please contact HOYECHI customer service directly. Refer to the product packaging or the official HOYECHI website for contact details.