

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [NUMGMT](#) /

› Wireless Bluetooth Open-Ear Earbuds User Manual

## NUMGMT Wireless Bluetooth Open-Ear Earbuds (B0CHK22TSF)

# Wireless Bluetooth Open-Ear Earbuds User Manual

Model: Wireless Bluetooth Open-Ear Earbuds (B0CHK22TSF)

## 1. PRODUCT OVERVIEW

The NUMGMT Wireless Bluetooth Open-Ear Clip-On Sports Earbuds are designed for comfort and high-quality audio. Featuring Bluetooth V5.3, they provide a stable and fast connection for various activities. Their unique clip-on design ensures a secure fit without entering the ear canal, promoting long-term, pain-free wear and healthy listening. These earbuds are equipped with intelligent noise reduction for clear communication and deliver high-fidelity sound, making them suitable for gaming, music, and fitness. Intuitive smart touch controls allow for easy management of music playback, calls, volume, and voice assistant activation. The portable charging case includes a clear LED display to indicate battery levels, ensuring your earbuds are always ready for use.



Image: The NUMGMT Wireless Bluetooth Open-Ear Earbuds, showing both earbuds and their charging case with an LED power display.

## 2. SPECIFICATIONS

Feature	Detail
Brand	NUMGMT
Model Name	Wireless Bluetooth Earbuds
Bluetooth Version	V5.3

Transmission Distance	Up to 10 meters (33 feet)
Battery Capacity (Charging Case)	300 mAh
Single Earbud Use Time	Approx. 5-6 hours
Total Playback Time (with case)	Up to 50 hours
Charging Duration	Approx. 1.5 hours
Charging Port	Type-C
Ear Placement	Open-Ear, Clip-On
Noise Control	Active Noise Cancellation (Intelligent Noise Reduction)
Water Resistance	Yes (Sport-ready)
Included Components	Charging Case, Earbuds

## 3. GETTING STARTED (SETUP)

---

### 3.1 Charging the Earbuds and Case

Before first use, ensure both the earbuds and the charging case are fully charged.

1. Place the earbuds into the charging case. Ensure they are correctly seated to make contact with the charging pins.
2. Connect the Type-C charging cable to the charging port on the case and plug the other end into a USB power source (e.g., wall adapter, computer USB port).
3. The LED display on the charging case will show the current battery level and charging status. A full charge typically takes about 1.5 hours.
4. Once fully charged, the LED display will indicate 100%. Disconnect the charging cable.




Image: The earbuds placed inside their charging case, which features an LED power display indicating battery status.

### 3.2 Pairing with a Bluetooth Device

The earbuds will automatically enter pairing mode when taken out of the charging case.

1. Open the charging case and remove both earbuds. They will automatically power on and enter pairing mode.
2. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings.
3. Search for available devices. You should see "Wireless Bluetooth Earbuds" or a similar name appear in the list.
4. Select the earbuds from the list to connect. Once connected, you will hear a confirmation tone, and the earbuds' indicator lights will change.
5. If pairing fails, place the earbuds back into the case, close the lid, wait a few seconds, and then repeat the steps.

## 4. OPERATION

### 4.1 Wearing the Earbuds

These earbuds feature an open-ear, clip-on design for comfort and awareness of your surroundings.

- Gently clip each earbud onto your earlobe, ensuring the speaker is positioned near your ear canal without entering it.

- Adjust the position for a comfortable and secure fit. The soft silicone clip is designed for extended wear without discomfort.




Image: A person wearing one of the open-ear clip-on earbuds, demonstrating its ergonomic design that does not enter the ear canal.

## 4.2 Smart Touch Controls

The earbuds are equipped with smart touch sensors for easy control of various functions:

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause Music, Answer/End Call
Double Tap (Left Earbud)	Previous Song
Double Tap (Right Earbud)	Next Song
Triple Tap (Left Earbud)	Volume Down
Triple Tap (Right Earbud)	Volume Up
Long Press (2 seconds)	Reject Call, Activate Voice Assistant

## 5. MAINTENANCE

---

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use abrasive cleaners, alcohol, or chemical sprays.
- **Water Resistance:** While water-resistant, avoid submerging the earbuds in water. Dry them thoroughly if they get wet from sweat or light rain before placing them back in the charging case.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging:** Charge the case regularly, even if not using the earbuds frequently, to maintain battery health. Avoid overcharging for extended periods.

## 6. TROUBLESHOOTING

---

If you encounter issues with your earbuds, refer to the following common solutions:

- **Earbuds not pairing/connecting:**
  - Ensure Bluetooth is enabled on your device.
  - Make sure the earbuds are charged.
  - Place earbuds back in the case, close the lid, then open and remove them to re-enter pairing mode.
  - Forget the device from your phone's Bluetooth settings and try pairing again.
  - Ensure no other Bluetooth devices are interfering.
- **No sound or low volume:**
  - Check the volume level on both your device and the earbuds (using touch controls).
  - Ensure the earbuds are properly connected to your device.
  - Clean any debris from the earbud speakers.
- **Charging case not charging:**
  - Verify the Type-C cable is securely connected to both the case and the power source.
  - Try a different charging cable or power adapter.
  - Ensure the power source is active.
- **Touch controls not responding:**
  - Ensure your fingers are clean and dry when touching the sensors.
  - Restart the earbuds by placing them in the case and taking them out again.

## 7. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the purchase documentation or contact the seller directly. Keep your proof of purchase for any warranty claims.

Manufacturer: NUMGMT

ASIN: B0CHK22TSF

For further assistance, you may visit the product page on Amazon.sa:[Product Link](#)



© 2024 NUMGMT. All rights reserved.