**Signature Design by Ashley 9050318**

# Signature Design by Ashley Biscoe Power Reclining Loveseat with Console Instruction Manual

## 1. Introduction

This manual provides essential information for the assembly, operation, maintenance, and care of your Signature Design by Ashley Biscoe Power Reclining Loveseat with Console. Please read these instructions thoroughly before use to ensure proper function and longevity of your product.

The Biscoe Power Reclining Loveseat features a contemporary design with high-performance fabric and plush cushioning. Key functionalities include power reclining, an adjustable Easy View headrest, a center console with cup holders and storage, and integrated USB ports for charging devices.



*Image 1.1: The Signature Design by Ashley Biscoe Power Reclining Loveseat with Console in Light Gray.*



*Image 1.2: Overview of key features including power reclining, adjustable headrest, USB port, extended ottoman, and center console.*

## 2. Setup and Assembly

Your Biscoe Power Reclining Loveseat requires minor assembly. Follow these steps carefully:

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all parts are present before beginning assembly.
2. **Attach Backs:** Align the backrests with the corresponding slots on the base of the loveseat. Slide them down firmly until they click into place.
3. **Attach Armrests:** Secure each armrest to the main frame according to the provided instructions.
4. **Connect Power:** Locate the power cord and connect it to the power input on the loveseat. Plug the power adapter into a standard electrical outlet.

The loveseat is designed to fit through doorways 32 inches or wider. Ensure a minimum clearance of 5 inches between the recliner and any wall to allow for full reclining motion.

ALSO AVAILABLE IN THIS COLLECTION







*Image 2.1: Rear view of the loveseat, illustrating the structure and potential assembly points for backrests.*

## 3. Operating Instructions

The Biscoe Power Reclining Loveseat offers intuitive controls for comfort and convenience.

### 3.1 Power Reclining Function

Each seating position on the loveseat is equipped with a power reclining mechanism. Use the control panel located on the side of the armrest to adjust your position.

- Press and hold the **recline button** to extend the footrest and recline the backrest.
- Release the button at your desired position.
- Press and hold the **return button** to bring the loveseat back to its upright position.




**WIDTH:78"** **DEPTH:43"** **HEIGHT:42"**

Arm height: 25"
Seat depth: 23"
Fully reclined length: 68"
Footrest height: 18"

Distance between arms: 59"
Seat height: 21"
Distance between recliner and wall: 5"




*Image 3.1: The loveseat with one seat in a reclined position, demonstrating the extended footrest.*

## 3.2 Adjustable Easy View Headrest

The Easy View headrest can be adjusted independently to provide optimal neck and head support, especially when viewing a screen.

- Use the dedicated **headrest control buttons** on the side panel to tilt the headrest forward or backward.
- Adjust to your preferred angle for comfort.

## 3.3 USB Charging Ports

Integrated USB ports are available on the control panel for convenient charging of your electronic devices.

- Locate the USB port on the side of the armrest.
- Plug your device's USB cable into the port to begin charging.



*Image 3.2: Detail of the control panel, showing buttons for reclining and headrest adjustment, along with the USB charging port.*



*Image 3.3: A smartphone connected to the USB charging port on the loveseat.*

## 3.4 Center Console with Storage and Cup Holders

The center console provides practical amenities for your convenience.

- Use the two integrated cup holders to secure beverages.
- Lift the console lid to access the hidden storage compartment for remotes, magazines, or other small items.



*Image 3.4: The center console with its lid open, showcasing the internal storage space and cup holders.*

## 4. Maintenance and Care

Proper care will help maintain the appearance and extend the life of your loveseat.

### 4.1 Upholstery Care

The loveseat features Next-Gen Nuvella polyester upholstery, a solution-dyed performance fabric known for high UV resistance and durability.

- **Spot Cleaning:** For spills and stains, spot clean immediately with a damp cloth. Use a mild, water-based cleaning agent if necessary, and blot gently. Avoid harsh chemicals or abrasive cleaners.
- **Regular Cleaning:** Vacuum regularly using a soft brush attachment to remove dust and loose debris.
- **UV Resistance:** While the fabric is UV resistant, prolonged direct exposure to sunlight can still cause fading over time. Position the loveseat to minimize direct sun exposure.



*Image 4.1: A close-up view of the Next-Gen Nuvella polyester fabric, highlighting its texture and weave.*

### 4.2 General Care

- Avoid placing the loveseat near heat sources or in excessively humid environments.
- Do not sit on the armrests or console.
- Periodically check and tighten any loose hardware.

## 5. Troubleshooting

If you encounter any issues with your loveseat, refer to the following common troubleshooting tips:

- **Power Issue:** If the reclining function or USB ports are not working, ensure the power cord is securely plugged into both the loveseat and the wall outlet. Check if the outlet is functional by plugging in another device.
- **Reclining Mechanism Jam:** Ensure there are no obstructions (e.g., objects, pets) under or behind the loveseat that could interfere with the reclining mechanism.
- **Unusual Noises:** Minor operational noises are normal. If you hear loud or persistent grinding/squeaking, inspect the mechanism for loose parts or contact customer support.

For persistent issues not resolved by these steps, please refer to the Warranty & Support section.

## 6. Specifications

Detailed specifications for the Signature Design by Ashley Biscoe Power Reclining Loveseat (Model: 9050318):

| Feature | Detail |
|---|---|
| Brand | Signature Design by Ashley |
| Model Number | 9050318 |
| Product Dimensions | 43"D x 78"W x 42"H |
| Item Weight | 252 Pounds |
| Type | Loveseat |
| Color | Light Gray |
| Upholstery Fabric Type | Polyester (Next-Gen Nuvella) |
| Special Features | Position Lock, Recliner, Storage, USB Charging Ports, UV Resistant |
| Weight Limit | 500 Pounds |
| Seat Depth | 23 inches |
| Seat Height | 21 Inches |
| Arm Height | 25 Inches |
| Reclined Length | 68 Inches |
| Minimum Required Door Width | 32 Inches |
| Furniture Wall Clearance | 5 Inches |
| Assembly Required | Yes |
| Product Care Instructions | Spot Clean with Damp Cloth |
| Warranty Type | Limited |
| UPC | 024052857641 |




*Image 6.1: Key dimensions of the loveseat, including width, depth, height, and arm height.*

## 7. Warranty and Support

Your Signature Design by Ashley Biscoe Power Reclining Loveseat comes with a limited warranty. For specific details regarding coverage and duration, please refer to the warranty documentation included with your purchase or contact Signature Design by Ashley customer service.

### 7.1 Protection Plans

Additional protection plans may be available for purchase to extend coverage beyond the standard manufacturer's warranty. These plans typically cover repairs or replacements for a specified period.

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly plan covering multiple eligible purchases)

### 7.2 Customer Support

For assistance with assembly, operation, troubleshooting, or warranty claims, please contact Signature Design by Ashley customer support. You can also visit the official Signature Design by Ashley Store for more product information and support resources.

**Ask a question about this manual**

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**