Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

oneisall N12-2

oneisall 4-in-1 Cordless Pet Grooming Kit User Manual

Model: N12-2

Brand: oneisall

Introduction

This manual provides comprehensive instructions for the safe and effective use of your oneisall 4-in-1 Cordless Pet Grooming Kit. This versatile kit is designed to simplify pet grooming, offering solutions for trimming hair on the body, face, ears, paws, and rump, as well as a quiet nail grinder for claw care. Its low-noise operation ensures a stress-free experience for your pets.



Image: The oneisall 4-in-1 Pet Grooming Kit, featuring the main clipper unit, various interchangeable heads, and two happy dogs, illustrating the product's purpose.

What's Included

Your oneisall 4-in-1 Pet Grooming Kit includes the following components:

- Main Clipper Unit (Rechargeable)

- Standard Cutter Head (for fast trimming of pet's hair)
- Narrow Cutter Head (for face and pads)
- Small Cutter Head (for sensitive areas and paws)
- Nail Grinder Head (for pet nail grinding)
- 2 Trimming Combs (1.5mm, 3mm)
- Charging Cable (USB)
- Cleaning Brush
- Lubricating Oil
- User Manual



Image: A visual representation of the four interchangeable heads included in the kit: Standard Cutter Head, Narrow Cutter Head, Small Cutter Head, and Nail Grinder Head.

Setup

1. **Initial Charge:** Before first use, fully charge the main clipper unit. Connect the charging cable to the unit and a compatible USB power source (wall adapter, laptop, power bank, computer). The indicator lights will show charging status. A full charge takes approximately 120 minutes.

2. **Attaching Heads:** To attach a grooming head, align the head with the main unit and twist it into the lock position until it clicks securely. To remove, twist in the opposite direction and pull off.
3. **Attaching Guide Combs:** For the clipper heads, select the desired trimming comb (1.5mm or 3mm) and slide it onto the clipper head until it locks into place.




Image: The main clipper unit connected to a charging cable, demonstrating how to charge the device.



Image: Visual instructions on how to attach and remove the interchangeable grooming heads from the main unit.

Operating Instructions

General Operation

- Press the power button to turn the unit on.
- The device features two speed settings (5300 rpm and 6300 rpm). Press the power button again to switch between speeds.
- For body hair, use the high-speed setting. For sensitive areas like the face and ears, use the low-speed setting for a gentle, quiet trim.
- Ensure your pet is calm and comfortable before beginning grooming.

Using the Clippers

1. Select the appropriate clipper head (Standard, Narrow, or Small) and attach it securely.
2. Attach a guide comb if desired for specific hair lengths.
3. Gently hold your pet's skin taut and move the clipper in the direction of hair growth.
4. For paw trimming, use the Small Cutter Head to carefully trim hair between the paw pads.



Image: A person using the oneisall paw trimmer to carefully trim hair on a dog's paw, showing before and after results.



Image: Demonstrates the two-speed functionality, showing high speed for body trimming and low speed for delicate paw trimming.




Image: A sleeping puppy next to the trimmer, highlighting the ultra-quiet operation (below 50 dB) of the device.

Using the Nail Grinder

1. Attach the Nail Grinder Head to the main unit.
2. Choose the appropriate grinding port size for your pet's nails (small, medium, or large).
3. Gently hold your pet's paw and place the nail into the grinding port. Grind each nail for a few seconds at a time to avoid overheating and discomfort.

4. Regularly check the nail length and stop when desired length is achieved.



Image: A close-up of the nail grinder in use on a dog's paw, demonstrating the grinding process.



Image: Illustrates the three different grinding port sizes (small, medium, large) available on the nail grinder head, suitable for various pet sizes.

Maintenance

1. **Cleaning Blades:** After each use, remove the clipper head and use the provided cleaning brush to remove any trapped hair from the blades.
2. **Oiling Blades:** Apply a few drops of the lubricating oil to the blades after cleaning to ensure smooth operation and prolong blade life.
3. **Cleaning Grinder Head:** After using the nail grinder, gently brush away any nail dust from the grinding stone.
4. **Storage:** Store the kit in a dry, cool place away from direct sunlight and moisture.

Troubleshooting

Problem	Possible Cause	Solution
Clipper not turning on.	Low battery or unit not charged.	Charge the unit fully. Ensure charging cable is properly connected.
Poor trimming performance.	Blades are dull, dirty, or not oiled. Hair buildup.	Clean blades thoroughly with the brush. Apply lubricating oil. Ensure no hair is stuck in the blade mechanism.
Nail grinder not effective.	Grinding stone is worn or dirty. Incorrect port size.	Clean the grinding stone. Ensure the correct grinding port size is used for the pet's nail.
Excessive noise during operation.	Blades require oiling or cleaning.	Clean and oil the blades. If noise persists, contact customer support.

Specifications

- **Model:** N12-2
- **Item Weight:** 10.6 ounces (0.3 Kilograms)
- **Item Package Dimensions L x W x H:** 7.48 x 7.4 x 1.81 inches
- **Batteries:** 1 C battery required (included)
- **Operating Time:** Approximately 120 minutes
- **Charging Time:** Approximately 120 minutes
- **Noise Level:** Below 50 dB
- **Speed Settings:** 2 (5300 rpm, 6300 rpm)
- **Color:** Blue
- **Material:** Plastic



Image: A visual summary of the product's dimensions and key specifications, including model number, operating time, and noise level.

Warranty and Support

Your oneisall Pet Grooming Kit comes with a**2-Year Warranty**. For any product inquiries, technical assistance, or warranty claims, please contact oneisall customer service. We offer **24-hour Customer Service** to ensure your satisfaction.

For more information, visit theoneisall Store.

Product Demonstration

Watch the video below for a detailed unboxing and demonstration of the oneisall 4-in-1 Pet Grooming Kit, including how to use the various attachments and the nail grinder.

Your browser does not support the video tag.

Video: An unboxing and demonstration of the oneisall 4-in-1 Pet Grooming Kit, showcasing its features and ease of use for grooming pets.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CHM8828W

More documents and user manuals: **https://manuals.plus/**