

[Manuals.plus](#) /

› [Marsail](#) /

› Marsail Glass Standing Desk User Manual

Marsail MSED7W-US

Marsail Glass Standing Desk User Manual

Model: MSED7W-US

1. INTRODUCTION

Welcome to the user manual for your Marsail Glass Standing Desk. This electric height-adjustable desk is designed to enhance your workspace with its elegant glass tabletop, integrated charging ports, and convenient storage drawer. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your desk.



Figure 1: Marsail Glass Standing Desk with monitors and accessories.

2. SETUP AND ASSEMBLY

The Marsail Glass Standing Desk is designed for hassle-free assembly with its one-piece tabletop. All necessary installation tools and detailed instructions are included.

2.1 Unpacking and Component Check

Carefully unpack all components and verify against the included parts list. Ensure no parts are missing or damaged before proceeding with assembly.

2.2 Assembly Steps

1. Refer to the [Installation Manual \(PDF\)](#) for step-by-step assembly instructions.
2. It is recommended that **one person** is sufficient for assembly.
3. Ensure all screws and connections are securely tightened before use.

Hassle-Free Assembly

Detailed instructions & labeled hardware



Figure 2: Hassle-Free Assembly with detailed instructions.

Charging Made Easier



Figure 3: Product Dimensions and Weight Capacity.

3. OPERATING INSTRUCTIONS

Your Marsail Glass Standing Desk offers convenient electric height adjustment and integrated charging capabilities.

3.1 Height Adjustment

The desk allows for easy transition between sitting and standing positions, with a height range of 28.3 inches to 46.5 inches.

- Use the **UP/DOWN** buttons on the control panel to adjust the desk height manually.
- The desk features **four preset buttons (1, 2, 3, M)** to save your favorite height settings for quick adjustment. Consult the installation manual for programming specific presets.



Figure 4: Intuitive Control Panel for height adjustment and charging.



Figure 5: Sit and Stand Comfortably with adjustable height.

3.2 USB Charging Ports

The desk is equipped with integrated USB-A and Type-C charging ports on the front panel to keep your devices powered.

- Simply plug your compatible devices into the available USB-A or Type-C ports.
- Ensure the desk is connected to a power source for charging functionality.

Sit & Stand Comfortably



Figure 6: Fast and Convenient Charging.

3.3 Storage Drawer

The desk includes a spacious 25.4" x 12.4" dual-zone drawer for organizing office supplies and accessories, helping to maintain a clutter-free workspace.

Product Dimensions

 **110 lbs**



Figure 7: Slim Dual-Zone Drawer for organized storage.

4. MAINTENANCE AND CARE

Proper care ensures the longevity and appearance of your Marsail Glass Standing Desk.

- **Cleaning the Glass Surface:** Wipe the glass tabletop with a dry cloth. For stubborn marks, use a glass cleaner and a soft, lint-free cloth. Avoid abrasive cleaners or harsh chemicals.

- **Dry Erase Functionality:** The glass desktop can be used with dry erase markers. Always use **dry erase markers only** and wipe clean with a dry cloth or whiteboard eraser.
- **Frame Care:** The metal base is polished and rust-resistant. Wipe with a dry cloth to remove dust.
- **General Maintenance:** Periodically check all screws and connections to ensure they remain tight. Do not overload the desk beyond its maximum weight recommendation of 120 pounds.

Slim Dual-Zone Drawer



Figure 8: Strong Tempered Glass surface is easy to clean.

5. TROUBLESHOOTING

If you encounter any issues with your Marsail Glass Standing Desk, please refer to the following common troubleshooting tips:

- **Desk Not Adjusting Height:**
 - Check if the power cable is securely plugged into both the desk and a working power outlet.
 - Ensure there are no obstructions preventing the desk from moving up or down.
 - Perform a reset if indicated in the full installation manual (often involves holding down certain buttons).
- **USB Ports Not Charging:**
 - Verify the desk is powered on and connected to an active power source.
 - Try a different USB cable or device to rule out a faulty accessory.
- **Unstable Desk:**
 - Ensure all assembly screws are tightened.
 - Check that the desk is placed on a flat, level surface.
 - Do not exceed the maximum weight capacity of 120 pounds.

For more detailed troubleshooting or persistent issues, please contact Marsail customer support.

6. SPECIFICATIONS

Feature	Detail
Brand	Marsail
Model Number	MSESD7W-US
Product Dimensions (D x W x H)	24"D x 46.5"W x 28.3"H
Color	Soft White
Style	Glass Top
Base Material	Metal
Top Material Type	Glass
Minimum Height	28.3 Inches
Maximum Height	46.5 Inches
Maximum Weight Recommendation	120 Pounds
Special Features	Adjustable Height, Built-In USB Outlet, Electric, Rust Resistant, Scratch Resistant
Included Components	Built-in USB Port, Cable Management Tray, Electric Standing desk, Installation Instruction Manual, Necessary installation tools - Allen Wrench

Feature	Detail
Product Care Instructions	Wipe with Dry Cloth
Number of Drawers	1

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The Marsail Glass Standing Desk comes with a**Limited Warranty**. The manufacturer's warranty type is listed as 5 years. Please retain your proof of purchase for warranty claims.

- **2-Year Protection Plan:** Available for purchase.
- **3-Year Protection Plan:** Available for purchase.

For detailed warranty terms and conditions, please refer to the documentation provided with your product or contact Marsail customer service.

7.2 Customer Support

For any questions, technical assistance, or support needs, please contact Marsail customer service through the following channels:

- Visit the official Marsail Store on Amazon:[Marsail Store](#)
- Refer to the [Installation Manual \(PDF\)](#) for additional information.
- Contact Amazon Customer Support for purchase-related inquiries.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question