

ECG Forza 8000 Pour over Nero

ECG Forza 8000 Pour Over Nero Kettle User Manual

Model: Forza 8000 Pour over Nero | Brand: ECG

IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using the appliance and keep them for future reference. Incorrect use may lead to injury or damage to the appliance.

- Do not immerse the power base, cord, or plug in water or any other liquid.
- Ensure the kettle is placed on a stable, flat, heat-resistant surface, away from the edge of the countertop.
- Do not overfill the kettle beyond the maximum fill line to prevent boiling water from spilling.
- Always unplug the kettle from the power outlet when not in use, before cleaning, and before moving.
- Keep the appliance out of reach of children and pets.
- Do not operate the kettle if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Avoid touching hot surfaces. Use the handle.
- Only use the kettle with its supplied power base.
- This appliance is intended for household use only.

PRODUCT OVERVIEW

The ECG Forza 8000 Pour Over Nero is a 1.0-liter electric kettle designed for precise temperature control, ideal for pour-over coffee and tea preparation. It features a gooseneck spout for controlled pouring and a matte black stainless steel housing.



Image: The ECG Forza 8000 Pour Over Nero kettle with its power base, showcasing its matte black finish and gooseneck spout.

Key Features:

- **Gooseneck Spout:** For precise water flow control.
- **Matte Black Design:** Stylish and minimalist aesthetic.
- **Stainless Steel Housing:** Durable and easy to clean.
- **1.0 Liter Capacity:** Optimal for personal or small-group use.
- **Durable Strix Controller:** Ensures reliable performance.
- **Round LED Display:** Located on the base, shows real-time temperature.
- **Adjustable Temperature:** Allows selection of desired water temperature.
- **Automatic Shut-off:** For safety and energy efficiency.
- **Boil-Dry Protection:** Prevents damage if the kettle is accidentally switched on without water.



Image: The ECG Forza 8000 kettle detached from its power base, illustrating the separate components.

SETUP

1. **Unpack:** Carefully remove all packaging materials and ensure all components (kettle, lid, power base) are present and undamaged.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water to the maximum fill line. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, stable, and heat-resistant surface. Ensure the power cord is not dangling or in a position where it can be tripped over.
4. **Connect Power:** Plug the power cord into a suitable electrical outlet.

OPERATING INSTRUCTIONS



Image: Close-up of the ECG Forza 8000 power base, showing the LED display and control buttons (Boil, Keep Warm, ON/OFF, temperature adjustment).

1. **Fill the Kettle:** Remove the kettle from the power base and open the lid. Fill the kettle with the desired amount of fresh, cold water. Do not fill below the minimum mark or above the maximum fill line. Close the lid securely.
2. **Place on Base:** Place the kettle firmly onto the power base.
3. **Power On:** Press the **ON/OFF** button to activate the kettle. The LED display will illuminate, showing the current water temperature.
4. **Set Temperature (Optional):** Use the **+** and **-** buttons to select your desired target temperature. The display will show the set temperature.
5. **Start Boiling:**
 - To boil water to 100°C (212°F), press the **Boil** button. The kettle will start heating.
 - If a specific temperature was set, the kettle will heat the water to that temperature.
6. **Keep Warm Function:** After reaching the target temperature, you can press the **Keep Warm** button. The kettle will maintain the water at the set temperature for a specified period (refer to product specifications for duration).
7. **Automatic Shut-off:** The kettle will automatically switch off once the water reaches the set temperature or boils (100°C).
8. **Pouring:** Carefully lift the kettle from the base and pour the hot water using the gooseneck spout for precise control.
9. **Power Off:** To manually turn off the kettle, press the **ON/OFF** button again.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your kettle and ensure optimal performance.

1. **Before Cleaning:** Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
2. **Exterior Cleaning:** Wipe the exterior of the kettle and the power base with a soft, damp cloth. Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish.
3. **Interior Cleaning:** The interior of the kettle can be hand washed with mild dish soap and a soft sponge. Rinse thoroughly.
4. **Descaling:** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. To descale:
 - Fill the kettle with a mixture of equal parts water and white vinegar, or use a commercial descaling solution according to its instructions.
 - Bring the mixture to a boil and let it stand for at least 30 minutes, or longer for heavy buildup.
 - Empty the kettle and rinse it thoroughly several times with fresh water to remove any residue and vinegar smell.
 - Repeat if necessary.
5. **Storage:** When not in use, store the kettle and its base in a dry, safe place.

TROUBLESHOOTING

If you encounter any issues with your ECG Forza 8000 kettle, please refer to the following common problems and solutions:

- **Kettle does not turn on:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Check that the kettle is correctly placed on the power base.
 - Press the **ON/OFF** button firmly.
- **Water is not heating:**
 - Verify that the kettle is powered on and a heating cycle has been initiated (e.g., by pressing **Boil** or setting a temperature).
 - Check for any error messages on the LED display.
- **Kettle switches off too quickly:**
 - This may indicate limescale buildup. Perform a descaling procedure as described in the Maintenance section.
 - Ensure the kettle is filled above the minimum fill line.
- **Water tastes unusual:**
 - For first use, ensure you have performed the initial cleaning steps (boiling and discarding water multiple times).
 - Regularly clean and descale the kettle.
- **Leakage from the spout or lid:**
 - Ensure the lid is securely closed.

- Do not overfill the kettle beyond the maximum fill line.

If the problem persists after trying these solutions, please contact customer support or a qualified service technician.

SPECIFICATIONS

Feature	Specification
Brand	ECG
Model Name	Forza 8000 Pour over Nero
Capacity	1.0 Liters
Material	Stainless Steel
Color	Black
Wattage	1200 watts
Voltage	220 volts
Item Dimensions (L x W x H)	16.7 x 27 x 20 centimeters
Item Weight	2.12 Kilograms
Special Features	Automatic Shut-Off, Boil Dry Protection, Digital Display, Gooseneck Spout
Recommended Use	Pour-over coffee brewing and precise temperature control
Product Care Instructions	Hand wash, Washable

WARRANTY AND SUPPORT

This ECG Forza 8000 Pour Over Nero kettle comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging or your purchase receipt for specific terms and conditions, including the warranty period and coverage details.

For technical support, service, or warranty claims, please contact your retailer or the ECG customer service department. Contact information can typically be found on the manufacturer's official website or in your product documentation.