

etoolab Electric Spin Scrubber

etoolab Electric Spin Scrubber Instruction Manual

MODEL: ELECTRIC SPIN SCRUBBER

1. Introduction

The etoolab Electric Spin Scrubber is designed to simplify various cleaning tasks around your home and vehicle. Featuring an adjustable long handle, dual-speed operation, and multiple interchangeable brush heads, this device aims to provide efficient cleaning for tubs, tiles, floors, and more. Its IPX7 waterproof design ensures safe use in wet environments.

2. Product Components

The etoolab Electric Spin Scrubber package includes the following items:

- Electric Spin Scrubber main unit with adjustable handle
- 5 Replacement High-Density Brush Heads:
 - Dome Brush (for bathtubs, sinks, toilets)
 - Corner Brush (for narrow and hard-to-reach areas)
 - Large Flat Brush (for grounds, glass, doors, walls)
 - Small Flat Brush (for detail work)
 - Mop Brush (for smooth surfaces like car hoods and glass)
- Charging Cable
- Storage Bag
- Microfiber Cleaning Cloths




Figure 2.1: Included components of the etoolab Electric Spin Scrubber.

3. Setup

3.1 Initial Charging

Before first use, fully charge the electric spin scrubber. Connect the charging cable to the device and a suitable power source. The charging indicator light will provide status updates.

3.2 Assembling the Handle

The handle can be adjusted to various lengths for comfortable use. Extend the handle by pulling the sections apart until they lock into your desired length. The maximum length is 55 inches (138 cm).

Upgraded Pure Copper Motor

Designed for customer's cleaning needs



35

kgf

Pressure Uniform
Rotation

480 rpm

Max Speed Improved
Cleaning Efficiency

Figure 3.1: Adjustable handle lengths for ergonomic cleaning.

3.3 Attaching Brush Heads

To attach a brush head, align the head with the rotating base of the scrubber and push firmly until it clicks into place. To remove, pull the brush head off with moderate force.

4. Operating Instructions

4.1 Powering On and Speed Selection

Press the power button once to activate the low-speed mode (380 RPM) for daily cleaning tasks. Press and hold the power button to switch to the high-speed mode (480 RPM) for deep cleaning stubborn stains. Press the power button again to turn off the device.

4.2 Using Different Brush Heads

Select the appropriate brush head for your cleaning task:

- **Dome Brush:** Ideal for curved surfaces such as bathtubs, sinks, and toilet bowls.
- **Corner Brush:** Designed for reaching into narrow spaces, corners, and grout lines.
- **Large Flat Brush:** Suitable for large flat surfaces like floors, glass panels, doors, and walls.
- **Small Flat Brush:** For detailed cleaning of smaller flat areas or intricate surfaces.

- **Mop Brush:** Best for delicate or smooth surfaces, such as car exteriors or glass, to prevent scratches.



Figure 4.1: Application of different brush heads for various cleaning needs.

4.3 General Usage Tips

Apply appropriate cleaning solution to the surface before scrubbing. Allow the scrubber to do the work; avoid applying excessive pressure, which can reduce motor efficiency and battery life. For optimal results, move the brush slowly over the surface.

Your browser does not support the video tag.

Video 4.2: Demonstrates the wide range of uses for the etoolab Electric Spin Scrubber on various surfaces.

5. Maintenance

5.1 Cleaning the Device and Brush Heads

After each use, rinse the brush heads thoroughly with water to remove any cleaning solution or debris. The main unit can be wiped clean with a damp cloth. Ensure the charging port cover is securely closed when cleaning to maintain water resistance.

5.2 Waterproof Design

The etoolab Electric Spin Scrubber features an IPX7 waterproof design, allowing it to be used in wet environments without damage. However, avoid submerging the entire unit for extended periods.




Figure 5.1: The scrubber's IPX7 waterproof rating ensures durability in wet conditions.

5.3 Storage

Store the scrubber and its accessories in the provided mesh bag in a dry place when not in use. This helps keep all components together and extends their lifespan.

6. Troubleshooting

If you encounter any issues with your etoolab Electric Spin Scrubber, please consider the following:

- **Device not turning on:** Ensure the battery is fully charged.
- **Reduced scrubbing power:** Check if the brush head is securely attached. Ensure the battery is adequately charged.
- **Unusual noise:** Discontinue use and check for any obstructions in the brush head or motor area.

For further assistance, please refer to the Warranty and Support section.

7. Specifications

Brand	etoolab
Model	Electric Spin Scrubber
Color	Green
Product Dimensions	24.13"L x 3.62"W x 9.84"H (compact)
Adjustable Handle Length	Up to 55 inches
Material	Polypropylene
Item Weight	4.8 Pounds
Battery	1 Lithium Ion battery (included)
Spin Speeds	2 (380 RPM Low, 480 RPM High)
Waterproof Rating	IPX7
Specific Uses	Bathroom, Tile, Shower, Bathtub, Grout, Floor, Car

8. Warranty and Support

The etoolab Electric Spin Scrubber comes with a **24-Month Warranty**. We are committed to product quality and customer satisfaction.

If you have any questions, concerns, or require support, please contact us via Amazon's messaging system. Our customer service team aims to resolve issues within 24 hours.